NUMERICAL PRICE LIST AND INDEX

FOR

KENT-MOORE SPECIAL SERVICE TOOLS

WARRANTY

All tools are warranted for one year against defective material or workmanship, except where warranty certificate accompanies tool.

THIS PRICE LIST SUPERSEDES FORM NO. 63-44 — EFFECTIVE OCTOBER 15, 1963

All prices subject to change without notice

PRICES EFFECTIVE FEBRUARY 1, 1965 — F.O.B. JACKSON, MICHIGAN

Page Numbers refer to Kent-Moore Service Tool Manuals Form No. 64-61, 61-1.

NOTE: WHEN ORDERING, USE TOOL NUMBER AND COMPLETE DESCRIPTION

SERVICE PARTS

For availability and prices on service parts not listed on this price list — write direct to:

Service Tool Division
Kent-Moore Org., Inc.
28635 Mound Road
Warren, Michigan 48092

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 129-2	Guide Reamer	4	45	¼	$ 4.50
J 136	Bushing Press	*	*	10½	36.85
J 267	Guide Remover	4	45, 68	¾	2.95
J 269	Guide Remover	4	46, 68	½	5.00
J 270-6	Driver Head	32	3	2	5.80
J 270-7	Driver Head	*	3	1¾	5.75
J 270-13	Seal Replacer	37	*	¾	5.35
J 270-14	Driver Head	32	3	2	8.20
J 270-22	Bearing Replacer	32	*	1½	7.30
J 358-1	Plate Holder	57	1, 3, 31	3	13.20
J 452-G	Wheel Puller	*	*	10	24.50
J 508	Carb. Jet Extractor	*	*	½	1.15
J 526	Press Plate	*	*	8¼	18.95
J 544	Checking Scale	40	24, 26, 28	½	9.90
J 553	Spg. Bush. Rem. & Inst.	*	*	3	24.45
J 554-C	Peening Fixture	47	3	44½	81.90
J-554-3	Peening Tool (7/16")	47	3	1 5/16	6.75
J-554-4	Peening Tool (9/16")	47	3	1¼	6.75
J-554-11	Peening Tool (⅜")	47	3	1¼	6.75
J 554-18	Staking Tool (½")	47	3	1¼	7.50
J 628	Brake Bleeder Tube	48	23	¼	1.75
J 728	Hub & Dust Cap. Rem.	*	*	¾	2.50
J 736	Wheel Puller	*	*	7	27.40
J 787	Bending Tool	*	*	¼	1.10
J 855	Univ. Joint Replacer	31	*	2	8.95
J 865	Univ. Joint Replacer	*	*	2	8.95
J 870	Lock Nut Wrench	*	4, 28	3¾	25.10
J 918	Oil Seal Puller	*	1, 4	9	61.60
J 932	Snap Ring Pliers	57	31	¼	7.25
J 933-02	Retainer Wrench	16	31	½	5.25
J 936	Press Plate	16	31	2½	10.10
J 937	Clutch Gear Puller	16	31	5	21.85
J 941	Bearing Replacer	32	*	3	7.70
J 943	Oil Seal Remover	37	4	1	8.00
J 947-P	Axle Brg. Remover	37	*	27	56.95
J 966	Timing Cover Gauge	2	46	1¼	15.00
J 971	Gear Remover	4	43	4	13.50
J 972	Diff. Nut Wrench	32	1, 4	¾	7.25
J 995	Oil Seal Replacer	2	*	3	6.45
J 996	Press Plate	32	1, 4	1¼	5.35
J 1013	Adjusting Lever	*	*	¼	5.30
J 1048	Clutch Gauge	16	42	1½	9.45
J 1089	Guide Replacer	4	*	1½	17.20
J 1126	Trans. Align. Pins (pr.)	16	31	¼	5.10
J 1135	Metering Rod Gauge	*	*	1/16	.50
J 1137	Idle & Unload. Iron	10	*	¼	1.25
J 1218	Piston Vise	7	49, 92	4¾	36.20
J 1226	Pulley Puller	*	52	1½	$ 7.95
J 1227-01	Spring Compressor	*	68, 79	1¼	5.70
J 1241-06	Injector Service Set	*	*	2	38.15
J 1242	Timing Gauge	*	57, 79	¼	1.65
J 1243	Spray Tip Reamer	*	79	¼	2.50
J 1261	Vise Jaws	*	79	2½	9.95
J 1262	Wheel Puller	*	*	3	9.50
J 1264	Ten. Wrench (0-200#)	57	92	3	20.00
J 1265	Metering Rod Gauge	*	*	1/16	.50
J 1270-01	Wheel Remover	41	*	8	25.95
J 1273	Stud Remover	*	24	½	2.25
J 1290	Spring Lifter	*	*	½	3.95
J 1291-02	Bushing Cleaner	*	79	½	2.75
J 1293	Piston Pin Installer	7	*	½	8.40
J 1298	Bearing Puller	16	*	3½	35.00
J 1306	Retainer Ring Remover	*	*	1/16	.50
J 1313	Ten. Wrench (0-150#)	57	92	2¼	18.60
J 1315	Ten. Wrench (0-25#)	57	92	1	20.00
J 1318	Bearing Remover	*	4	17½	24.60
J 1319-04	Compression Gauge	*	57	2¾	45.90
J 1343	Ball Retain. Ring Inst.	*	*	1/16	.80
J 1354	Oil Seal Replacer	21	*	4	10.80
J 1357	Oil Seal Replacer	32	*	11	31.00
J 1359	Oil Seal Expander	*	57	9½	21.50
J 1365-A	Spanner Wrench	*	*	11/16	4.15
J 1376	Pitman Arm Puller	*	*	3	7.25
J 1388	Carb. Throt. Valve Ga.	*	*	1/16	.80
J 1389	Adjusting Tool	*	*	1/16	.60
J 1407	Pump Spring Load. Unit	*	*	5/16	.45
J 1429-01	Valve Guide Remover	4	*	11/16	4.45
J 1434	Trans. Guide Pins (pr.)	16	*	¼	4.70
J 1435	Clutch Align. Arbor	16	*	1½	6.15
J 1436-A	Oil Seal Puller	37	*	10¼	31.75
J 1439	Pin. Bearing Remover	*	4	¾	8.05
J 1448	Bearing Puller	7	49	¾	14.25
J 1453-01	Pin. Bearing Remover	16	4, 31	1¾	21.55
J 1459-B	Rear Unit Holder	21	35	¾	3.75
J 1465	Dial Indicator Extension	*	35	9/16	1.95
J 1471	Spring Installer	*	75	1¾	6.65
J 1475	Pump Stroke Gauge	*	*	¼	3.90
J 1503-3A	Jet Wrench Handle	*	*	1/16	1.20
J 1508-02	Fuel Pump Set	*	79	7½	25.35
J 1513-02	Bushing Remover	*	57	10	52.30
J 1522	Bushing Driver	7	49	2¾	6.85
J 1537	Spring Compressor	21	35	1	7.80
J 1541	Depth Gauge	*	*	1	9.55
J 1561	Metering Jet Wrench	*	*	1/16	1.85

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 1592	Brg. Lock Wrench	*	*	1	$ 4.95
J 1594	Steer. Wheel Adapt.	*	*	3	41.35
J 1614	Bushing Remover	40	24	2¾	8.40
J 1615	Bushing Remover	*	24, 26	3½	8.65
J 1617	Bearing Loader	16	32	¾	3.40
J 1619	Bearing Puller	*	4, 32	4½	31.60
J 1625	Alignment Arbor	16	*	1½	8.80
J 1644	Hub Puller	47	*	11½	50.10
J 1644-S	Hub Puller	47	*	9⅝	46.00
J 1646	Depth Gauge	*	*	1	13.50
J 1652-01	Nut Wrench	*	86	½	6.00
J 1682-01	Service Tool Set	*	*	6	39.75
J 1686-02	Ream Fixture	*	57	49	145.00
J 1693-02	Servo. Adj. Gauge	21	35	1	13.00
J 1698-02	Blower Feelers	*	75	½	6.05
J 1736	Valve Insert Repl.	*	68	2	12.25
J 1815	Clutch Adj. Gauge	*	*	¼	3.85
J 1853	Timing Gauge	*	57, 79	¼	1.65
J 1859-02	Wheel Puller	41	*	2	21.85
J 1902-01	Cam. Gear Puller	*	57	4¾	19.80
J 1903	Cam. Gear Replacer	*	57, 73	3	11.70
J 1907	Bearing Remover	*	87	2	4.35
J 1918-02	Cyl. Liner Remover	*	57	13	34.75
J 1927-01	Alignment Studs	*	57	1½	9.75
J 1928-01	Stud Wrench	*	68	1	11.50
J 1930	Oil Remover	*	73	¾	2.55
J 1932	Bearing Wrench	*	87	5	11.40
J 2034	Valve Guide Remover	4	*	1¾	20.65
J 2037	Pinion Driver	32	*	1¾	9.00
J 2040	Transmission Yoke	16	*	1¼	9.35
J 2044	Supp. Arm Spread	45	*	2¾	13.80
J 2045	Clutch Align. Tool	16	*	1¼	28.25
J 2092	End Play Tool	32, 37	*	1½	4.75
J 2100-01	Bearing Replacer	32	*	2¼	9.75
J 2104-01	Bearing Replacer	32	*	2½	10.65
J 2130-B	Nozzle Check. Tool	9	*	7¾	52.40
J 2162	Pitman Arm Puller	44	*	2	12.50
J 2170	Oil Seal Installer	21	35	5	11.75
J 2173	Drum Spacer	21	35	1	2.95
J 2174	Retainer Bracket	21	35	¾	1.70
J 2175	Swaging Set	21	*	4½	21.50
J 2182	Retainer Remover	21	*	¾	4.25
J 2183	Rivet Set	21	35	2	8.15
J 2184	Socket Set	21	35	¾	5.25
J 2187	Carrier Assy. Hold.	21	35	5	7.05
J 2189	Weatherstrip Set	*	20	1¼	31.85
J 2190	Holding Fixture	21	*	5½	39.90
J 2191	Gear Spacer	*	*	¾	1.65
J 2204	Bearing Installer	31	4	2¼	17.35
J 2222	Bearing Nut Wrench	*	4, 28	3	18.75
J 2223-01	Wheel Race Driver	*	4	4¼	12.75
J 2224	Press Plate	*	1, 4	1¾	4.35
J 2225	Press Plate	*	4	1½	4.35
J 2226	Bearing Replacer	*	*	3 3/16	12.50
J 2228	Press Plate	*	32	1½	14.45
J 2229	Press Plate	*	1, 5	1¾	18.60
J 2231	Seal Replacer	*	*	4½	7.10
J 2241-01	Bearing Puller	32	*	5½	32.55
J 2244	Bearing Remover	*	*	2	10.40
J 2245	Bearing Remover	32	*	1	16.30
J 2494	Dial Ind. Assembly	2	*	¼	5.95
J 2497-01	Bearing Remover	32	*	4¾	20.50
J 2498	Bearing Remover	37	*	8½	27.45

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 2532	Bearing Replacer	32	*	3⅛	$ 11.50
J 2534-01	Bearing Cup Replacer	*	*	3¾	10.40
J 2542	Valve Guide Ream.	*	*	¾	2.90
J 2544-01	Linkage Adjusting Pin	21	*	¾	.90
J 2545	Checking Gauge	21	36	2	6.35
J 2554	Oil Seal Driver	*	5	3	7.20
J 2565	Brg. Rem. & Repl.	41	24, 26	3	18.10
J 2571-B	Pinion Brg. Wrench	*	*	10¼	22.80
J 2576	Univ. Joint Remover	*	5	3¾	10.85
J 2586	Hub Check. Gauge	*	*	3	6.60
J 2587	Trans. Check. Gauge	21	36	3	11.45
J 2590-02	Spring Compressor	21	*	7¼	35.05
J 2591-01	Transmission Link	22	*	¼	2.40
J 2592	Stator Tool	22	*	¼	1.35
J 2595	Trans. Band Inst.	22	*	1/16	2.60
J 2596-A	Convert. Clear. Gauge	*	*	1¾	11.95
J 2597	Oil Seal Installer	*	*	1	9.85
J 2619	Slide Hammer Assy.	57	5, 26, 32 36, 76, 92	9	12.05
J 2623	Oil Seal Installer	22	32	2	17.10
J 2624	Oil Pump Set	*	73	2	47.25
J 2626	Oil Seal Replacer	37	*	2½	11.95
J 2631-01	Trim Pad Depresser	51	*	¾	2.95
J 2637	Holding Tool	*	5	3½	13.55
J 2648	Feeler Gauge Set	22	*	¼	1.25
J 2650	Backlash Gauge	*	*	¾	4.95
J 2655	Trans. Cap Remover	22	*	½	4.50
J 2659	Holding Tool	*	*	3½	11.70
J 2667	Brg. Rem. & Repl.	*	32	6½	51.10
J 2668	Idler Gear Bush.	*	32	3	13.35
J 2669	Clutch Gear Remover	*	32	2¼	9.15
J 2670	Spanner Wrench	*	*	2	9.50
J 2681	Servo Adj. Tool	22	36	4	21.50
J 2682	Burr Remover	52	*	¼	9.65
J 2730	Lock Ring Installer	4	*	¼	1.55
J 2767	Seal Insert. Installer	53	*	¼	6.55
J 2772	Headlining Installer	51	*	¼	2.25
J 2787	Rear Bearing Remover	*	32	4	44.10
J 2895	Lock Screw Remover	16	*	¾	7.20
J 2927-01	Wheel Puller	41	24, 26	3	29.60
J 2934	Press Plate	32	*	1	18.65
J 2936-A	Brg. Cup Remover	*	*	½	5.35
J 2937	Brg. Cup Installer	32	*	1½	6.45
J 2938	Brg. Cup Remover	*	*	¾	3.95
J 2939	Brg. Cup Installer	*	*	1	5.35
J 2940	Driver Handle	33	46	2½	3.80
J 2958	Control Arm Remover	45	*	1	6.20
J 2959	Gear Puller	9	*	¾	10.95
J 2963	Stud Remover	*	*	4	12.10
J 2980-B	Monoxivent	59	*	28	68.15
J 2980-56	Tunnel Assembly	*	*	22	29.75
J 2980-61	Hose Guide Assembly	*	*	9½	38.40
J 2982	Wheel Puller	*	*	¾	11.50
J 2984	Prop. Shaft Puller	*	*	1¾	18.50
J 2986-01	Axle Brg. Remover	37	*	20	75.60
J 2995	Snap Ring Installer	16	*	3¼	13.00
J 2996	Bushing Replacer	22	*	1½	5.15
J 2997	Bushing Remover	22	*	2½	5.25
J 3042	Transmission Yoke	16	*	1	10.15
J 3044-01	Wheel Puller	41	*	1	17.10
J 3045-A	Convert. Clear. Gauge *	22	*	1¾	11.95
J 3049	Valve Lifter Remover	4, 16	*	½	4.35
J 3051	Gear Puller	*	*	5¾	27.50

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 3057	Bushing Reamer (.923")	*	1	3	$ 10.95
J 3060	Valve Guide Ream.	4	*	¼	4.60
J 3062	Valve Guide Remover	4	*	¾	4.10
J 3063	Cam Bearing Set	*	*	15¼	111.30
J 3064	Cyl. Head Holder	4	*	9½	35.00
J 3065-C	Throttle Gauge	*	*	3	5.75
J 3066-A	Valve Guide Installer	4	*	3¼	8.50
J 3067	Oil Seal Replacer	*	5, 29	6¼	8.50
J 3071-01	Piston Reamer Set	*	57	15½	108.75
J 3074	Valve Lifter Test	4	*	¼	4.25
J 3078-01	Water Pump Wrench	*	73	½	9.60
J 3079-03	Carburetor Kit	*	53	4	32.95
J 3085	Shift. Gauge	*	*	¼	2.35
J 3087-01	Holding Plate	*	68	5½	29.00
J 3091-01	Valve Remover	*	68	2¾	38.70
J 3092-01	Push Rod Remover Set	*	68	½	4.75
J 3154-04	Oil Seal Remover Set	*	87, 92	18	85.50
J 3172	Gauge Set	*	49, 57, 92	¼	2.25
J 3174-01	Piston Feeler Gauge	*	*	¼	4.70
J 3179-1	Lapping Block	*	92	8	18.50
J 3180	Nut Wrench	*	73	¼	2.50
J 3185	Snap Ring Remover	16	32	½	3.65
J 3189	Bushing Reamer	46	*	1¾	8.40
J 3197	Bushing Remover	22	*	¾	22.35
J 3211	Impeller Puller	9	*	1	32.45
J 3212	Hub Cap Wrench	*	*	1½	.95
J 3213-01	Valve Spring Tool	4	*	2	22.60
J 3222	Rear Axle Jack	*	*	27⅝	48.35
J 3224	Bolt Guide Set	*	*	¼	3.50
J 3232	Bearing Adjuster	33	*	¾	3.95
J 3234	Brg. Cup Installer	33	5	1¾	7.50
J 3243	Pin. Brg. Cup Installer	33	*	1½	8.25
J 3248	Bearing Installer	33	5	1	4.75
J 3250-01	Bearing Puller	33	*	3¾	34.80
J 3269	Clear. Check. Tool	*	46	2	29.50
J 3272-03	Piston Inserter	*	57	8	28.25
J 3274-A	Wheel Puller	41	*	2¼	12.85
J 3285	Bearing Replacer	*	88	4	9.65
J 3287	Bearing Replacer	*	88	5½	9.65
J 3289-01	Holding Fixture	33	5	19½	43.60
J 3289-20	Base & Screw Assembly	33	5	8½	9.90
J 3295	Ball Stud Remover	44	25	½	3.95
J 3296	Cement Gun	53, 59	20, 92	¾	3.10
J 3299	Pinion Brg. Remover	*	*	6½	14.95
J 3310	Bending Tool	22	*	3	7.95
J 3361-01	Trans. Assy. Fixture	18	*	56	106.20
J 3362	Race Installer	18	*	¾	8.85
J 3364	Clutch Spr. Comp.	18	*	1	6.30
J 3365	Servo Ring. Comp.	18	*	¾	5.95
J 3377	Servo Spring Comp.	18	*	¾	5.45
J 3383	Lock Spring Remover	18	*	¾	8.60
J 3387	Pilot Stud Set	18	*	¾	11.80
J 3409	Diff. Rep. Stand	*	1, 5, 38, 93	100	87.90
J 3420	Pinion Yoke Remover	*	5	9½	9.55
J 3453	Pinion Yoke Bar	*	5, 36	10¼	36.25
J 3455	Cylinder Stud Set	2	*	¼	2.95
J 3493	Puller Set	*	5	60	183.90
J 3816	Brg. Rem. & Repl.	*	6	6	8.65
J 3822-02	Axle Seal Installer	*	6	54¼	119.30
J 3841	Diff. Support	*	42	¾	11.50
J 3886	Valve Guide Remover	*	46, 68	¾	7.75
J 3890	Valve Insert. Tool	*	46	2½	6.50
J 3895	Clutch Align. Tool	*	42	2¼	9.70

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 3936-01	Piston Ring Clean.	7	49	2	$ 4.00
J 3940	Pin. Gauge Cup Rem.	*	1, 6	1¾	12.10
J 3941	Diff. Support Fixture	*	6	17½	19.95
J 3942	Brg. Rem. Sleeve	*	6	4¾	10.90
J 3960	Oil Seal Installer	*	43	1¾	9.15
J 4140-02	Valve Remover	*	68	2¾	43.50
J 4142	Valve Seat Installer	*	68	2¾	10.75
J 4143	Valve Guide Installer	*	68	¾	7.35
J 4144	Valve Stem Replacer	*	68	1	6.00
J 4147-01	Brg. Rem. & Replacer	40	*	1¼	19.30
J 4159	Cyl. Head Hooks	2	43	2½	10.20
J 4160-A	Valve Lifter Remover	4	46	1¾	3.60
J 4161	Bushing Rem. & Repl.	46	*	2¼	39.10
J 4174	Univ. Joint Remover	31	*	1¼	5.75
J 4177	Oil Seal Replacer	*	*	4¼	16.30
J 4184	Timing Gauge	*	57, 80	½	4.70
J 4185-01	Gear Puller	*	73	½	6.45
J 4194	Oil Seal Installer	*	57	6¼	35.00
J 4195	Oil Seal Expander	*	57	1	22.50
J 4211	Nut Wrench	*	86	½	3.00
J 4212	Nut Wrench	*	86	¾	3.70
J 4213	Lock Nut Wrench	*	86	¾	4.45
J 4217-02	Injector Vice Jaws	*	80	3	9.85
J 4235-01	Cyl. Head Fixture	*	68	14½	28.45
J 4236-01	Hub. & Pump Tool	*	38, 88	14¼	39.95
J 4237	Stator Assembly	*	38, 88	1¾	10.25
J 4239	Oil Seal Expander	*	58	7	27.75
J 4242	Fuel Wrench	*	73, 80	½	2.80
J 4245	Snap Ring Pliers	57	26	¼	2.65
J 4254	Rotor Rem. & Inst.	*	75	2	38.25
J 4258	Torque Tube Remover	31	6	5	15.95
J 4260-02	Transmission Gauge	18	*	3	15.20
J 4261	Modulator Assy. T1	18	*	¼	1.50
J 4262	Transmission Sling	18	*	¼	7.10
J 4263	Front Pump Driver	18	*	9¾	26.30
J 4264	Oil Filler Funnel	18, 57	*	2	9.95
J 4266	Cyl. Head Hooks	2	*	2½	7.35
J 4268	Trans. Press. Gauge	*	21	1½	6.85
J 4270	Trans. Press. Gauge	*	*	1½	9.50
J 4274	Valve Lifter Tool	*	*	½	4.95
J 4275	Trans. Brg. Remover	19	*	3¼	12.95
J 4277	Servo Band Wrench	19	*	1¼	12.50
J 4279	Transmission Hoist	19	*	25	82.35
J 4281	Flywheel Index. Tool	19	*	2	8.75
J 4283	Spline Fixture	*	*	4½	47.50
J 4284	Transmission Studs	29	*	¼	1.25
J 4285	Brake Adj. Tool	29	*	¼	16.55
J 4286	Converter Flange	29	*	13	25.50
J 4297	Injector Cleaner Brush.	*	80	¼	.40
J 4298-01	Injector Cleaner	*	80	¼	2.70
J 4299-04	Injector Service Kit	*	80	2	38.90
J 4310	Injector Cleaner	*	80	¼	4.95
J 4353	Hydra. Check. Fixture	22	36	7	21.35
J 4354	Stator Assembly	*	38, 88	4⅛	22.75
J 4355-01	Hub & Pump Tool	*	38, 88	19½	21.65
J 4383	Clutch Brg. Remover	7	76	¾	22.25
J 4384-02	Lock Nut Wrench	*	88	24¾	55.90
J 4385-01	Lock Nut Wrench	*	88	20	**
J 4390	Speedo Gear Remover	16	*	1¾	9.40
J 4393	Vacuum Cylinder Driver	*	*	¼	.90
J 4394	Gauge	*	*	¼	.65
J 4395	Bending Tool	*	*	½	1.35
J 4400	Torque Rod Set	*	6, 28	37	165.00

*Not Illustrated **Special Order Only—Not Stocked—Quote on Request

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 4414	Transmission Brg. Set	*	32	20	$218.15
J 4415	Servo Spring Comp.	22	36	5	14.70
J 4420	Flywheel Wrench	22	*	¾	4.45
J 4448	Torque Wrench Adapt.	22	36	¾	1.80
J 4460	Piston Rg. Comp (3 9/16″)	7	50	1	3.00
J 4464	Carb. Float Lev. Ga. (11/64″)	*	*	¼	.50
J 4465	Choke Unload. Ga. (7/32″)	*	*	¼	.50
J 4476-01	Cam. Brg. Remover	2	43	35	138.60
J 4477-01	Ster. Tool Set	45	*	11	17.00
J 4484	Oil Seal Remover	*	*	2½	4.95
J 4485	Oil Seal Installer	16	*	2¾	8.10
J 4486	Prop. Shaft Wrench	*	*	1	12.95
J 4490	Pit. Arm Puller	44	*	2	9.25
J 4494-02	Cyl. Comp. Gauge	*	58	3¾	50.50
J 4497-01	Snap Ring Remover	*	88	6	49.50
J 4498	Inlet Rem. & Rep.	*	*	¼	1.55
J 4511	Idler Shaft Repl.	*	88	3	55.80
J 4512	Eyebolt	*	88	3	41.65
J 4513	Converter Eyebolt	*	88	7¼	21.20
J 4514	Lock Nut Wr. (3.688″)	*	88	3¼	23.90
J 4515-01	Lock Nut Wrench (3″)	*	88	17¾	44.05
J 4516	Pilot Studs	*	89	¾	5.75
J 4518	Oil Seal Replacer	*	89	2¾	22.30
J 4519	Bushing Replacer	*	89	1½	19.50
J 4520	Bushing Remover	*	89	1	15.30
J 4521	Ream. & Bush. Set	*	89	1	18.60
J 4523-01	Bearing Replacer	*	38, 89	3	16.80
J 4524	Bearing Replacer	*	89	3	16.80
J 4525	Adj. Wrenches (9/16″)	*	86	¼	1.90
J 4531-01	Transmission Yoke	16	*	¾	5.75
J 4540	Tappet Gauge Set	*	*	¼	1.95
J 4543	Magnetic Wrench	19	*	¼	3.25
J 4548	Prop. Shaft. Remover	*	6	20	38.95
J 4550	Pinion Set Gauge	*	6	20	121.45
J 4550-6	Basic Tool Set	*	6	12	104.55
J 4550-7	Box Assembly	*	*	5½	16.90
J 4551	Seal Punch	10	*	¼	4.15
J 4552	Bending Tool	10	*	½	2.95
J 4555-02	Pinion Gauge	*	*	57	310.00
J 4558	Flywheel Remover	*	36, 89	5¼	24.10
J 4565	Brg. Rem. & Repl.	*	7	3	8.65
J 4566-01	Piston Ring Comp.	*	58	8	40.25
J 4582	Nut Wrench	52	*	½	2.95
J 4583	Windshield Seal Brg.	53	*	¼	2.65
J 4588	Brg. Nut Remover	*	89	1	6.55
J 4590-02	Monoxivent Outlet	59	*	1	9.15
J 4590-03	Monoxivent, Jr.	59	*	15	31.70
J 4599	Pinion Assy. Tool	19	*	½	4.40
J 4600	Hog Ring Pliers (45°)	51	*	½	5.50
J 4608	Locating Gauge	*	73	¾	7.80
J 4609	Locating Gauges	*	73	¼	5.25
J 4610	Bushing Replacer	*	73	1½	17.50
J 4611	Bushing Remover	*	74	1¾	17.50
J 4612	Bushing Reamer	*	74	2	11.00
J 4613	Bushing Remover	*	74	¼	9.70
J 4626	Ring Gear Riveter	*	1. 7	123	234.75
J 4627	Valve Grinder Set	*	68, 93, 101	1¼	22 85
J 4628	Flywheel Reamer	2	43	¼	3.50
J 4637	Trim Panel Remover	51	*	¾	5.65
J 4641-01	Inj. Recond. Set	*	80	22	235.00
J 4643	Universal Puller	*	102	5½	31.20
J 4644-1	Bushing Remover	*	86	¾	$ 7.50
J 4644-2	Bushing Installer	*	86	¼	4.45
J 4644-3	Bushing Burnisher	*	86	½	28.00
J 4646	Truarc Pliers (#5 Int.)	*	86	½	3.05
J 4648	Bearing Replacer	*	86	1	4.45
J 4649	Bearing Replacer	*	86	1	11.15
J 4653	Governor Wrench	16	*	¾	3.25
J 4656	Checking Fixture	2, 19	*	½	18.70
J 4661	Wrench Set	*	69	¾	13.45
J 4664	Bearing Remover	*	86	8	6.30
J 4666	Reamer Set	*	58	64	153.60
J 4668	Thrust Wash. Gauge	29	*	8¾	28.35
J 4670-01	Clutch Sprg. Comp.	22	36	4	8.75
J 4673	Valve Guide Remover	4	*	3	21.00
J 4674-01	Cylinder Head Holder	2	*	15	20.95
J 4685	Bearing Remover	*	87	¼	13.15
J 4691	Adjust. Wrench	45	*	¼	13.15
J 4693-02	Pinion Gauge Set	*	*	35	230.05
J 4700	Oil Seal Remover	*	89	2½	42.50
J 4707	Brake Adj. Tool	48	23	¼	1.50
J 4710-C	Flywheel Align. Set	22	*	1¾	21.00
J 4731	Governor Gauge	22	36	1	8.25
J 4732-01	Eng. Support Fixture	2, 22	*	14½	36.90
J 4734	Windshield Replacer	53	*	¾	12.75
J 4735	Brake Adj. Tool	48	*	¼	1.50
J 4741-02	Nut Wrench	*	89	1¼	30.65
J 4743	Pinion Yoke Remover	*	1, 7	7½	8.25
J 4746	Piston Rem. Tool	*	90	½	12.75
J 4747	Seal Driver	*	90	3¼	33.35
J 4749	Bearing Nut Wrench	*	90	¾	6.85
J 4752	Piston Seal	22	36	½	1.75
J 4756-04	Engine Tune-up Kit	*	58	1	22.20
J 4757	Microm. Ball Attach.	57	93	¼	1.35
J 4761	Idler Shaft Remover	*	*	¼	3.50
J 4768	Cam Gear Installer	*	58	1¾	8.65
J 4773	Float Level Gauge	*	*	¼	.50
J 4778-01	Cyl. Liner Remover	*	58	14	34.55
J 4780	Gear Installer	*	74	¾	3.80
J 4791	Bearing Remover	*	39, 90	5½	24.40
J 4794-01	Universal Puller	*	52, 102	1½	9.50
J 4822	Valve Reamer (.343″)	4	*	¼	4.60
J 4824-01	Valve Insert Rem.	*	69	2¾	32.40
J 4830-02	Bearing Remover	29, 16, 28	*	1¼	14.90
J 4832-A	Fly. Hous. Tool Set	22	*	10½	50.55
J 4833	Fly. Hous. Tool Set	*	*	7	14.95
J 4850	Brg. Rem. & Inst.	*	39, 90	2	15.30
J 4852	Brg. Sleeve Puller	*	39, 90	1	21.90
J 4853	Brg. Sleeve Installer	*	39, 90	6	34.00
J 4856	Oil Seal Installer	*	*	2	13.65
J 4869	Speedo Gear Remover	16	32	6	15.15
J 4870	Universal Puller	*	102	2½	15.85
J 4871	Univ. (Large) Puller	*	102	8	30.35
J 4873	Spring Wrench	*	*	¼	8.60
J 4880	Truarc Pliers (#22)	57	87, 93	¼	2.30
J 4889	Pump Recond. Set	*	74	4	33.10
J 4894-01	Piston Inserter	*	58	7½	34.60
J 4895-A	Piston Pin Retainer	*	58	¼	1.50
J 4897-03	Cyl. Comp. Gauge	*	58	2½	44.90
J 4898	Cam Bushing Installer	*	58	6¾	43.80
J 4920	Torque Conv. Tool	19	*	2½	10.75
J 4969	Inj. Timing Gauge	*	58, 80	¼	1.60
J 4970-02	Bushing Reamer Set	*	58	20	107.75
J 4971-01	Conn. Rod Ream. Set	*	58	40	137.50

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 4972	Bushing Installer	*	59	¾	$ 19.90
J 4973	Injector Holder	*	80	2¾	13.70
J 4974-02	Injector Service Kit	*	80	2	42.50
J 4982	Socket Wrench	*	81	1¼	7.95
J 4983-01	Socket Wrench	*	81	1	2.95
J 4984	Socket Wrench	*	81	½	20.65
J 4985	Tip Seat Reamer	*	81	½	19.80
J 4986-01	Tip Seat Reamer	*	81	½	16.25
J 4995	Carblast (#16)	*	*	65	16.80
J 4996-01	Cyl. Lin. Remover	*	59	12¼	34.65
J 5066-GA	Monoxivent	59	*	43	66.80
J 5066-15	Floor Outlet	*	*	15	21.70
J 5066-62	Hose & Intake	*	*	14	22.55
J 5071	Rear Servo Gauge	22	36	½	1.75
J 5086	Truck Monoxivent (4″).	*	*	8	24.50
J 5092	Plunger Remover	*	*	¼	6.20
J 5099	Lifter Cleaner Brush	4	*	¼	.45
J 5119	Injector Tip Gauge	*	81	7¼	58.55
J 5120	Choke Idle Gauge	*	*	¼	1.90
J 5124	Bush. Rem. & Repl.	*	59	3	19.50
J 5127-01	Carb. Tool Kit	*	*	1	15.40
J 5128	Flywheel Tool Set	*	*	1¾	7.35
J 5131	Bushing Reamer Set	*	59	11	111.00
J 5133	Clutch Spr. Comp.	19	*	1¼	7.75
J 5139	Bearing Remover	22	*	¼	.90
J 5152-01	Bush. Inst. & Rem.	*	59	17	63.75
J 5153-01	Bush. Inst. & Rem.	*	59	13	64.15
J 5154	Oil Seal Installer	19, 22	7, 32, 36	3¼	8.95
J 5157	Regulator Clamp	*	*	1	1.75
J 5158-02	Valve Guide Remover	4	46	2¾	8.55
J 5172	Snap Ring Pliers	57	36	½	6.35
J 5174	Starter Switch	*	*	1	3.95
J 5175	Bearing Assy. Tool	9	52	1½	4.50
J 5176-01	P.S. Check. Gauge	42	*	2	26.25
J 5177	Exhaust Valve Remover.	*	*	1¼	7.65
J 5178	Steering Wheel Scale	57	*	¾	10.50
J 5182	Retainer Collar	42	*	¾	3.30
J 5184	Generator Scale	14	55	¼	7.50
J 5185-1	Spanner Wrench	56	*	¼	4.70
J 5186-A	Piston Ring Comp.	42	*	¼	2.60
J 5188	Seal Installer	42	26	1½	6.80
J 5189	Bearing Installer	42	26	5	5.20
J 5190-01	Bearing Remover	40	25	½	10.75
J 5191	Bearing Installer	42	*	1¼	4.75
J 5192	Belt Tightener	*	*	½	2.75
J 5193	Piston Rod Inserter	42	*	¼	2.80
J 5195	Idle Gauge	*	*	¼	1.65
J 5196	Choke Gauge	*	*	¼	1.80
J 5197	Bending Tool	10	*	¼	1.90
J 5198	Float Level Gauge	*	*	¼	.85
J 5202-B	Monoxivent "Y" Assy.	59	*	24	33.00
J 5206	Adapter Studs	*	*	¼	3.60
J 5207	Snap Ring Pliers	57	*	½	3.50
J 5209	Cam Installer	*	*	½	6.00
J 5213	Belt Tightener	*	*	¼	4.45
J 5214	Adapter for J 5526	19	*	14¼	25.50
J 5223-02	Pinion Set Gauge	33	*	9¼	49.50
J 5224	Front Spring Comp.	*	*	3¾	27.20
J 5227	Float Gauge (5/16″)	*	*	¼	.50
J 5228	Float Gauge (¼″)	*	*	¼	.50
J 5231-01	Ax. Hous. Spreader	37	7	20	34.75
J 5236	Bearing Remover	*	*	1½	16.95
J 5237	Clutch Spring Tester	*	42, 93	22	97.50

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 5238	Lifter Disassy. Tool	*	*	½	$ 3.95
J 5239	Bolt Guide Set	7	50	¼	6.10
J 5240	Valve Guide Installer	4	46	3	6.60
J 5250	Oil Seal Installer	2	43	3¾	9.65
J 5251-A	Cyl. Head Hold. Fixture	4	*	18	49.45
J 5254	Bearing Seal Installer	40, 42	*	1½	9.25
J 5255	Pitman Seal Installer	42	*	1	5.95
J 5256	Steel Hose (4″x12′)	*	*	36	68.75
J 5259	Brg. Nut Wrench	42	*	½	3.35
J 5260	Bending Tool	*	37	2	7.30
J 5261	Tachometer Adapter	*	59	1	30.00
J 5268	One Gal. Inj. Oil	4	*	1½	2.15
J 5273	Reaming Fixture	*	59	7½	68.75
J 5283-A	Valve Align. Tool	*	*	¾	2.75
J 5286-01	Injector Set	*	81	22	97.50
J 5288	Exhaust Blower Assy.	59	*	9	55.00
J 5290	Steering Wheel Puller	41	*	½	7.35
J 5292-01	Bearing Replacer	33	*	3	6.80
J 5297-01	Autronic-Eye Tester	59	*	14	48.00
J 5324	Cont. Arm Spreader	*	*	4¾	8.95
J 5338	Dyna. Convert. Installer	*	*	¾	4.40
J 5339	Dial Ind. Ext.	57	*	1½	2.00
J 5341	Tool Set	*	1, 7	35	124.10
J 5345-03	Diesel Tune-up Kit	*	59	3	39.80
J 5347	Cylinder Check. Gauge	*	59, 93	4¾	192.70
J 5355	Tachometer Adapter	*	59	¼	9.80
J 5356	Crank. Pulley Remover.	*	59	6	48.75
J 5364-A	Bearing Installer	*	*	¾	5.70
J 5365	Brg. Cone Remover	33	*	3½	10.95
J 5372-01	Axle Hous. Spread.	37	*	14½	26.90
J 5381	Bushing Remover	19	*	1	28.30
J 5382	Bushing Replacer	19	*	2½	8.25
J 5384	Conv. Holding Tool	19	*	¼	1.50
J 5385	Valve Posit. Gauge	19	*	¼	.75
J 5386	Oil Seal Driver	19	*	2	9.35
J 5388	Torque Conv. Tool	*	*	1¼	6.85
J 5389	Modulator Assy. Tool	19	*	¼	1.25
J 5390	Stator Race Installer	19	*	1¾	7.80
J 5391	Throttle Posit. Gauge	*	*	¼	4.40
J 5395-01	Oil Seal Installer	33	*	3¼	10.80
J 5397-A	Hood Spring Remover	51	*	1½	6.25
J 5398	Belt Tension Adj.	42	*	¼	3.25
J 5399-A	Float Level Gauge	*	*	¼	.95
J 5403	Snap Ring Pliers	19, 57	26, 87, 93	¼	2.30
J 5404	Guide Pin Set	48	*	¼	1.85
J 5405-01	Seal Installer	48	*	¼	3.35
J 5406	Piston Assy. Ring	48	*	½	1.95
J 5407	Govern. Gauge (.170″).	*	87	¼	3.40
J 5408	Brg. Rem. & Repl.	*	*	2¾	5.05
J 5413	Conv. Screw Wrench	29	*	½	3.15
J 5418	Charg. Lines (36″)	54	*	½	2.25
J 5420	Gauge Adapter	54	*	¼	1.40
J 5421	Thermometer	54	*	¼	2.95
J 5424	Tube Wrench Set	54	*	¾	4.65
J 5424-1	Tube Wrench (9/16″)	*	*	¼	2.45
J 5424-2	Tube Wrench (¾″)	54	*	½	2.95
J 5426	Valve Key (3/16″)	54	*	¼	1.00
J 5427	Valve Key (¼″)	54	*	¼	.85
J 5428-02	Vacuum Pump	54	*	35	65.00
J 5428-11	1 Qt. 150 Viscos. Oil	54	*	2½	.55
J 5430	Ignit. Nut Wrench	*	*	¼	4.15
J 5433-01	Power Brake Stand	48	*	2¾	13.95
J 5437	Valve Guide Clean.	*	69	¼	4.80

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 5438	Feeler Gauge Set	*	50, 59	½	$ 15.00
J 5439-02	Pinion Gauge Set	*	7	70	354.15
J 5440	Bearing Driver	42	*	¾	4.65
J 5441	Seal Installer	29	28	1¼	3.25
J 5448-06	Holley Carb. Kit	*	53	3½	29.85
J 5453	Goggles	54	*	¼	2.50
J 5454	Spanner Wrench	*	*	¾	3.30
J 5457	Float Lev. Gauge (⅛″)	*	*	¼	.50
J 5458	Float Lev. Gauge (3/16″)	*	*	¼	.50
J 5462-01	Gauge Hook-up Set	54	*	1¼	12.50
J 5463-01	Bearing Installer	*	*	1	4.15
J 5465	Float Level Gauge	*	*	¼	.95
J 5468-02	Bush. Recond. Set	*	59	34½	141.75
J 5469-A	Pulley Remover	*	*	3¼	12.50
J 5470	Belt Tightener	*	*	½	4.45
J 5472	Bush. Rem. & Repl.	45	*	14½	29.50
J 5475	Float Level Gauge	*	*	¼	.50
J 5476	Ring. Installer	*	*	¼	1.95
J 5478	Clutch Assy. Fixture	29	*	1½	3.70
J 5481	Lube Test Rod	29	*	¼	2.25
J 5482	Governor Wrench	29	*	¼	2.95
J 5484	Trans. Holding Fixture	29	*	2½	7.45
J 5487	Piston Ring Installer	*	*	¼	9.00
J 5489	Timing Gauge (.090″)	*	*	¼	.90
J 5492	Checking Fixture	*	37	3¼	12.60
J 5494-01	Valve Spring Remover	4	*	1½	27.25
J 5496	Bending Tool	*	*	¼	1.45
J 5500	Hood Spring Wrench	51	*	½	3.30
J 5502	Drive Shaft Remover	*	*	11½	39.50
J 5503	Oil Seal Remover	42	*	1¼	12.50
J 5504	Pitman Arm Puller	44	*	2¼	15.25
J 5510	Float Gauge (9/32″)	*	*	¼	.50
J 5513	Piston Scale	7	50	¾	24.05
J 5514	Yoke Remover	31	*	2½	10.45
J 5515	20# Feel. & Scale	7	*	1	19.55
J 5526	Jack Pad	19	*	8	17.25
J 5538-02	Piston Assy. Tool	7	50	3¾	27.30
J 5540	Piston Feel. & Scale	*	*	¼	10.50
J 5544-01	Hood Spring Remover	*	*	1¾	6.80
J 5547	Cyl. Hd. Wr. (¾″x½″)	2	43	¼	3.25
J 5548	Press. Check. Gauge	42	*	1½	17.25
J 5550	Bearing Remover	*	*	1½	5.25
J 5558	Brg. Rem. & Inst.	9	*	1¼	9.25
J 5559-A	Brg. Rem. & Inst.	2	*	5¾	22.85
J 5562	Bush. Rem. & Repl.	42	*	2½	3.25
J 5563	Pow. St. Adj. Tool	42	*	½	1.50
J 5564	Valve Guide Remover	4	*	1½	4.30
J 5566-04	Pitman Arm Puller	40	*	2	16.75
J 5567	Clutch Adj. Gauge	16	*	1¼	9.40
J 5569	Ring Comp. (4″)	7	50	1¾	4.45
J 5573	Bearing Installer	*	*	½	2.95
J 5574	Belt Tension Tool	*	*	½	3.75
J 5579-01	Gauge Set	*	*	12	267.70
J 5579-1	Ring Gauge	*	60	6	75.00
J 5580-01	Cyl. Gauge Set	*	*	12	267.70
J 5580-1	Ring Gauge	*	60	6	75.00
J 5581-01	Cyl. Gauge Set	*	*	12	302.70
J 5581-1	Ring Gauge	*	60	6	110.00
J 5583	Torque Wr. Adapt.	57	92	½	1.80
J 5584	Piston Ring Compr.	7	*	1¼	3.50
J 5585	Valve Guide Clean.	*	69	¼	5.25
J 5586	Snap Ring Pliers	57	93	1½	8.75
J 5588	Throt. Posit. Gauge	19	*	½	4.80
J 5589	Countershaft Tool	16	*	1½	2.90

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 5590	Trans. Brg. Inst.	9, 16	7, 32, 44	1¾	$ 7.15
J 5592	Trans. Puller Plate	*	*	1	17.35
J 5593	Protector Yoke	*	*	½	15.90
J 5598	Val. Guide Repl. (Int.)	4	*	1¼	5.45
J 5599	Val. Guide Repl. (Exh.)	4	*	1¼	6.10
J 5600	Valve Guide Remover	4	*	½	3.95
J 5601	Ring Comp. (3¾″)	7	*	1	4.25
J 5605	Throttle Fixture	*	*	¾	3.90
J 5606	Piston Ring Tool	*	37	¼	2.45
J 5608	Ring Compressor	*	37	½	3.90
J 5609	Carb. Posit. Gauge	*	37	½	3.95
J 5610	Light Switch Remover	52	*	¼	6.75
J 5619	Seal Inst. (¾″)	*	*	1½	3.75
J 5627	Lock Nut Wrench	*	7	13½	102.15
J 5630	Seal Inst. Tool	*	*	¼	2.95
J 5631-02	Power Steering Gauge	*	26	4½	34.90
J 5633	Lock Nut Wrench	*	37	½	4.65
J 5640	Wire Gauge (.012-0)	*	*	¼	.80
J 5647-02	Pinion Gauge	33	*	22¾	119.90
J 5647-5	Pinion Set. Ga. Disc.	33	*	1¼	4.95
J 5650	Piston Assy. Tool	48	*	½	1.80
J 5651	Float Gauge	*	*	¼	.50
J 5652	Metering Gauge	*	*	¼	.50
J 5655	Power Steer. Conv. Set	*	*	1	6.30
J 5659	Wiper Nut Wrench	52	*	¼	4.25
J 5660	Wire Gauge	*	*	¼	.80
J 5661-01	Rivet Extractor	*	*	¼	2.90
J 5664-01	Pitman Arm Puller	40	*	2¼	19.25
J 5669	Oil Seal Installer	*	7, 29	½	12.40
J 5670	Wheel Bearing Wrench	*	29	6	25.00
J 5672	Oil Seal Installer	*	*	4	14.75
J 5673	Trans. Nut Wrench	*	*	4	23.25
J 5680	Crowfoot Adapt. (1⅜″)	42	*	¼	3.20
J 5681	Prop. Shaft Brg. Rem.	*	*	1½	5.90
J 5682	Cl. Lin. Clamp Set	*	60	11	21.50
J 5683	Float Lev. Ga. (1 19/32″)	*	*	¼	.70
J 5684	Ring. Compr. (4⅛″)	7	*	1½	3.50
J 5690	Brg. Cup Remover	33	*	2	5.70
J 5691	Brg. Cup Remover	33	*	½	5.35
J 5698	Brg. Cup Driver	*	7, 29	4¼	9.50
J 5710	Valve Train Gauge	4	46	¼	6.90
J 5712	Valve Spring Compr.	2	*	11¼	24.65
J 5715	Rock. Arm Reamer (.004″ O.S.)	5	46	¼	3.85
J 5725-02	Manifold & Gauge	54	*	2¾	12.65
J 5725-1	600# Gauge	*	*	½	2.85
J 5725-3	Refrigerant Comp. Ga.	*	*	2	4.30
J 5725-4	Manifold	*	*	5	5.50
J 5727-01	Distributor Wrench	14	55	½	2.85
J 5734	Val Guide Inst. (Exh.)	5	*	1	5.45
J 5742-01	Wind. Align. Blocks	53	*	½	1.75
J 5746	Bearing Installer	37	7	2½	14.45
J 5747	Seal Installer	37	*	½	2.95
J 5749	Comp. Flange Installer	31	8	¾	2.55
J 5751	Valve Seal Installer	5	46	¼	5.10
J 5754	Steering Gear Remover	40	*	1¾	21.75
J 5755	Bearing Cup Installer	40	*	5¾	9.30
J 5757	Weatherstrip Tool	53	20	¼	3.50
J 5777	Counter Assy. Tool	16	*	1	3.20
J 5778	Trans. Remover	16, 19	33	3	8.30
J 5787	Pitman Shaft Guide	40	*	¼	8.00
J 5790	Lifter Tester	5	46	28	65.95
J 5792	Monox. Hoses (5′3″)	*	*	12	29.90
J 5793	Monox. Set (4″)	*	*	42	93.25

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 5794	Spanner Wrench	48	*	½	$ 3.25
J 5798	Steer. Reamer	*	*	½	7.05
J 5801	Stud Installer	5	*	½	4.55
J 5802-01	Stud Remover	5	*	¼	4.15
J 5804	Trans. Gauge	22	*	1¼	4.75
J 5805	Shim Depth Gauge	48	*	¼	9.45
J 5806	Stator Installer	22	*	½	6.30
J 5808	Support Rod	22	*	¼	3.75
J 5810	Tor. Wr. Adpt. (¾-⅜")	57	*	¼	3.10
J 5813	Seal Installer	40	*	1	3.75
J 5814-01	Speedo Gear Remover	16, 19	*	10½	40.45
J 5816-01	Bushing Replacer	22	*	2	8.45
J 5818	Oil Seal Replacer	37	*	4¾	32.35
J 5819	Clutch Link. Gauge	16	*	¾	8.80
J 5821	Lift. Clean. Tank	5	46	12	23.40
J 5822	Steering Brg. Remover	40	*	1	18.00
J 5824	Clut. Align. Tool	17	*	6¼	20.95
J 5825	Crank. Puller	7	50	2¾	11.25
J 5830-02	Reamer Set	5	47	1¼	23.50
J 5830-1	Reamer (.003" O.S.)	5	47	¼	4.70
J 5830-2	Reamer (.015" O.S.)	5	47	¼	4.70
J 5830-3	Reamer (.030" O.S.)	5	47	¼	4.70
J 5830-4	Reamer (.010" O.S.)	5	47	¼	4.70
J 5830-5	Reamer (.020" O.S.)	5	47	¼	4.70
J 5839	Blow. Tool Set	*	75	8¼	41.20
J 5840-01	Cam Fixture	*	69	5¼	24.50
J 5853	Torque Wr. (0-100#)	57	8	¾	20.00
J 5855	Brg. Rem. & Inst.	14	*	1	6.80
J 5856-02	Engine Stand	59	*	94	92.00
J 5859	Oil Seal Remover	17	*	2	17.75
J 5862	Monoxivent	59	*	32	59.65
J 5864	Dial Ind. Rod	28, 29	*	½	2.10
J 5865	Tube Remover	29	*	¼	5.75
J 5867	Link. Adj. Rod	29	*	½	3.75
J 5868	Oil Seal Replacer	*	*	3½	12.50
J 5870	Link. Adj. Tool	29	*	½	3.95
J 5875	Spring Compressor	28, 29	*	2¼	9.60
J 5878	Clutch Assy. Fixture	29	*	3¾	4.75
J 5879-01	Throt. Control Pin	29	*	¼	.50
J 5880	Adjusting Tool	*	*	2	29.95
J 5880-01	Adjusting Wrench	28, 29	*	2	32.85
J 5883-01	Adjusting Wrench	29	*	4½	39.10
J 5884	Gauge Assembly	29	*	¼	3.90
J 5886-01	Spring Compressor	28, 29	*	2½	16.25
J 5887	Bending Tool	29	*	½	3.25
J 5888	Bush. Inst. Set	45	*	7¾	24.00
J 5892	Cyl. Head Holder	5	*	8	15.25
J 5892-1	Valve Spg. Compressor	5	*	1	3.95
J 5893-01	Nut Wrench	52	*	¾	6.25
J 5895	Nut Wrench	*	87	¼	7.55
J 5897	Nut Wrench	*	20	½	6.25
J 5899-01	Clearance Gauge	22	*	8	28.25
J 5900	P.S. Gauge Adapter	42	*	½	2.15
J 5901	Puller Set	*	90, 93	4¾	33.80
J 5901-1	Hammer & Shaft	*	*	3	8.25
J 5901-2	Bearing Adapter	*	26, 42, 90	¾	18.75
J 5901-3	Tach. Adapter	*	60	½	2.70
J 5902-01	Cylinder Hone	2	93	11¼	84.50
J 5904	Tach. Adapter	*	60	1	18.00
J 5905	Bearing Spacer	33	*	½	3.85
J 5906	Posit. Gauge	19	*	1½	8.35
J 5907	Pressure Gauge	57	37	2	12.65
J 5907-3	Pressure Hose (9')	*	37	1	3.60

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 5908	Idle Gauge	*	*	¼	$ 1.10
J 5913	Bushing Installer	23	*	3	8.10
J 5915	Float Level Gauge	*	*	¼	.55
J 5916	Float Level Gauge	*	*	¼	.55
J 5917	Float Level Gauge	*	*	¼	.55
J 5920	Choke Gauge	*	*	¼	.55
J 5921	Choke Gauge	*	*	¼	.50
J 5922	Oil Seal Installer	*	*	1½	5.50
J 5930	Oil Seal Installer	23	*	½	9.40
J 5943	Spring Compressor	29	*	3	6.65
J 5946	Oil Seal Remover	23	*	2¾	18.05
J 5948	Dust Seal Installer	23	*	2½	7.10
J 5955	Nut Wrench	*	29	5½	25.00
J 5956	Fuel System Primer	*	81	1	10.90
J 5959	Dial Ind. Set	*	8, 93	3	37.95
J 5959-1	Dial Indicator	*	8, 93	¼	18.00
J 5959-2	Plate & Post	*	8, 93	½	3.90
J 5959-3	Ext. Rod (¼"x10½")	*	8, 93	¼	2.10
J 5959-4	"C" Clamp w/Rod (⅜"x8")	5	8, 93	½	4.40
J 5959-5	Ext. Rod (¼"x4½")	*	8, 93	¼	2.10
J 5959-6	Swivel Sleeve	*	8, 93	¼	1.80
J 5959-7	Lug Attachment	*	8, 93	¼	7.80
J 5961	Valve Spring Compr.	5	*	½	5.55
J 5975-A	Pressure Test Set	29	*	9	42.50
J 5976	Governor Wrench	29	*	1	1.95
J 5977	Brake Pist. Remover	29	*	6½	25.40
J 5978-A	Lifter Check. Tool	5	*	1	8.25
J 5979	Auto. Trans. Driver	57	*	20	30.20
J 5979-1	Handle and Driver	57	*	4½	7.35
J 5979-2	Driver	57	*	4½	5.50
J 5979-3	Driver	57	*	2¼	3.50
J 5979-4	Driver	57	*	2¼	3.50
J 5979-5	Driver	57	*	3½	5.05
J 5979-6	Driver	57	*	3	4.55
J 5979-7	Cart. & App. Chart	*	*	½	.75
J 5981	Door Hand. Tool	51	*	¼	2.50
J 5983	Oil Seal Installer	*	*	2	5.40
J 5984	Weatherstrip Tool	53	20	½	8.50
J 5986	Nut Wrench	52	*	¼	1.95
J 5990-01	Impeller Installer	*	74	1½	7.10
J 5992	Vib. Damp. Remover	*	*	6	12.25
J 6036	Stud Reamer (.382")	5	47	½	3.50
J 6039	Float Level Gauge	*	*	¼	.50
J 6040-A	Carter Carb. Kit (4 BB)	*	*	1	7.65
J 6042	Valve Reamer Set	5	*	1	17.00
J 6042-1	Reamer (.003 O S)	5	*	¼	4.90
J 6042-4	Reamer (.030 O S)	5	*	¼	4.90
J 6042-5	Reamer (.015 O S)	5	*	¼	4.90
J 6047-03	Piston Pin Assy. Tool	7	*	15½	46.90
J 6049-01	Valve Tool Set	*	28	5	32.30
J 6049-2	Nut Wrench	*	28	½	5.45
J 6049-3	Shaft Rem. & Installer	*	28	½	3.45
J 6049-4	Holding Fixture	*	28	2	11.60
J 6049-8	Lock Nut Wrench	*	28	½	5.30
J 6049-7	Lock Nut Wrench	*	28	½	6.50
J 6056	Wire Gauge	*	*	¼	1.70
J 6057	Wire Gauge	*	*	¼	1.70
J 6058-A	Bending Tool	10	*	¼	1.35
J 6061	Wire Gauge	*	*	¼	1.70
J 6063	Posit. Gauge	*	*	¼	4.45
J 6066	Valve Spr. Compr.	5	*	1½	6.95
J 6069	Oil Seal Installer	28	*	1¼	5.50

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 6071	Bolt Guide Pins	*	*	¼	$ .80
J 6076	Humidicator	54	*	½	11.50
J 6078	Pist. Seal Installer	*	8	5½	7.05
J 6079	Pin. Brg. Remover	*	8	½	4.35
J 6080	Bearing Installer	*	8	5	7.45
J 6081	Comp. Flange Inst.	*	8	6¼	9.50
J 6083	Snap Ring Pliers	57	76, 93	½	2.65
J 6084	Leak Detector	54	*	3½	9.95
J 6086	Comp. Installer	*	*	1	6.90
J 6090	Gasket Installer	*	52	½	19.20
J 6091	Energy Cell Rem.	*	60	1	10.10
J 6092	Alignment Blocks	*	20	¼	3.45
J 6094-01	Carb. Tool Kit	*	*	¼	4.35
J 6098	Cam Brg. Remover	2	44	4½	38.15
J 6099	Pin. Set. Adapt. Kit	*	*	2	21.75
J 6104-01	Brg. Nut Wrench	*	*	3	19.75
J 6105	Valve Key Set	54	*	½	3.50
J 6115-02	Trans. Hold. Fixture	23, 28	37	23¼	48.15
J 6116-01	Clutch Hold. Fixture	23	*	5	8.40
J 6118	Oil Seal Installer	23	*	2	12.55
J 6119	Bushing Protector	23	*	2½	2.75
J 6120-01	Drive Flange Retainer	23	*	¼	.50
J 6121	Cover Remover	23	*	6	25.25
J 6122-01	Exh. Valve Spr. Ret.	23	*	¼	1.15
J 6123-01	Speedo Gear Remover	23	*	3	18.80
J 6124	Cover Rem. & Repl.	23	*	1	7.95
J 6125	Hammer Assy.	23	*	4	9.90
J 6125-1	Slide Hammer	*	*	2	3.70
J 6126	Dial Ind. Fixture	23	*	½	2.10
J 6127	Checking Gauge	23	*	2½	10.05
J 6129	Spring Compressor	23	*	1¼	5.25
J 6133-A	Speedo Gear Installer	23	37	2	6.50
J 6134	Speedo Gear Gauge	23	*	¼	1.25
J 6135	Clutch Retainer	23	*	¾	5.50
J 6136	Oil Seal Remover	23	*	1¾	14.95
J 6151	Float Level Gauge	*	*	¼	1.10
J 6154	Ring Gear Set	*	*	¼	2.35
J 6156	Idle Adj. Spring	*	*	¼	.35
J 6157	Cam Contact Bend. Tl.	*	*	¼	.70
J 6158	Choke Lever Weight	*	*	¼	.80
J 6161	Pressure Hose (72")	*	37	1½	3.85
J 6166	Brake Adj. Wrench	48	*	½	1.55
J 6171	Pin Brg. Remover	*	*	1½	4.35
J 6173	Cam Brg. Remover	2	44	6¾	34.95
J 6177	Carrier Fixture	33	*	27	39.30
J 6178	Wire Gauge (.115"-.033")	*	*	¼	1.70
J 6179	Float Level Gauge	*	*	¼	.95
J 6185	Axle Hous. Spread.	37	*	24	49.85
J 6188	Throt. Lev. Gauge	*	37	1¼	11.75
J 6192	Pin. Sock. Wrench	*	*	2	11.55
J 6194-01	Bearing Support	33	*	8½	38.15
J 6197	Brg. Cup Installer	33	*	1½	5.35
J 6198	Brg. Cup Remover	33	*	1	4.25
J 6199-01	Bearing Puller	*	*	5	23.95
J 6200	Oil Seal Installer	*	*	4¼	6.80
J 6202	Cam Rem. Adapt.	*	60	4¼	12.85
J 6203	Pin. Brg. Remover	*	*	1¼	4.35
J 6204	Valve Spring Compr.	5	*	1	9.40
J 6207	Hydraulic Pump	59	*	16	35.70
J 6212	Belt Tension Tool	*	*	½	3.25
J 6213	Brg. Seal Guide	*	*	1	3.25
J 6215	Pinion Press	31	*	26¼	34.75

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 6216	Ring Compr. (3⅛")	42	26	¾	$ 6.15
J 6217	Seal Installer	42	26	¼	2.05
J 6219	Oil Seal Installer	42	*	1¾	4.10
J 6220	Brg. Rem. & Repl.	42	*	5¼	6.35
J 6221	Brg. Rem. & Repl.	42	26	1¼	3.00
J 6222	Seal Protector	42	27	¼	4.45
J 6223	Screw Adapter	42	27	¼	2.75
J 6224	Valve Link. Adapt.	42	27	¼	2.50
J 6245	Pin. Nut Tool (2" Hex).	*	*	1	3.95
J 6246	Pin. Sock. Handle	33	*	6	13.80
J 6247	Diff. Carr. Sling	*	*	2½	4.50
J 6248	Need. Brg. Installer	*	*	¾	4.50
J 6251	Guide Studs	33	*	¼	1.50
J 6255	Brg. Cup Installer	33	*	2½	8.60
J 6257	Brg. Ring Installer	37	*	1½	6.85
J 6258	Adapter (½"-13"x¾"-16")	57	*	½	4.60
J 6263	Brg. Cup Installer	33	*	2	9.20
J 6266-05	Pinion Setting Gauge	33	*	11½	132.30
J 6270-02	Blow. Serv. Tool Set	*	75	21	122.85
J 6271	Fits-All Valve	54	*	¼	1.80
J 6272-01	#4 Multi-Opener	54	*	1	13.90
J 6273	Reamer (.020" O.S.)	*	1	4¾	13.20
J 6277	Reamer (.010" O.S.)	*	1	4¾	15.20
J 6278	Brg. Rem. & Inst.	42	*	3	7.05
J 6279	Bearing Remover	*	*	¼	2.50
J 6280	Brg. Installer	*	*	¾	2.50
J 6281	Over-Center Adapt.	42	27	½	4.75
J 6282	End-Play Gauge	*	23	1½	13.25
J 6284	Bushing Reamer	*	2	3	11.25
J 6285	Staking Tool	42	27	1	3.65
J 6289	Comp. Flange Hold.	31	*	2¾	7.95
J 6292	Bearing Remover	40	*	1	10.65
J 6293-A	Valve Spool Hold. Tool	42	*	¼	4.55
J 6295-01	Comp. Flange Remover	31	*	2½	10.45
J 6297	Impellor Remover	*	74	1¾	4.65
J 6298	"I" Beam Reamer (.010" O.S.)	*	2	1½	9.90
J 6299	"I" Beam Reamer (.010" O.S.)	*	2	2¾	12.45
J 6300	"I" Beam Reamer (.020" O.S.)	*	2	3	12.45
J 6301	Stud Installer	5	47	¼	9.50
J 6303	Bush. Rem. & Repl.	*	2	2½	8.55
J 6304	Bush. Rem. & Repl.	*	2	3¼	14.50
J 6305-01	Bolt Guide Set	7	50	¼	6.10
J 6306	Energy Cell Remover	*	60	1	5.10
J 6307	Clutch Align. Arbor	*	42	3	18.35
J 6308	Timing Gauge	*	60	¼	5.45
J 6309	Timing Gauge	*	60	¼	5.45
J 6310	Hous. Align. Fixture	29	*	6	15.10
J 6311	Monox. (4" Undgrd.)	*	*	40	109.50
J 6311-1	Guide & Bail. Assy.	*	*	22	72.50
J 6311-2	Tunnel Assy.	*	*	18	37.00
J 6313	Oil Seal Installer	29	*	3¼	6.55
J 6315	Trans. Bench Stand	29	*	6¼	13.85
J 6316	Trans. Adapter	30	*	10	29.95
J 6318	Spring Compressor	46	*	3	15.80
J 6320	Seal Protector	54	*	¼	3.00
J 6322-01	Clutch Plate Remover	54	*	1	7.95
J 6324	Valve Train Gauge	5	47	¼	5.20
J 6326	Float Level Gauge	*	*	¼	.50
J 6328	Bushing Reamer	*	*	2¾	9.85

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 6329-01	Clutch Align. Arbor	*	42	2¼	$ 8.55
J 6330	Welch Plug Reamer	*	*	¾	7.05
J 6331	Piston Pin Driver	*	60	4	8.50
J 6332	Bushing Serv. Tool Set	*	60	5	39.70
J 6334-01	Cam Bush. Remover	*	60	12¼	70.35
J 6335	Trim Pad Remover	51	20	¼	1.95
J 6337	Float Gauge	*	*	¼	.60
J 6338	Choke Gauge	*	*	¼	.50
J 6341	Valve Guide Reamer	5	47	½	8.00
J 6342-01	Trot. Check Clamp	23	*	¼	.95
J 6343	Trot. Lev. Gauge	23	*	½	5.10
J 6344	Trot. Lev. Gauge	23	*	½	4.80
J 6346-01	Hydra. Tool Board	*	*	50	40.00
J 6347	Eng. Stand Adapter	*	60, 100	82½	62.45
J 6349	Oil Seal Installer	2	*	5½	8.00
J 6354	End-Play Adjuster	40	*	¼	1.35
J 6355	Fuel Press. Gauge	*	88	¾	8.50
J 6356	Cam Brg. Remover	2	44	17½	67.60
J 6357	Fuel Press. Gauge	*	82	¾	8.00
J 6358	Throt. Lev. Gauge	*	*	¾	4.50
J 6360	Piston Pin Remover	7	*	4½	12.50
J 6361-01	Flywheel Lift. Hook	*	61	6½	25.75
J 6367	Brg. Cup Remover	33	8	2½	19.95
J 6368	Brg. Cup Installer	33	8	1¼	6.85
J 6369	Brg. Rem. & Repl.	34	8	3½	19.20
J 6372	Hydramatic Manual	*	*	1	1.00
J 6373-01	Trot. Lev. Tool	23	37	¾	8.75
J 6377	Press Plate Replacer	34	*	1	9.10
J 6378	Axle Brg. Remover	*	8	9	15.70
J 6379	Retain. Ring Installer	*	8	¾	3.15
J 6380	Oil Seal Installer	34	8	3¼	5.00
J 6381-04	Pinion Set. Gauge	34	*	6	60.65
J 6382-01	Idler Gear Remover	*	33	2½	18.30
J 6384	Spring Compressor	5	47	½	16.70
J 6385	Energy Cell Remover	*	61	1¼	10.60
J 6387	Dies. Parts Rack	*	61, 99	500	375.00
J 6388	Eng. Stand Adapt. Pl.	*	61, 100	30	38.50
J 6390-01	Valve Seat Grind.	*	69, 101	1¼	33.55
J 6392	Stud Remover	5	47	1	12.40
J 6399	Brg. Rem. & Inst.	17	*	5	5.50
J 6402	Seal Protector	54	*	¼	3.90
J 6403-01	Seal & Brg. Inst.	17, 30	*	3	15.20
J 6405	Spr. Hold. & Rem.	*	*	5	22.50
J 6407	Press Plate Holder	57	93	6¾	23.30
J 6408	T-3 Safety Aimer	*	*	10	18.95
J 6413	Tim. Ga. (.215″-.200″)	*	61	¼	3.85
J 6416	Oil Seal Installer	*	33	4¼	12.75
J 6418	Press Plate Holdter	57	33	6	8.35
J 6419-01	Brg. Driver Set	*	33	15¾	49.00
J 6421	Bearing Remover	*	33	5¼	16.95
J 6424	Alignment Gauge	*	2	1	6.25
J 6429-01	Tim. Ga. (.512″-.567″)	*	61	¼	4.50
J 6430	Lifting Eye	*	39	¼	4.70
J 6432-01	Crimping Tool	*	39	¼	2.80
J 6435	Truarc Pliers (#26 Ext.)	57	33, 94	½	3.50
J 6436	Bosch Conn. Set	*	*	¾	17.95
J 6438	Spring Compressor	*	39	2¾	9.60
J 6440	Seal & Brg. Inst.	30	*	3¼	10.35
J 6441-01	Pin. Gauge & Discs	*	9	72	387.75
J 6444	Distrib. Pt. Rem.	*	56	¼	1.65
J 6445-28	Nozzle Tester	*	*	17	98.75
J 6445-34	Carrying Case	*	82	8	12.95
J 6445-38	Nozzle Fixture	*	*	1½	9.20
J 6445-50	Spray Collector	*	82	½	$ 1.40
J 6446-01	Ball Joint Remover	45	*	1¾	9.15
J 6448-01	Pow. St. Gear Hold.	43	*	6½	13.75
J 6455	Seal & Bush. Rem.	30	*	2	12.15
J 6456	Depth Gauge	17	42	¼	.85
J 6458	Torque Wrench Set	*	*	½	21.45
J 6459	Torque Wrench	*	9, 94	2	20.00
J 6463	Bearing Remover	*	28	½	1.95
J 6464	Brg. Inst. Kit	*	28	1¾	6.65
J 6467-02	Clutch Ckg. Fixture	*	39	41¾	62.60
J 6471-02	Slide Hammer. Adapt	*	94	16	66.25
J 6481	Nut Wrench	52	*	½	6.55
J 6482-01	Pinion Conver. Kit	*	*	4	20.50
J 6486	Nut Wrench	52	*	¾	6.25
J 6492	Choke Gauge	*	*	¼	1.40
J 6498	Torque Wrench Ext.	23	*	¼	2.85
J 6499	Press. Test Set	30	*	9	42.50
J 6501	Trans. Press. Gauge	*	*	1¼	9.75
J 6502	Bell Hous. Align.	*	33, 44	4¼	18.90
J 6504	Rem. Inst. Screw	23, 31	*	¼	3.75
J 6505	Comp. Flange Inst.	23, 31	*	1¼	14.90
J 6506	Hood Spr. Rem. Tool	51	*	2	6.25
J 6507	Oil Seal Installer	2	44	¾	7.95
J 6508	Brg. Locating Gauge	9	52	1	4.15
J 6509	Spr. Rem. & Inst.	46	*	4¼	9.65
J 6513	Seal Installer	9	52	1	3.40
J 6523	Seal Installer	*	39	3	11.25
J 6525-01	Axle Brg. Rem.	37	*	9½	29.50
J 6526-02	Eng. Stand Adapt.	*	61, 100	42	38.50
J 6527	Eng. Stand Adapt	*	61, 100	44	38.50
J 6528	Oil Seal Installer	2	44	3½	6.50
J 6529-02	Pinion Disc Set	*	9	10	44.75
J 6531	Pin. Brg. Rem.	34	*	5½	33.30
J 6533	Pin. Brg. Rem.	34	*	1	5.75
J 6534	Spanner Wrench	*	39	6¾	46.90
J 6535	Spacer Block	5	*	1¼	8.90
J 6539	Oil Seal Installer	43	*	1¾	6.60
J 6541	Hub Seal Installer	47	*	4	7.15
J 6544	Comp. Flange Holder	31	*	7½	7.75
J 6547	Pin. Brg. Installer	34	*	1¾	5.15
J 6552-02	Brg. Cup Remover	34	*	7¼	65.00
J 6553-01	Brg. Supp. Remover	34	*	4¼	33.75
J 6555	Pin. Brg. Remover	34	*	6	22.40
J 6556	Bending Tool	*	*	½	1.10
J 6557	Selector Gauge	19	*	3¼	14.40
J 6560	Pump. Assy. Sleeve	19	*	4	13.50
J 6561	Bushing Installer	19	*	6½	16.00
J 6567	Valve Seat Remover	*	69	1¾	39.95
J 6568	Valve Seat Installer	*	69	1¾	8.50
J 6569	Valve Guide Remover	*	69	½	3.50
J 6570	Valve Guide Installer	*	69	1½	6.30
J 6571	Carrier Hold. Fixture	34	*	17	33.75
J 6573	T.V. Lever Gauge	23	*	½	1.65
J 6580	Piston Assy. Tool	19	*	9	17.65
J 6581	Bush. Rem. & Inst.	19	*	4	9.25
J 6582	Bushing Installer	20	*	2¾	6.10
J 6583	Bushing Installer	20	*	2¾	5.70
J 6584	Oil Seal Installer	20	*	6	8.35
J 6585-01	Trans. Assy. Rem.	20	*	3¾	10.90
J 6586	Oil Deliv. Sleeve Rem.	24	*	¼	3.70
J 6592-02	Wiper Wrench	52	*	½	7.15
J 6600-01	Comp. Gauge Adapt.	*	61	1¼	23.90
J 6601-02	Compr. Gauge Adapt.	*	61	2½	29.50

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 6608	Sunshade Remover	51	*	¾	$ 3.25
J 6609	Door Knob Wrench	51	*	¼	1.40
J 6618	Mast. Cyl. Wrench	*	*	1¼	12.75
J 6619	Need. Brg. Remover	*	*	3	5.75
J 6621	Valve Guide Reamer (.005″ O.S.)	5	47	¼	4.60
J 6624	Antenna Wrench	51	*	¾	6.50
J 6626	Alignment Blocks	53	*	¼	1.90
J 6627	Ball Joint Remover	44	*	1½	18.75
J 6628	Float Level Gauge	*	*	¼	1.85
J 6629	Float Level Gauge	*	*	¼	.75
J 6632	Pitman Arm Puller	44	*	5	19.25
J 6638	Trans. Hold. Fixture	20	*	12	21.35
J 6640	Leak Detector	59	94	3	24.35
J 6643	Bushing Installer	20	*	2	6.80
J 6645	Inj. Tip Seat Ream.	*	82	½	14.50
J 6646	Float Level Gauge	*	*	¼	.75
J 6647	Ring. Compr. (3⅞″)	7	*	2	3.00
J 6648	Idle Gear Remover	*	33	2	6.90
J 6649	Brg. Nut Wrench	*	2, 29	1¾	10.85
J 6650	Fuel Inj. Gauge Set	*	82	½	8.95
J 6650-11	Cam Ang. Ga. (50°)	*	82	¼	1.25
J 6650-12	Cam Ang. Ga. (85°)	*	82	¼	1.25
J 6650-13	Cam Ang. Ga. (120°)	*	82	¼	1.25
J 6650-14	Cam Ang. Ga. (42°)	*	82	¼	1.25
J 6652	Thrust Yoke	17	*	1¼	12.90
J 6654	Bearing Remover	*	*	3¼	26.25
J 6655	Torque Wrench Ext.	28	*	¼	3.95
J 6657	Need. Brg. Rem.	40	*	4	6.50
J 6659	Starter Holder	14	*	2¼	6.50
J 6660	Elec. Tachometer	14, 59	94	5	39.75
J 6661	Ring Installer	38	*	2¼	11.35
J 6665	Motor Oil Dye	59	94	1¼	9.50
J 6670	Broach Set	*	76	4½	42.35
J 6671	Brg. Inst. Set	*	76	9	18.25
J 6672	Ring Remover	*	76	3½	7.35
J 6673	Shaft Pilot	*	76	¼	7.95
J 6674	Seal Ream. (Turbine)	*	76	2¼	15.35
J 6675	Seal Ream. (Blower)	*	76	2	14.20
J 6676	Casing Puller	*	*	6¼	17.75
J 6678	End-Play Spacer	*	76	½	2.75
J 6683	Spring Compressor	*	69	1	13.15
J 6684	Holding Bracket	10	*	¼	2.50
J 6685	Brg. Adapt. Plug	10	*	¼	2.95
J 6686	Mainshaft Adapt. Plug	10	*	¼	3.10
J 6687	Anvil Plug	10	*	½	5.80
J 6688	Bearing Installer	10	*	1¾	14.30
J 6689	Holding Fixture	10	*	5¾	10.95
J 6690	Puller Screw	10	*	¼	3.70
J 6692	Cyl. Compr. Gauge	*	61	1½	21.00
J 6693	Spline Hub Puller	38	*	¼	2.65
J 6695	T.V. Press. Ga. (100#)	24	*	½	3.50
J 6699	Wire Gauge	*	*	¼	.80
J 6700	Screw Driver	*	9	½	.35
J 6701	Hydraul. Tire Tool	*	29, 94	84	177.25
J 6704	10-Ton Jack	*	94	67	60.25
J 6706-01	King-Pin Wr. (2½″x3″)	*	2	1½	15.95
J 6707	20-Ton Jack	*	94	76	204.25
J 6708	Thread Prot. (5.45x12)	*	9	5	18.85
J 6709-02	Pry Bar Tool Set	*	29, 94	10	14.35
J 6709-1	Pry Bar	*	29, 94	6	4.95
J 6709-3	Ratchet Tool	*	29, 94	4	4.70
J 6710	Seal Remover	*	94	½	8.30
J 6711	Jack Handle	*	94	15	$ 13.85
J 6712	Aligning Bar	*	94	3½	4.50
J 6713	Pry Bar	*	94	2¼	4.95
J 6714-02	Charging Assy.	*	21, 79	3¾	60.00
J 6714-8	Valve & Fit. Kit	*	21, 79	1	12.50
J 6715	Hydraul. Tire Tool	*	29, 94	45	192.25
J 6717	Quick-Coup. Adapt.	*	95	¾	7.40
J 6722	Rotor Nut Wrench	*	75, 76	¼	7.90
J 6723	Pulley Nut Wrench	*	75, 76	1½	16.35
J 6729	Brg. Rem. Adapt.	2, 10	*	¼	7.00
J 6730	Pinion Adapter Set	*	*	34½	154.25
J 6731	Pinion Gauge Set	*	*	46¾	275.70
J 6732	Ring Rem. & Inst.	*	9	¾	8.15
J 6734	Aero-Quip Tool Kit	*	95	15	65.50
J 6737	Dual-Chuck Assy.	*	29	3	24.60
J 6741-01	Axle Jack Adapter	*	*	25	61.05
J 6742	Thermom. (0-180°F.)	54	*	¼	9.95
J 6745	T.V. Lever Gauge	*	37	¼	6.90
J 6749	Fuel Valve Wrench	*	82	2	2.50
J 6750	Nozzle Remover Set	*	76	15	33.70
J 6751	Exh. Hous. Remover	*	76	10	24.45
J 6752	Brg. Inst. Set	*	76	13	31.70
J 6753	Brg. Broach Set	*	77	7½	52.75
J 6754	Seal Ream. (Turbine)	*	77	4	26.95
J 6755	Seal Ream. (Blower)	*	77	3	19.75
J 6756	Turbine Pilot	*	77	¾	21.30
J 6757	End-Play Spacer	*	77	½	6.25
J 6758	Brg. Rem. Adapter	*	77	1	16.50
J 6761-02	Compr. Gauge Adapter	*	61	2	25.00
J 6761-1	Nozzle Asembly	*	61	½	6.25
J 6762-02	Cyl. Compr. Gauge	*	61	3	46.00
J 6765	Fuel Inj. Wrench	*	82	½	4.65
J 6766	Power Equipment Set	59	*	6½	15.10
J 6767	Trans. Adapter	*	39	10	17.20
J 6769	Adapt. (⅜-11 Male x ¾-16 Female)	*	*	¾	3.45
J 6770	Hose Strip. Tool Set	*	95	18	92.40
J 6771	Ratchet Wrench (⅞″)	*	*	1	13.00
J 6772	Inj. Cut-Out Tool	*	69	1½	5.90
J 6773	Brg. Cup Installer	47	*	¾	5.35
J 6776	Oil Seal Installer	24	*	¼	4.10
J 6777	Tail Pipe Adapter	*	*	3	5.60
J 6780	Monox. "Y" Conn.	59	*	2	4.35
J 6781	Monox. Flex. Tube (3″ x 11″)	59	*	12	15.85
J 6782	Pinion Set. Gauge	32	*	6	25.60
J 6783	Brg. Inst. Plate	38	*	2¾	9.80
J 6786	Cam Bush. Remover	*	61	12¼	73.05
J 6788-01	Cam & Distrib. Tool	57	*	½	11.50
J 6791	Valve Guide Inst.	*	69	¾	7.15
J 6793	Oil Seal Remover	20	*	3¼	15.00
J 6795-01	Pump Assy. Remover	*	39	1½	9.20
J 6795-1	Pump Assy. Remover	*	39	1	4.50
J 6798	Monox. Hose (3″x9′)	59	*	10	12.95
J 6801	Tail Pipe Adapter	*	*	2½	6.25
J 6831	Tail Pipe Adapters	*	*	6	6.95
J 6833	Cyl. Liner Remover	*	61	13	30.15
J 6833-1	Spring Assembly	*	61	2½	8.30
J 6833-2	Bottom Shoe	*	61	2	8.45
J 6836	Axle Jack Adapt. Kit	38	*	23	36.70
J 6837-01	Eng. Overhaul Stand	*	62, 100	730	550.00
J 6838	Wire Ga. (.076 x .230″)	*	*	¼	1.90

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 6839	Oil Seal Installer	20	*	3	$ 10.30
J 6840-01	Press. Ga. (0-400#)	49	*	¾	5.85
J 6840-1	Pressure Gauge	46	*	½	4.90
J 6842	Valve Seat Inst.	*	47	3½	18.40
J 6843	Snap Ring Pliers (Int.)	*	95	4	22.85
J 6844-01	Lok-Thread Tap Set	*	95	3	96.50
J 6844-1	Tap (⅝"x12")	*	95	¾	16.00
J 6844-2	Tap (⅝"x11")	*	95	¾	18.60
J 6844-3	Tap (¾"x10")	*	95	¾	23.30
J 6844-4	Tap (¾"x16")	*	95	¾	23.30
J 6844-5	Tap (½")	*	95	¾	15.50
J 6846	Bridge Guide Remover	*	*	¼	6.40
J 6848	Antenna Wrench	*	*	¼	2.45
J 6850	Posit. Gauge	20	*	¼	2.55
J 6851	Cam. Bush. Rem. Set	*	62	12½	65.90
J 6852	Cam Bush. Rem. Set	*	62	12½	43.00
J 6855	Support Fixture	9	*	4½	9.65
J 6856	Tube Wrench (1")	54	*	¾	3.85
J 6857	Tube Wrench (1¼")	54	*	¾	5.05
J 6858-01	Adapt. Disc. Set	*	9	52	251.00
J 6865	Nozz. Rem. Adapt.	*	82	¼	1.50
J 6868-01	Inj. Fixture	*	82	16	69.80
J 6874-01	Coil Spring Compr.	46	*	12½	47.45
J 6876	Choke Gauge	*	*	¼	.50
J 6878-01	Hdlt. Aim. Device	56	56, 95	7	49.95
J 6880	Stud Installer	5	*	¼	3.55
J 6881	Valve Adapter	49	*	¼	2.90
J 6882	Inj. Nut Wrench	*	83	2¼	3.50
J 6883-01	Ring Compressor	*	62	7¼	28.25
J 6884-01	Seal Inst. Set	*	74	2½	24.40
J 6887	Leak Test Adapt.	*	*	¼	1.95
J 6888	Valve Core Rem.	49	28	¼	4.25
J 6889	Guide Pin Set	*	39	¼	7.70
J 6892	Flar. Tool Kit (45°)	57	95	12	82.50
J 6893	Hub Brg. Nut Wrench	*	2, 29	1	14.95
J 6896	Valve Guide Ream.	*	69	¾	6.40
J 6897	Oil Seal Protector	*	62	2¾	21.35
J 6901	Piston Pin Remover	7	50	3¾	22.40
J 6902	Pump Seal Remover	*	74	1¼	4.10
J 6904	Oil Pump Serv. Set	*	74	3	43.45
J 6904-1	Bush. & Seal Remover	*	74	¾	17.75
J 6904-2	Oil Seal Protector	*	74	¾	13.40
J 6904-3	Oil Seal Installer	*	74	¾	11.95
J 6904-4	Oil Seal Installer	*	74	¾	6.20
J 6905	Bush. Burn. (1.098")	*	50	1¼	16.50
J 6906	Bush. Burn. (.9085")	*	50	2	16.60
J 6907	Bush. Burn. (.864")	*	50	1¼	13.10
J 6911	Bush. Burn. (.740")	*	47	1	12.05
J 6912	Wheel Puller Set	*	25	11	26.90
J 6914	Burn. Supp. Block	*	47, 50	14	34.00
J 6915	Bushing Driver	*	47	3½	10.75
J 6916	Bushing Driver	*	47	3½	10.75
J 6917	Bushing Driver	*	47	2	10.75
J 6918	Bushing Driver	*	47	2	10.75
J 6919	Pitman Arm Puller	*	25	2½	20.75
J 6920	Pitman Arm Puller	*	25	4	22.55
J 6922	Staking Tool (⅝")	*	*	2½	12.00
J 6923	Wrench Ext. (¾")	*	44	¾	4.25
J 6924	Wrench Ext. (¾")	*	44	¾	6.30
J 6925	Bush. Reamer Set	*	2, 25	3½	39.10
J 6926	Ring Exp. (4½")	*	50	½	10.50
J 6927	Ring Exp. (3 11/16")	*	51	½	6.75
J 6931	Piston Pin Remover	*	51	1	4.35
J 6933	Oil Pump Tool Set	*	52	1¼	$ 14.80
J 6934	Pitman Arm Puller	*	25	4¾	22.55
J 6935	Clean. Brush Set	*	52	½	10.25
J 6936	Riveting Fixture	*	*	121	260.00
J 6938	Staking Tool (¾")	*	*	1¼	14.80
J 6940	Crank. Gear Puller	*	44	12	46.00
J 6942	Centering Gauge	*	48	2¼	7.50
J 6943	Oil Seal Replacer	*	48	1½	6.25
J 6944-01	Bearing Remover	*	44	2	12.65
J 6945	Oil Seal Compressor	*	44	8½	24.50
J 6946	Seal Installer	*	52	1¼	2.75
J 6947	Guide Replacer	*	48	1¼	3.50
J 6948	Cam Bush. Remover	*	48	35	108.90
J 6949	Core Plug Installer	*	44	1¼	5.75
J 6950	Nut Wrench	*	52	1	4.90
J 6951	Valve Guide Gauge Set	*	48	1½	35.00
J 6952	Brake Adjust. Tool	*	24	½	1.45
J 6953	Clutch Pilot Remover	*	42	3½	30.00
J 6954	Holley Carb. Tool Set	*	53	3	21.90
J 6955	Seal Seat Arbor	*	52	3	20.60
J 6956	Spanner Wrench	*	2	2	8.70
J 6957	Valve Gauge Set	*	48	¼	8.65
J 6958	Rear Eng. Support	*	33	9½	13.30
J 6959	Reamer Set	*	44	3½	32.95
J 6961-02	Gear Inst. Set	*	44	9	95.00
J 6962	Zenith Carb. Tool Kit	*	53	3	19.40
J 6964-01	Oil Seal Installer	24	*	6	17.90
J 6965	Oil Seal Remover	24	*	3½	12.25
J 6966	Riveting Set	*	*	6½	18.65
J 6968	Radio Nut Wrench	56	*	¼	7.80
J 6969	Pinion Gauge Set	*	9	81	383.00
J 6970	Adapter Disc Set	*	9	62	261.55
J 6974	Valve Remover	*	70	1¼	35.30
J 6975	Valve Rem. & Inst.	*	*	¼	1.30
J 6976	Valve Installer	*	70	2½	11.30
J 6978-04	Vib. Damp. Rem.	7	45	3	19.95
J 6983	Spring Scale (0-34#)	*	9	½	8.25
J 6985	Wrench Set	*	95	16	180.95
J 6986	Need. Brg. Remover	*	*	2	10.90
J 6988	Oil Seal Inst.	2	*	4¾	11.50
J 6991	Cyl. Bore Plug	2	*	1	6.95
J 6994-03	Piston Pin Remover	7	*	5¼	34.00
J 6997	Pinion Hose Gauge	31	*	4	27.75
J 6998	G-P-M Gauge Adapter	*	*	¼	3.20
J 6999	Nozz. Hold. Fixture	*	83	2	3.95
J 7003	Guide Pin Set	24	*	¼	.75
J 7004	Pump Remover	24	*	1¾	7.00
J 7005	Oil Seal Remover	24	*	2¾	15.35
J 7006	Oil Seal Inst.	24	*	5¾	9.25
J 7007	Spring Assy. Tool	24	*	¼	1.80
J 7009-01	Trans. Hold. Fixture	24	*	13¾	70.00
J 7012	Bearing Assy. Tool	24	*	2	3.80
J 7013	Bearing Driver Set	24	*	5	14.95
J 7013-1	Handle Assy.	*	*	2	5.75
J 7017	Oil Seal Inst.	43	27	2	4.50
J 7022-01	Bush. Rem. & Replacer	45	*	4¾	13.20
J 7023	Seal Installer	40	*	1	3.25
J 7026	Oil Seal Installer	24	*	4¾	19.35
J 7027	Fly. Hous. Support	24	*	¼	1.30
J 7028	Bearing Remover	34	9	2	14.15
J 7030	Brg. Rem. & Inst.	40	*	¾	5.20
J 7031	Valve Remover	*	70	1¼	35.70
J 7032	Valve Installer	*	70	3	10.25

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 7034	Locating Gauge	9	*	¼	$ 3.85
J 7035	Brake Bleeder Tube	48	*	1	2.75
J 7040	Ecc. Grinder Set	*	70, 101	42	296.50
J 7041	Inj. Comparator	*	80, 95	248	974.50
J 7042	Ecc. Grinder Set	*	70, 101	43	44.10
J 7043	Ecc. Adapter Set	*	70, 101	42	37.25
J 7045	Valve Installer	*	70	1	4.95
J 7046	Valve Inst. Set	*	70	1½	7.75
J 7047	Valve Installer	*	70	1½	7.50
J 7049	Valve Reamer Set	5	48	1½	50.90
J 7052	Bush. Rem. & Inst.	45	*	3¼	17.00
J 7052-5	Bushing Installer	45	*	¾	3.20
J 7053	Bush. Rem. & Inst.	38	*	4½	13.35
J 7055	Bushing Installer	38	*	1½	13.95
J 7057	Dial Ind. Extension	57	*	¼	1.50
J 7058-01	Cyl. Lin. Remover	*	62	4¾	30.85
J 7059	Cyl. Lin. Remover	*	62	13	30.05
J 7060	Piston Inserter	*	62	5	28.50
J 7061	Piston Inserter	*	62	6½	37.20
J 7062	Piston Inserter	*	62	10	46.40
J 7063	Control Arm Remover	38	*	½	6.40
J 7065	Press. Test. Assy.	49	*	1¼	12.40
J 7068	Press. Gauge Kit	24	*	11¼	36.00
J 7073	Air Plug Check. Set	24	*	½	3.50
J 7075	Valve Insert Remover	*	48	2½	22.75
J 7076	Float Level Gauge	*	*	¼	.85
J 7077	Rear Brg. Support	24	*	4½	3.45
J 7079-2	Driver Handle Assy.	57	27, 95	1¾	3.85
J 7080	Oil Seal Installer	*	*	1¾	10.05
J 7081	Ring Compressor	49	*	¼	3.40
J 7085	Valve Press. Tool	49	*	¼	2.20
J 7086	Oil Ring Assy. Tool	24	*	¼	2.80
J 7090-01	Fuel Inj. Cal. Tool	10	*	1	41.25
J 7091-01	Valve Guide Remover	*	70	1¼	13.75
J 7092	Piston Pin Driver	*	62	4	5.45
J 7093	Piston Pin Driver	*	62	1½	3.70
J 7094	Valve Seat Installer	*	70	2½	7.60
J 7095	Valve Seat Installer	*	70	2¾	4.75
J 7096	Valve Seat Installer	*	70	3½	9.75
J 7099	Var. Resis. (25 ohm)	59	*	¾	9.45
J 7100	Ring Compressor	24	*	¼	2.65
J 7108	Slide Hammer Assy.	*	62, 95	8½	13.40
J 7111	Oil Seal Installer	43	*	1¼	3.10
J 7112-02	Bearing Remover	34	9	4¼	29.70
J 7116	Pist. Shim Gauge	24	*	¼	1.90
J 7117	Ring Exp. (4⅛″)	7	*	1	6.75
J 7119-01	Prop. Shaft Gauge	31	*	¾	25.00
J 7120	Brg. Cup Installer	47	*	½	4.00
J 7125	Metal Box	*	62	3½	8.25
J 7126	Clutch Adj. Wrench	*	43	¼	3.55
J 7127	Tachometer Set	*	62, 95	4	81.50
J 7132	Oil Seal Installer	43	*	¾	5.35
J 7133	Pitman Shaft Inst.	40	*	2¾	5.25
J 7135	Ring. Exp. (4 11/16″)	7	*	1	6.75
J 7137	Brg. Cup Installer	47	*	1	6.30
J 7141	Adapter	43	*	¼	.70
J 7142	Hydra. Bush. Set	24	37	17	71.05
J 7143	Air-Ride Fittings	49	*	½	5.50
J 7144	Valve Seat Remover	*	48	1¼	29.30
J 7145	Valve Guide Reamer	*	70	½	6.55
J 7146	Press. Check. Gauge	49	*	½	5.90
J 7147	Turbine Cover Rem.	24	*	½	4.45
J 7150	Spring Compressor	20	*	¼	2.50
J 7151-02	Non-Mag. Feel. Ga.	54	*	¼	$ 3.75
J 7152	Carter Carb. Tool Set	12	*	¼	3.35
J 7153	Stator Align. Tool	49	*	¼	3.25
J 7154-01	Grill Installer	51	*	¾	8.05
J 7156-01	Spring Gauge Set	49	*	¼	7.15
J 7157-01	Float Level Gauge	*	*	¼	.80
J 7158	Drive Socket (3/16″)	51	*	¼	2.30
J 7159	Drive Socket (⅛″)	51	*	¼	2.45
J 7161	Air Ride Press. Gauge	50	*	1½	7.70
J 7162	Cy. Lin. Remover	*	63	3¾	19.75
J 7165	Service Tool Set	*	74	4	25.50
J 7167	Control Arm Spread	45	*	2¼	15.75
J 7169	Atmos. Valve Gauge	*	*	¼	1.00
J 7170	Brg. Cup Installer	40	*	½	6.10
J 7171	Pitman Seal Installer	40	*	1¼	4.50
J 7174	Deburring Tool	*	83	¼	3.10
J 7177	Crimping Block	50	*	¼	3.95
J 7179	Bushing Replacer	*	*	1	4.75
J 7180	Bush. Rem. & Inst.	30	*	2¼	13.15
J 7181	Protractor Gauge	31	*	1	9.95
J 7182-2	Bending Tool	10	*	¼	6.10
J 7184-01	Monox. (9′ Hose)	59	*	13	22.10
J 7185-01	Monox. (11′ Hose)	59	*	15	25.00
J 7186	Inj. Timing Gauge	*	63, 83	¼	5.65
J 7187	Spring Compressor	*	79	¼	3.85
J 7190	Oil Seal Installer	*	79	2	4.20
J 7191	Oil Seal Inst. Set	*	79	2	12.50
J 7192	Piston Inst. Tool	*	79	¼	1.45
J 7196	Roch. Carb. Tool Set	12	*	¼	3.40
J 7273	Dyna. Serv. Set	*	*	18	60.75
J 7277-01	Clutch Link Gauge	17	*	¼	3.95
J 7280	Spanner Wrench	2	*	½	5.40
J 7282	Pinion Br. Driver	34	*	2¾	14.00
J 7284	Suspen. Test Bar	45	*	1½	3.45
J 7285-02	Rotor Installer	9	*	¼	6.25
J 7286	Oil Slinger Installer	31	*	½	2.40
J 7287	Main. Meas. Gauge	17	*	½	3.70
J 7288	Brake Lever Gauge	48	*	¼	2.75
J 7289-01	Locating Gauge	2	*	1	3.90
J 7290	Oil Seal Installer	7	*	3¼	5.55
J 7292	Roch. Carb. Tool Set	12	*	¼	1.80
J 7293	Carter Carb. Tool Set	12	*	¼	3.15
J 7294	Float Level Gauge	*	*	¼	.75
J 7296	Oil Seal Remover	17	*	2¼	16.35
J 7297	Bushing Installer	*	39	1½	6.90
J 7316	Belt Tension Tool	14, 58	*	1¼	19.25
J 7317	Brg. Rem. & Instl.	*	63	12¼	72.45
J 7320	Roch. Carb. Tool Set	12	*	¼	2.60
J 7323	Roch. Carb. Tool Set	12	*	¼	3.15
J 7324	Carter Carb. Tool Set	12	*	¼	3.15
J 7325	Roch. Carb. Tool Set	12	*	¼	3.15
J 7326	Roch. Carb. Tool Set	12	*	¼	2.05
J 7327	Roch. Carb. Tool Set	12	*	¼	3.65
J 7328	Carter Carb. Tool Set	12	*	¼	3.35
J 7329	Eng. Repair Stand	*	63, 100	390	445.00
J 7330	Roch. Carb. Tool Set	12	*	¼	3.80
J 7331	Float Level Gauge	*	*	¼	.80
J 7333-06	Diagnosis Test Kit	*	63	35½	427.00
J 7334-03	Compr. Gauge Pack	*	63	10¼	83.65
J 7340	Prop. Shaft Tool	*	*	¾	7.15
J 7341	Wh. Brg. Nut Wrench	*	9, 29	4½	14.00
J 7354	Oil Pump Gauge	*	*	¾	7.85
J 7357	Carb. Gauge Set	12	*	¼	2.30

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 7359	Strom. Carb. Tool Set..	12	*	¼	$ 3.20
J 7360	Pin. Brg. Remover	*	*	1½	4.00
J 7361	Bearing Remover	*	*	¾	4.00
J 7362	Ring Compr. 35 H. P. ..	*	*	½	2.90
J 7363	Valve Gr. Tool 35 H.P. .	*	*	1¼	10.25
J 7365	Bearing Replacer	*	*	1½	4.15
J 7366	Bearing Remover	*	*	1	6.00
J 7367	Bearing Replacer	*	*	1¼	3.50
J 7368	Flywheel Remover	*	*	1¼	5.70
J 7369	Bearing Remover	*	*	1	2.70
J 7370	Spanner Wrench	*	*	½	4.00
J 7372	Bearing Replacer	*	*	¾	3.20
J 7373	Bearing Remover	*	*	½	3.95
J 7374	Bearing Replacer	*	*	¾	2.25
J 7375	Ring Compressor	*	*	½	2.50
J 7376	Roch. Carb. Tool Set ..	12	*	¼	3.65
J 7377	Roch. Carb. Tool Set ..	12	*	¼	3.50
J 7378	Roch. Carb. Tool Set ..	12	*	¼	3.15
J 7380	Ring Compressor	*	*	½	2.65
J 7381	Brg. Rem. & Repl.	*	*	1½	2.50
J 7388	Valve Installer	*	*	2¼	3.75
J 7389	Spring Compressor ...	47	*	5	12.45
J 7390	Monoxivent	59	*	40	49.10
J 7391	Roch. Carb. Gauge	12	*	¼	2.05
J 7392	Turbine Cover Rem. ..	24	*	3	22.50
J 7394	Wheel Paint. Temp. ...	*	*	1	7.00
J 7395	Cam. Bush. Remover ..	*	63	12¼	216.80
J 7399	Gear Puller	*	75	3	18.20
J 7400	Roch. Carb. Tool Set ..	12	*	¼	3.40
J 7401	Carter Carb. Tool Set .	12	*	¼	3.20
J 7402	Carter Carb. Tool Set .	12	*	¼	1.55
J 7403	Strom. Carb. Tool Set .	12	*	¼	2.75
J 7405	Carter Carb. Tool Set .	12	*	¼	2.10
J 7406	Carter Carb. Tool Set .	12	*	¼	1.55
J 7407	Strom. Carb. Tool Set .	12	*	¼	3.20
J 7408	Roch. Carb. Tool Set ..	12	*	¼	4.05
J 7409	Roch. Carb. Tool Set ..	12	*	¼	3.15
J 7410	Roch. Carb. Tool Set ..	12	*	¼	2.60
J 7411-02	Lock Nut Wrench.....	*	*	¼	3.35
J 7412	Cyl. Bal. Tester	59	*	4	19.75
J 7414	Shift Link. Gauge	*	*	¼	.75
J 7415	Roch. Carb. Tool Set ..	12	*	¼	2.95
J 7418	Brg. Cap Installer	*	45	1½	16.40
J 7419	Bolt Guide Set	*	51	¼	7.00
J 7423	Adapter Plate	*	63, 100	59	40.25
J 7426	Pinion Oil Seal Inst. ..	34	*	2¼	4.25
J 7431	Oil Seal Remover	50	*	1	8.75
J 7434	Press. Gauge Adapt. ..	50	*	¼	5.15
J 7436-02	Diagnosis Test Kit ...	*	63	25½	233.20
J 7441	Spring Compressor ...	*	39	4½	29.70
J 7443-03	Brg. & Seal Rem.	*	29	2	32.80
J 7445-01	Carb. Tool Kit	*	*	2½	34.20
J 7447	Carter Carb. Gauge ...	12	*	¼	1.60
J 7450	Carter Carb. Gauge ...	12	*	¼	2.75
J 7452	Fly. Hous. Fixture	*	63	1½	13.50
J 7453	Guide Rem. Adapter ..	*	70	¼	4.00
J 7454	Crank. Seal Tool	*	63	¾	9.60
J 7455	Spring Compressor ...	*	71	2¼	18.55
J 7459	Carb. Chain Gauge	*	*	¼	2.90
J 7460	Spring Remover	48	*	½	4.05
J 7461	Brg. Rem. Plate	34	*	½	3.40
J 7462	Bearing Puller	*	40	4	50.00
J 7463	Arbor Press Fixture ...	*	40	12	130.00

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 7464	Bushing Inst. Tool	*	40	11½	$106.50
J 7465	Drift Pin	*	40	1	24.00
J 7466	Spanner Wrench	*	40	6	195.00
J 7467	Arbor Press Fixture...	*	40	23	149.00
J 7468	Universal Puller	*	40	10	299.25
J 7469	Brg. & Seal Installer...	*	40	35	305.75
J 7470	Clutch Spring Compr...	*	40	12	49.85
J 7471	Need. Brg. Installer ...	*	40	9	38.85
J 7472	Valve Seal Installer....	*	40	2	75.70
J 7473	Inst. & Peening Tool...	*	40	1	65.00
J 7474	Carrier Holding Tool ..	*	40	7	259.60
J 7475	Seal Replacer	*	40	44	115.00
J 7477-01	Strom. Carb. Tool Set..	12	*	¼	1.90
J 7478	Carter Carb. Tool Set ..	12	*	¼	2.10
J 7480	Spring Inst. Tool.....	*	*	¾	4.75
J 7481	Valve Guide Installer...	*	71	¼	5.95
J 7482	Valve Guide Installer...	*	71	¼	4.25
J 7485	Eng. Stand Adapt. Pl. ..	*	63, 100	59	48.00
J 7486	Eng. Stand Adapt. Pl....	*	63, 100	52	55.75
J 7487	Eng. Stand Adapt. Pl....	*	63, 100	42	53.00
J 7488	Eng. Stand Adapt. Pl...	*	63, 100	35	22.00
J 7489	Eng. Stand Adapt. Pl....	*	64, 100	30	22.00
J 7490	Eng. Stand Adapt. Pl....	*	64, 100	33	35.00
J 7493	Eng. Stand Adapt. Pl....	*	64, 100	77	46.75
J 7494	Eng. Stand Adapt. Pl....	*	64, 100	75	46.75
J 7495	Eng. Stand Adapt. Pl....	*	64, 100	92	54.00
J 7496	Eng. Stand Adapt. Pl....	*	64, 100	140	47.00
J 7497	Eng. Stand Adapt. Pl....	*	64, 100	48	51.25
J 7498	Eng. Stand Adapt. Pl....	*	64, 100	74½	56.00
J 7499	Eng. Stand Adapt. Pl....	*	64, 100	88	62.50
J 7500	Eng. Stand Adapt. Pl....	*	64, 100	44	56.00
J 7501	Holder Adapter	31	*	½	6.45
J 7503	Brake Lever Gauge....	48	*	¼	3.40
J 7504	Carter Carb. Gauge....	12	*	¼	1.55
J 7505	Injector Vise Set.....	*	83	3¾	17.85
J 7506	Injector Vise Set.....	*	83	2½	12.30
J 7507	Injector Comparator ..	*	*	238	885.00
J 7515	Needle Brg. Remover..	*	*	1	3.95
J 7515-1	Remover	*	*	½	1.80
J 7515-2	Installer	*	*	½	2.15
J 7516	Needle Brg. Installer...	*	*	½	4.50
J 7516-1	Remover	*	*	¼	2.10
J 7516-2	Installer	*	*	¼	2.40
J 7518	Flywheel Remover	*	*	1	6.30
J 7519	Ring Compressor	*	*	¾	5.45
J 7522	Prop. Shaft Brg. Inst...	*	*	1	5.40
J 7523	Prop. Shaft Brg. Rem...	*	*	¼	3.80
J 7524	Prop. Shaft Brg. Rem...	*	*	¼	2.90
J 7525	Prop. Shaft Brg. Inst...	*	*	¾	3.20
J 7529	Bush. Rem. & Inst.....	*	*	¾	2.15
J 7530	Brg. Rem. Installer....	*	*	½	5.95
J 7530-1	Installer	*	*	¼	3.05
J 7530-2	Remover	*	*	¼	2.90
J 7531	Brg. Rem. & Installer..	*	*	1	13.30
J 7531-1	Installer	*	*	½	2.40
J 7531-2	Brg. Remover Assy. ...	*	*	½	10.90
J 7532	Brg. Rem. & Installer ..	*	*	1	7.40
J 7532-1	Remover	*	*	½	3.25
J 7532-2	Bearing Installer	*	*	½	4.15
J 7533	Brg. Rem. & Installer..	*	*	1	6.00
J 7533-1	Brg. Cup Installer.....	*	*	½	3.05
J 7533-2	Brg. Cup Remover.....	*	*	½	2.95
J 7534	Spring Compressor	*	*	¼	3.05

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 7539-01	Piston Rack Arbor	43	*	¾	$ 3.25
J 7540	Fly. Hous. Stud Set	*	64	¼	5.15
J 7541	Spring Compressor	5	*	1	15.95
J 7545	Bearing Installer	38	*	10½	5.75
J 7546	Pin. Depth Gauge	34	*	¾	9.00
J 7547	Eng. Support Bar	2	*	8½	8.30
J 7550	Ball Joint Serv. Set	45	*	1½	6.75
J 7552	Oil Seal Remover	*	*	2	8.35
J 7552-1	Seal Installer	*	*	1	4.10
J 7552-2	Seal Remover	*	*	1	4.25
J 7553	Bush. Rem. & Installer	*	*	¼	3.70
J 7557	Timing Gear Inst.	*	64	5	10.30
J 7558	Gear Installer	*	*	3¼	12.00
J 7559	Trans. Bush. Inst.	20	*	6½	18.75
J 7560	Valve Guide Inst.	*	71	¾	6.25
J 7562	Bushing Installer	20	*	2	8.40
J 7564	Roch. Carb. Tool Set	12	*	¼	3.15
J 7568	Timing Light	*	95	4	32.95
J 7569	Compressor Gauge	*	*	2	25.00
J 7570	Vacuum Press. Gauge	*	*	2	14.95
J 7574	Bush. Rem. & Inst.	38, 50	*	2¼	19.80
J 7575	Bellows Compressor	54	*	1	4.75
J 7576	Seal Installer	43	*	1	7.10
J 7577	Seal Pilot	17	*	¼	1.70
J 7578	Bearing Installer	47	*	1¼	5.60
J 7583	Seal Remover	2	*	2¾	21.00
J 7584	Crank. Seal Inst.	3	*	1¾	5.75
J 7585	Bearing Installer	47	*	¾	4.85
J 7586-01	Seal Protector	43	*	¼	3.45
J 7587	Bush. Inst. & Rem.	*	64	¼	49.40
J 7588	Oil Seal Installer	3	45	2¾	5.75
J 7589	A/C Hose Clamp	54	*	1½	6.05
J 7590	Volt. Reg. Gauge Set	14	*	¼	6.95
J 7591	Oil Seal Installer	47	*	1	5.85
J 7592-01	Spring Compressor	47	*	4¾	19.50
J 7593-03	Cam Bush. Remover	*	71	4½	75.00
J 7595	#2 Phillips Socket	58	*	¼	1.10
J 7596	#1 Phillips Socket	*	*	¼	1.75
J 7605-02	Oil Injector	54	*	1½	18.95
J 7607-01	Ignit. Nut Wrench	14, 52	*	¼	4.75
J 7608-01	Bush. Reamer Set	*	64	40	128.30
J 7617-01	Lube Fitting	*	29	1¾	19.55
J 7622-01	Eng. Stand Adapt. Pl.	*	65, 100	18¾	25.65
J 7623	Speedo Gear Posit.	17	*	¼	1.25
J 7624	Spanner Wrench	43	27	2	3.75
J 7625-02	Connector Set	*	*	9	58.55
J 7626	Grinding Wheel Set	*	101	4	124.00
J 7627	Grinding Wheel Set	*	101	9	199.00
J 7628	Grinding Wheel Set	*	101	2½	124.00
J 7629	Grinding Wheel Set	*	101	3¾	80.00
J 7630	Grinding Wheel Set	*	101	4	53.40
J 7631	Grinding Wheel Set	*	101	4	67.00
J 7632	Conn. Rod Holder	*	65	8	26.65
J 7634	Roch. Carb. Gauge	12	*	¼	2.05
J 7638	Roch. Carb. Gauge	12	*	¼	2.50
J 7639	Roch. Carb. Gauge	12	*	¼	2.30
J 7640	Roch. Carb. Gauge	12	*	¼	3.85
J 7641	Roch. Carb. Gauge	12	*	¼	3.85
J 7642	Carter Carb. Gauge	12	*	¼	3.20
J 7643	Roch. Carb. Gauge	12	*	¼	2.60
J 7644	Roch. Carb. Gauge	12	*	¼	1.70
J 7645-01	Roch. Carb. Gauge	12	*	¼	2.85
J 7647	Brake Bleed. Wrench	48	*	¼	$ 3.45
J 7648-01	Oil Seal Remover	*	29	1	24.95
J 7650-05	Diagnosis Test Kit	*	65	31½	349.50
J 7651-04	Diagnosis Test Kit	*	65	32	395.40
J 7652	Cruise Control Gauge	56	*	¼	2.45
J 7654	Brg. Rem. & Installer	*	*	2	11.35
J 7655	Bearing Installer	*	*	2	5.80
J 7655-1	Remover	*	*	1½	4.10
J 7655-2	Installer	*	*	1½	1.70
J 7656	Brg. Rem. & Replacer	*	*	1¼	9.40
J 7656-1	Replacer	*	*	½	2.55
J 7656-2	Remover	*	*	¾	6.85
J 7657	Crank. Brg. Remover	*	*	4¼	21.75
J 7659	Grinder Adapter Kit	*	101	2	33.55
J 7662	Alignment Blocks	53	*	¼	2.25
J 7663	Pow. St. Pump Tool	43	*	¼	1.75
J 7664-05	Diagnosis Test Kit	*	65	32	358.90
J 7665	Carter Carb. Gauge	12	*	¼	4.15
J 7667	Grille Installer	51	*	½	6.25
J 7668	Tire Tool	*	30	6	4.50
J 7669	Rock. Panel Pliers	*	*	½	4.10
J 7673	Nut Wrench	14, 51, 52	*	½	3.95
J 7674-01	Vac. Mod. Wr. (.899″)	20	*	½	3.00
J 7675-01	Apron Hoist Tool	*	21	1¼	36.00
J 7687	Linkage Pin	17	*	¼	1.30
J 7689	Roch. Carb. Tool Set	12	*	¼	3.15
J 7690-01	Roch. Carb. Tool Set	12	*	¼	1.80
J 7691-04	Carter Carb. Tool Set	12	*	¼	3.70
J 7706	Bearing Remover	31	*	1	6.50
J 7708-01	Ignit. Nut Wrench	14, 52	*	½	5.75
J 7710	Crimping Block	50	*	¼	3.75
J 7712-04	Carter Carb. Tool Set	12	*	¼	5.25
J 7713-01	Roch. Carb. Tool Set	12	*	¼	3.15
J 7714-06	Roch. Carb. Tool Set	12	*	¼	4.75
J 7715	Press. Gauge (200#)	43	*	1	5.05
J 7716-01	Carter Carb. Gauge	13	*	¼	1.00
J 7717	Carter Carb. Gauge	13	*	¼	3.15
J 7718	Roch. Carb. Gauge	13	*	¼	4.00
J 7719-01	Strom. Carb. Gauge	13	*	¼	2.65
J 7720	Oil Seal Remover	*	*	¾	8.55
J 7721	Oil Seal Installer	*	*	1¼	3.55
J 7723-01	Push-Rod Gauge	48	*	¼	.60
J 7724	Wiper Nut Wrench	51, 52	*	¼	3.85
J 7725	Trans. Turning Tool	30	*	2¾	27.70
J 7726	Ignit. Nut Wrench	*	56	½	4.85
J 7727	Valve Adjuster	54	*	¼	3.60
J 7728	Oil Seal Installer	43	*	1	3.95
J 7736	Height Gauge	*	*	¼	1.75
J 7752	Roch. Carb. Tool Set	13	*	¼	3.10
J 7753-02	Carburetor Gauge	13	*	¼	1.65
J 7754	Tor. Wr. (0-25 in. lb.)	58	*	¾	20.00
J 7755	Valve Guide Installer	5	*	½	4.55
J 7756	Valve Guide Remover	5	*	½	3.35
J 7757	Wh. Brg. Nut Wrench	*	30	25½	93.75
J 7757-1	Octa. Wrench (3¼#)	*	30	2¼	14.00
J 7757-2	Octo. Wrench (3 13/16″)	*	30	2¾	14.50
J 7757-3	Hexa. Wrench (4″)	*	30	3¾	15.00
J 7757-4	Octa. Wrench (4⅜″)	*	30	4	15.50
J 7757-5	Octa. Wrench (4⅞″)	*	30	4½	16.00
J 7757-6	Ext. Bar (8″x¾″)	*	30	2½	4.75
J 7757-17	Nut Wrench (2⅜″)	*	30	2	11.50
J 7757-18	Nut Wrench (3⅞″)	*	30	4	14.50
J 7757-19	Nut Wrench (4⅛″)	*	30	5	15.00

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 7757-20	Nut Wrench (4⅞″)	*	30	7½	$ 16.00
J 7773	Pulley Inst. Set.....	*	65	3	10.90
J 7774	Valve Seat Remover ...	*	71	1¼	32.20
J 7775	Valve Guide Remover ..	*	71	½	4.75
J 7776	Roch. Carb. Tool Set...	13	*	½	4.00
J 7777	Fuel Line Clip Inst.....	10, 50	*	¼	2.75
J 7778	Fog Lamp Wrench.....	51	*	¼	3.35
J 7779	Brake Bleeder Set.....	48	*	½	3.25
J 7780	Piston Assy. Tool	48	*	½	2.75
J 7781	Seal Protector	20	*	¼	2.95
J 7782	Spring Compressor ...	20	*	½	4.75
J 7784	Jaw & Plate Assy.....	*	83	4¼	17.85
J 7785	Seal Installer	*	43	½	4.75
J 7786	P.S. Gauge Adapter....	43	*	¼	.75
J 7787	Crank. Drill Jig	7	*	1¼	31.50
J 7790	Valve Installer	*	71	1½	8.10
J 7792	Grinder Adapter Set ..	*	71, 101	1	25.05
J 7793	Valve Guide Cleaner ...	*	71	¼	4.30
J 7794	Shim Gauge	48	*	¼	5.75
J 7795	Core Rem. & Replacer..	50	*	¼	3.25
J 7796	Piston Depressor	50	*	¼	3.25
J 7797-03	Door Clip Remover....	51	*	¼	1.50
J 7798	Diagnosis Test Kit	*	65	23	193.35
J 7799-01	Nut Rem. & Installer...	*	*	¼	5.15
J 7800	Gauge & Hose Assy. ...	*	33	¾	6.80
J 7801-01	Yoke Installer	*	33	16¾	54.65
J 7802-01	Lock Nut Wrench	*	33	3½	22.80
J 7803	Sling	*	33	½	5.90
J 7804	Yoke & Remover.....	*	33	6¼	21.95
J 7805	Lifting Hook	*	34	¼	4.30
J 7806	Poppet Assy. Tool.....	*	34	¼	5.60
J 7807	Lifting Bracket	*	34	¼	2.35
J 7811	Valve Spr. Compressor.	5	*	¾	9.90
J 7814-02	Track Wear Gauge	*	30	1¼	14.95
J 7816	Clutch Adj. Tool	*	43	¼	6.10
J 7817	Pin. Brg. Installer	34	*	1	5.95
J 7818	Pin. Brg. Installer	34	*	1	6.25
J 7821	Autronic-Eye Adapt. ...	59	*	1½	14.25
J 7822	Brake Adj. Tool	*	24	½	7.90
J 7824	Gauge Kit	*	41	10	64.95
J 7825	Filter Check. Gauge....	10, 56	*	½	8.80
J 7828	Pin. Brg. Remover	34	*	4	16.00
J 7829	Roch. Carb. Ga. Set ...	13	*	¼	2.25
J 7830	St. Wheel Puller.....	*	*	¾	11.25
J 7831	Oil Seal Installer.....	*	*	5¼	6.00
J 7832	Valve Guide Installer...	*	71	½	5.70
J 7837	Float Level Gauge Set..	*	*	¼	2.55
J 7838	Feeler Gauge Set.....	*	*	¼	1.25
J 7839	Prop. Shaft. Seal Inst...	*	*	¼	2.90
J 7840	Oil Seal Installer.....	*	*	¾	2.80
J 7841	Hose Coupling Remover	*	*	¼	7.15
J 7842	Spring Compressor	47	*	5¾	10.65
J 7843	Valve Seat Installer ...	*	48	½	6.15
J 7844	Wiper Coil Puller.....	14, 52	*	¾	10.25
J 7849	Clutch Pull. Adapter...	54	*	¼	3.25
J 7850-02	Cyl. Comp. Ga. Ad.....	*	71	2½	30.00
J 7852	Nozzle Holder	*	83	1	10.00
J 7853	Music Wire (.40″ MM.).	*	83	½	2.60
J 7854	Music Wire (.35″ MM.).	*	83	½	2.60
J 7856	Head Bolt Socket.....	*	71, 83	¾	9.25
J 7857	Fuel Inj. Tube Rem.....	*	83	1	9.80
J 7858	Valve Guide Inst. (Int.).	*	71	1	8.30
J 7859	Valve Guide Inst. (Exh.).	*	71	1	8.45
J 7860	Grinder Adapt. Kit.....	*	71	2	$ 20.40
J 7861	Valve Seat Inst. (Int.)..	*	72	¾	7.90
J 7862	Valve Seat Inst. (Exh.).	*	72	1¼	8.45
J 7865-01	Fuel Inj. Tube Inst.....	*	*	¼	2.85
J 7866	Cyl. Head Stud Set....	*	72	¼	4.85
J 7869	Valve Lift. Remover....	*	*	½	12.95
J 7871-01	Fuel Inj. Bore Cleaner .	*	84	¾	20.50
J 7872	Mag. Base Ind. Set....	*	65, 95	2	32.50
J 7877	Bush. Rem. & Repl.....	45, 50	*	1	9.85
J 7878	Crank. Gear Puller....	*	45	3	21.10
J 7879-01	Vib. Damp. Remover...	*	45	4	37.40
J 7882	Carter Carb. Gauge ...	13	*	¼	2.25
J 7883	Gear Lever Gauge.....	17	*	¼	2.50
J 7889	Pump Assy. Tool	24	*	½	3.15
J 7890	Wiper Retain. Spr.	52	45	¼	.50
J 7891	Cyl. Head Stud Set....	*	45, 72	¼	5.25
J 7892	Pinion Set. Ga. Disc. ..	*	10	2½	6.85
J 7894	Jacking Fixture	59	*	16	32.15
J 7896-01	Trans. Hold. Fixture....	20, 17	*	10	24.10
J 7898-01	Mould. Clip Remover...	51, 53	*	¼	2.35
J 7900	Clip Depressor	*	20	¼	2.95
J 7902	Brg. Cup Installer.....	*	*	1½	6.50
J 7903	Brg. Cup Installer.....	*	*	1½	7.55
J 7905	Bearing Installer	*	*	¾	3.85
J 7906	Pinion Set. Gauge	*	*	6	36.35
J 7913	Filter Cap Socket.....	*	84	½	3.60
J 7914	Music Wire (.004″)....	*	84	¼	.50
J 7915-02	Cyl. Compr. Ga. Ad....	*	65	2	24.90
J 7916	Switch Socket	9	*	1¼	2.10
J 7923	Overdrive Wr. (1⅞″)...	30	*	1	3.65
J 7924	Grinder Adapt. Kit.....	*	72, 101	1	10.05
J 7931	Pinion Set Gauge.....	*	10	47½	182.55
J 7932	Puller Adapter	*	74	¼	2.45
J 7933	Seal Protector	*	21	1	7.50
J 7934	Seal Protector	*	21	1½	11.40
J 7935	Slide Hammer Set	38	*	1¾	9.55
J 7940	Carb. Tool Kit	10	*	½	11.90
J 7941	Fly. Hous. Reamers	.	45	2	14.85
J 7944	Wire Brush	*	84	¾	7.55
J 7999	Engine Parts Dolly	*	65, 99	300	265.00
J 8000	Copper Tube Cutter....	58	96	¾	4.65
J 8001	Dial Indicator Set	58	2, 10, 38, 96	2	27.85
J 8001-1	Clamp	58	*	¾	2.75
J 8001-2	Sleeve	58	*	¼	2.60
J 8001-3	Dial Indicator	58	*	¾	18.75
J 8001-4	Hole Attachment	58	*	½	3.85
J 8002	Brake Cyl. Clamps.....	48	24	1	2.40
J 8003	Valve Guide Reamer...	5	48	¼	4.85
J 8004-01	Wr. Adapt. (¾″ Hex.)..	3	45	½	4.50
J 8007	Pin Hole Reamer.....	*	2, 28	3	9.15
J 8008	Bush. Re. (.010″ O.S.)..	*	3	7	10.40
J 8009	Distrib. Term. Cleaner..	14	56, 96	¼	1.05
J 8010	Conn. Rod Bolt Socket.	7	*	¼	1.75
J 8013	Piston Ring Remover ..	*	*	½	6.75
J 8014	Pis. Ring Rem. (3⅜″) ..	7	*	½	6.75
J 8015	Pis. Ring Rem. (3½″) ..	8	*	½	6.75
J 8016	Pis. Ring Rem. (3⁷⁄₁₆″) ..	8	*	½	6.75
J 8017	Pis. Ring Rem. (3³⁄₃₂″) ..	8	*	½	6.75
J 8018	Pis. Ring Rem. (3⁵⁄₁₆″) ..	8	*	½	6.75
J 8019	Pis. Ring Rem. (3³⁄₁₆″) ..	8	*	½	6.75
J 8020	Pis. Ring Tool (3⁹⁄₁₆″) ..	8	*	½	6.75
J 8021	Pis. Ring Rem. (3⅞″) ..	8	51	½	6.75
J 8023	Piston Ring Tool	*	51	1	10.50

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 8024	Piston Ring Rem. (3″)	8	*	½	$ 6.75
J 8025	Pis. Ring Rem. (3⅛″)	8	*	½	6.75
J 8026	Pis. Ring Rem. (4 13/16″)	*	51	1½	14.00
J 8027	Pis. Ring Rem. (3⅝″)	8	*	½	6.75
J 8028	Pis. Ring Rem. (3¾″)	8	51	½	6.75
J 8029	Pis. Ring Rem. (3 13/16″)	8	51	½	6.75
J 8030	Pis. Ring Rem. (4¼″)	*	51	1½	6.75
J 8031	Pis. Ring Rem. (4 9/16″)	*	51	1½	10.50
J 8032	Piston Ring Rem. (4″)	8	51	½	6.75
J 8033	King-Pin Reamer	*	3	2½	8.95
J 8034	Bush. Reamer (.020″)	*	3	2½	10.95
J 8037	Ring Compressor	8	51	½	2.50
J 8039	Snap Ring Pliers	20	34, 38, 41, 90, 96	½	4.80
J 8040	Socket	*	*	¼	.85
J 8041	Clutch Head Screw Driver	51	*	1	5.40
J 8042	Rack	8	48	11¼	5.00
J 8046	Stud Wr. (9/16″-⅝″)	*	*	1	5.85
J 8047	Bat. Post Clean. Brush.	14	56, 96	¼	2.30
J 8048	Voltage Reg. Kit	14	56	¼	14.80
J 8050	Flaring Tool Set (37°)	*	*	17¾	129.85
J 8051	Flaring Tool Set (45°)	48, 58	24, 96, 101	14¼	104.90
J 8052	Wh. Brg. Nut Wrench	*	*	1¼	2.25
J 8053	Ring Compr. (3 3/32″)	8	*	¼	3.00
J 8054	Ring Compr. (3 7/16″)	8	*	¼	3.00
J 8056	Clutch Spr. Tester	6	48, 96	10½	33.35
J 8057	Brake Spr. Pliers	48	24	1	3.65
J 8058	Torque Wrench (½″ Dr., 0-50 Ft. lb.)	58	96	2	13.90
J 8059	Snap Ring Pliers	58	10, 34, 38, 76, 96	1	6.25
J 8060	Cylinder Guage	*	45, 65, 96	1¾	28.50
J 8062	Valve Spring Comp.	6	48	6	12.65
J 8064	10 Ton Arbor Press	*	*	68	65.00
J 8068	Adapter (⅜″ Fem. to ½# Male Dr.)	58	10, 96	¼	1.45
J 8069	Bush. Ream. (1-110″)	*	3	2	12.80
J 8071	Sheet Metal Cutter	51	20, 96	1½	5.95
J 8074	Hyd. Press. Gauge	56	*	¾	15.25
J 8075	Torque Wr. Adapter	58	96	¼	1.50
J 8076	Brg. Adjust. Bit	*	*	¼	2.50
J 8079	Ring Comp. (3⅜″)	8	*	¾	3.00
J 8080	Main Brg. Shell	3, 8	45	¼	1.90
J 8081	Spring Compressor	47	*	3	14.95
J 8087	Cyl. Bore Gauge	3	*	2½	36.75
J 8089	Carbon Rem. Brush	3	45, 96	¼	1.85
J 8092	Driver Handle	58	3, 10, 30 38, 41, 65	3	4.95
J 8093	Brg. Race Replacer	*	10, 30	3½	16.00
J 8095	Pitman Arm Puller (1½″ Shaft)	*	25, 27	2¾	18.25
J 8101	Valve Guide Cleaner	6	49, 72, 96	¼	1.30
J 8105	Crank. Gear Puller	8	45	3¼	19.30
J 8106	Val. Guide Ream. (5/16″)	6	*	½	6.35
J 8107	Bearing Puller	34	3, 10, 34	5	25.75
J 8109	Shift Level Rem.	*	34	1½	21.50
J 8111	Puller Set	58	102	10	61.55
J 8112	Bearing Puller	*	*	6¾	21.60
J 8113	Bush. Rem. & Repl.	*	*	3	3.95
J 8114	Brg. Race Replacer	*	10, 30	2¾	14.95
J 8117	Output Shaft Adapt.	24, 38	10,34,38,90	½	4.10
J 8118	Spring Pin Puller	*	28	½	6.50
J 8119	Oil Seal Remover	38	10, 25	2	19.70

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 8124	Blow Gun Assembly	30	38	1	$ 6.90
J 8124-01	Blow Gun Assembly	24	*	1¼	10.05
J 8127	Bat. Serv. Tl. Set.	14, 58	56, 96	1¼	9.75
J 8128	Ring Assy. Tool	*	65, 72	½	2.25
J 8129	Tension Scale (15#)	58	3, 10, 27, 65	¼	9.40
J 8130	Test Fluid (5 Gal.)	6	84	38½	9.55
J 8139	Brg. Remover Plate	34	*	2	4.80
J 8140	Brg. Rem. Washer	34	*	½	1.50
J 8142	Pis. Ring Rem. (3 15/16″)	8	*	½	4.30
J 8147	Blow. Serv. Tool Set	*	75	7	42.00
J 8148	Brg. Cup Inserter	47	*	1	4.50
J 8149	Brg. Cup Inserter	47	*	¾	4.90
J 8150	Rack Hole Brush	*	84	¼	.25
J 8151	Fuel Press. Gauge	*	65, 84	1¼	7.50
J 8152	Inj. Fuel Hole Brush	*	84	¼	.35
J 8153	Manometer (12-0-12)	*	97	5	17.30
J 8154	Filter Bag	*	*	2	11.05
J 8157	Bearing Remover	17	*	3½	29.95
J 8158	Extension Arm (30″)	*	97	½	6.75
J 8159	Extension Arm (24″)	*	97	¼	6.75
J 8160	Extension Arm (18″)	*	97	¼	6.75
J 8161	Extension Arm (12″)	*	97	¼	6.75
J 8162	Extension Arm (10″)	*	97	¼	6.75
J 8164	Brg. Cup Installer	*	*	½	3.20
J 8165	Valve Seat Grinder	*	101	45	329.40
J 8165-8	Adapter Set	*	72, 101	4	32.90
J 8166	Hand Tachometer (200-2400 R.P.M.)	*	97	4	45.00
J 8167	Press. Gauge (0-100#)	*	97	1¼	24.00
J 8169-02	Injector Cleaner	*	84	¼	2.95
J 8170	Sharpening Stone	*	84	¼	.45
J 8171	Puller Legs (22½″ Lg.)	*	*	9¾	11.15
J 8172	Brass Rule (6″)	*	66	¼	.20
J 8173	Steel Grip Puller	*	102	1¾	10.50
J 8174	Steel Grip Puller	*	102	4½	19.50
J 8175	Steel Grip Puller	*	102	10¼	29.95
J 8176	Bearing Separator	*	10, 34, 102	13	25.75
J 8177	Internal Puller	*	102	6½	21.40
J 8178	Steel Grip Puller	*	102	3¼	15.50
J 8179	Steel Grip Puller	*	102	7¾	29.15
J 8180	Puller Legs (4½″ Lg.)	*	*	2½	7.90
J 8181	Puller Adapter (Pr.)	*	102	¾	5.00
J 8182	Puller Adapter (Pr.)	*	102	¾	5.00
J 8183	Puller Adapter (Pr.)	*	102	½	5.00
J 8184	Puller Adapter (Pr.)	*	102	1	5.00
J 8185	Puller Adapter (Pr.)	*	102	1¾	4.50
J 8186	Manometer (4-0)	*	97	5	11.75
J 8187	Manometer (8-0-8)	*	97	3¼	14.50
J 8188	Manometer (10-0-10)	*	97	2¾	16.00
J 8189	Press. Gauge (0-15#)	*	97	2	20.50
J 8190	Universal Puller	*	34, 38, 102	21	41.90
J 8192	Exten. Arm (8″)	*	97	¼	6.75
J 8193	Puller Legs (16″)	*	*	6½	10.15
J 8196	Mounting Plate	*	66, 100	75	68.65
J 8198	Adapter Plate	*	66, 100	40	51.95
J 8200-01	Engine Adapt. Plate	*	66, 100	135	87.45
J 8229-02	Vib. Damp. Installer	8	*	8⅛	63.90
J 8257	Meth. Eth. Ke. (1 Gal.)	*	84	10½	5.45
J 8279	Seat Cleaner	*	30	¼	3.65
J 8302-01	End-Play Check. Tool	*	30	17	75.50
J 8303	Filter Cap Remover	*	21	4¼	13.95
J 8304	Ring Compressor	*	*	¾	3.75

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 8305	Univ. Gear Puller	58	*	¾	$ 22.75
J 8306	Tachometer Cable	*	97	1¼	18.00
J 8313	Head Lifting Sling	*	72	1	15.00
J 8316	Eng. Stand. Adap. Pl.	*	66, 100	150	139.85
J 8328	Carb. Holding Kit	10	53	¼	2.50
J 8329	Impeller Remover	*	74	2¼	10.25
J 8331	Pin. Brg. Remover	34	*	2	14.40
J 8333	Bush. Installer	34	*	¼	2.65
J 8340-01	Seal Installer	34	*	3	4.75
J 8342	Brg. Adj. Wrench	34	*	¼	4.90
J 8345	Bush. Rem. & Installer	45	*	1¾	10.20
J 8346	Bush. Rem. & Inst.	45	*	¾	9.15
J 8347-01	Bush. Rem. & Inst.	45	*	1¼	8.00
J 8349	Race Installer	47	*	½	3.75
J 8351	Race Installer	47	*	¼	3.45
J 8354	Stud Installer Set	3	*	¾	5.70
J 8355-01	Piston Pin Rem.	8	*	1½	17.95
J 8356	Ring Compressor	8	*	¼	5.75
J 8357	Bushing Installer	45	*	½	2.90
J 8358	Carb. Rem. Brush	3	*	¼	3.25
J 8359	Bearing Installer	35	*	¾	5.55
J 8360	Auto. Trans. Bush.	20, 24	*	3	21.15
J 8361	Clutch Gear Puller	17	*	2½	27.50
J 8362	Pinion Turn. Tool	35	*	¼	3.05
J 8364	Ind. Support & Ext.	24	*	½	8.45
J 8365	Posit. Gauge	20, 24	*	¼	2.45
J 8366	Bush. Remover	40	*	1¼	6.10
J 8367	Nozzle Gauge	56	*	¼	10.90
J 8368	Spark Plug Gauge	56	*	¼	2.75
J 8369	Pipe Installer	9	*	½	13.95
J 8370	Roch. Carb. Gauge	13	*	¼	2.75
J 8371	Selector Gauge	20	*	1¾	13.85
J 8381	Gas-Per-Mile Gauge	59	*	7½	25.35
J 8385-01	Master Ring	*	66	7	65.00
J 8386-01	Master Ring	*	66	9	75.00
J 8387-01	Spray Test Fixture	*	*	12½	195.00
J 8390-02	Piston Pin Rem. Set	8	*	1¼	17.35
J 8393	Deluxe Charg. Station	54	*	100	215.00
J 8393-50	Field Revision Kit	*	*	1	5.45
J 8394	Hydraulic Jack	59	*	172	250.00
J 8397	Vacuum Ga. (0-100#)	*	97	½	9.90
J 8398	Torque Wrench (¾"Dr., 0-500 Ft. Lb.)	58	98	11	106.00
J.8399	Eng. Stand. Adapt. Pl.	*	66, 100	28	49.75
J 8400	Bushing Service Set	25	*	24¼	140.75
J 8400-1	Trans. Bush. Chisel	*	*	½	2.50
J 8400-2	Installer	*	*	⅜	3.15
J 8400-3	Installer	*	*	⅜	2.65
J 8400-4	Installer	*	*	⅝	2.65
J 8400-6	Installer	*	*	¾	2.60
J 8400-7	Installer	*	*	1⅝	4.90
J 8400-8	Installer	*	*	⅝	3.95
J 8400-9	Installer	*	*	⅝	2.40
J 8400-11	Remover	*	*	¼	1.85
J 8400-12	Installer	*	*	½	2.50
J 8400-14	Installer	*	*	⅞	2.85
J 8400-16	Installer	*	*	⅞	2.70
J 8400-17	Installer	*	*	¾	2.65
J 8400-19	Installer	*	*	1	2.80
J 8400-21	Staker	*	*	¼	7.00
J 8400-22	Staker	*	*	⅜	7.00
J 8400-23	Installer	*	*	2¾	5.50
J 8400-24	Installer	*	*	3¾	9.25
J 8400-25	Installer	*	*	4	$ 9.35
J 8400-30	Support	*	*	¼	1.75
J 8400-31	Reamer	*	*	3⅛	16.95
J 8400-32	Reamer Guide	*	*	3	17.10
J 8400-36	Reamer Handle	*	*	1	3.95
J 8400-55	Installer	*	*	1⅜	5.25
J 8400-65	Reamer	*	*	3⅝	17.50
J 8404	Hose Clamp Pliers	9	*	½	2.75
J 8413	Chg. Cyl. Assembly	55	*	9	66.50
J 8418	Charging Station	55	*	39	151.00
J 8420	Deluxe Charging Cyl.	55	*	43	95.50
J 8421	Charging Cyl.	55	*	41	81.00
J 8422-01	Panel Assy.	55	*	2¾	26.50
J 8424	Valve Depressor	*	28	½	6.25
J 8430-01	Bearing Driver	*	21	2¾	8.45
J 8433	A/C Pulley Puller	25, 55	*	4½	18.60
J 8434	Flywheel Puller	*	*	3½	13.50
J 8436	Oil Seal Installer	35	*	¾	5.75
J 8437	Brille Clip Installer	51	*	½	6.50
J 8438	Nut Wrench	53	*	½	8.85
J 8443-01	Vib. Damp. Remover	8	*	3	21.25
J 8445-01	Bearing Installer	*	30	13¾	62.90
J 8446	Pulley Installer	55	*	1½	9.75
J 8448	Bush. Rem. & Inst.	35	*	1¾	9.55
J 8449	Nut Splitter	*	98	1	4.95
J 8450	Muffler Chisel	*	98	1	1.20
J 8456	Grease Ret. Installer	47	*	1	6.20
J 8457	Brg. Cup Installer	47	*	¾	6.20
J 8458	Brg. Cup Installer	47	*	¾	6.85
J 8459	Bushing Remover	*	28	3	29.50
J 8461	Snap Ring Rem. Set.	*	*	¾	4.65
J 8461-1	Snap Ring Remover	*	34	½	2.75
J 8463	Nozzle Remover	*	*	¾	5.85
J 8465-02	Guidematic Tester	59	*	8¾	52.00
J 8465-1	Head Assembly	*	*	8	11.55
J 8465-20	Aiming Device	59	*	¾	11.00
J 8466	Brg. Rem. & Inst.	*	90	1	8.10
J 8467	Oil Seal Installer	*	90	¾	9.75
J 8468	Track Wear Gauge	*	30	½	5.50
J 8469	Track Wear Gauge	*	30	½	5.50
J 8471	Nut Wrench Set	*	30	36½	106.75
J 8472	Exh. Pipe Gripper	*	98	2	9.75
J 8473	Exh. Pipe Cutter	*	98	2	9.75
J 8474	Bushing Remover	*	10	2¼	7.75
J 8476	Bushing Installer	*	10	¾	4.75
J 8477	Oil Seal Installer	*	11	5½	6.50
J 8478	Holding Tool	*	11	11	14.80
J 8479	Brg. Cup Installer	*	11	2¾	6.75
J 8481-01	Bushing Installer	45	*	3½	15.25
J 8482	Oil Seal Installer	38	*	½	5.75
J 8483-01	Trans. Bush. Set	*	41	4½	44.15
J 8484	Exh. Pipe Form. Tool	*	98	4	9.75
J 8491	Oil Seal Protector	*	90	1½	10.85
J 8493	Seal Installer	*	84	½	2.95
J 8496	Spring Compr. Set	6	*	2½	10.60
J 8497	Throt. Lever Gauge	25	*	½	6.10
J 8499	Seal Installer	*	74	4	7.45
J 8500-04	Diagnosis Test Kit	*	66	35	318.65
J 8501	Oil Seal Installer	*	74	1	5.80
J 8506	Float Lev. Ga. Set	*	*	¼	2.40
J 8507	Eng. Stand Adap. Pl.	*	66, 100	138	345.00
J 8508	Eng. Stand Adap. Pl.	*	66, 100	210	495.00
J 8509	Gear Installer	*	74	1¾	9.80

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 8514	Bolt Wrench (⅝″)	*	45	1	$ 2.70
J 8517	Tandem Wedge	*	28	4	8.95
J 8518	Bushing Installer	*	11, 28	¾	4.00
J 8520	Lift Indicator	6	49	1¼	62.00
J 8522	Bushing Installer	*	25	¾	3.50
J 8523	Bushing Remover	*	25	1	9.25
J 8524	Bearing Remover	*	27	½	5.70
J 8526	Seal Rem. & Inst.	*	27	1	7.45
J 8528	Oil Seal Installer	*	45	6½	13.75
J 8529	Volt. Reg. Thermom. ..	14	*	½	2.95
J 8530	Park. Brk. Lev. Ga.	48	*	¼	2.35
J 8531-01	Brake Shim Gauge	48	*	¼	1.15
J 8532	Trans. Bush. Set	25	*	24	132.45
J 8533	Bushing Serv. Set	25	*	24	121.95
J 8534	Bush. Serv. Set.	25	*	24	114.05
J 8535	Cup & Cone	*	43	5	8.95
J 8536	Staking Tool	*	43	1	1.40
J 8537	Nozzle Repair Kit	*	84	5	49.35
J 8538-01	Inj. Tester Assy.	*	84	16	119.25
J 8540	Spanner Wrench	*	21	2½	11.50
J 8541	Seal Protector	*	21	¼	6.85
J 8543	Spr. Compressor	*	21	¾	10.15
J 8544	Seal Installer	*	22	1	3.75
J 8546	Bearing Installer	*	22	½	6.55
J 8547	Control Wedge	56	*	¼	1.75
J 8548	Spr. Rem. & Instl.	48	*	¼	1.95
J 8549	Brg. & Shaft Inst.	*	52	3	9.15
J 8550	Seal Installer	*	75	3¼	9.75
J 8551	Fish Tail Wrench	*	31	1½	13.75
J 8553	Shaft Brg. Remover ...	*	34	7	12.95
J 8554	Brake Bleed Adapter ..	*	24	2	9.85
J 8555-03	Carb. Gauge Set	13	*	¼	2.80
J 8556-03	Roch. Carb. Ga. Set ...	13	*	¼	3.25
J 8557-03	Roch. Carb. Ga. Set. ...	13	*	¼	2.60
J 8558	Dr. Adapt. (½″ Allen x ½″ Sq.)	*	22	½	1.65
J 8559	Shaft Installer	*	22	¾	8.50
J 8561	Bearing Installer	*	91	¾	8.30
J 8562	Ignition Nut Wrench ..	53	*	¼	4.85
J 8563	Excutcheon Wrench ...	53	*	¼	4.25
J 8564	Oil Seal Installer	40	*	¼	3.55
J 8565	Valve Insert Remover .	*	49	3	26.15
J 8566	Service Tool Set	*	22	8¼	52.80
J 8567	Service Tool Set	*	22	11¼	76.20
J 8568	Engine Jack	60	*	3½	9.85
J 8569	Pitman Seal Inst.	40	*	1½	2.95
J 8571	Bushing Installer	*	41	4½	8.20
J 8573	Clutch Torque Adap. ..	*	41	½	3.60
J 8574	Quill Shaft Remover ..	*	41	¾	4.70
J 8575	Quill Shaft Adapter ...	*	41	1¼	10.65
J 8576	Brg. Cup Installer	*	41	10	16.20
J 8577	Brg. Cup Installer	*	41	4½	11.25
J 8578	Br. Cup Installer	*	41	9	15.30
J 8580	Bushing Installer	*	41	3	6.95
J 8582	Gear Screw Set	*	41	1¾	8.85
J 8583	Shaft. Bush. Installer ..	*	41	½	4.80
J 8588	Gear Bush. Installer ..	*	41	1½	6.95
J 8591	Allen Wrench (⅜″)	25	*	½	1.45
J 8592	Handle	58	41	4¼	6.50
J 8600	Valve Seat Installer ...	*	49	1¾	6.65
J 8601-01	Eng. Stand Adap. Pl. ..	*	66, 100	124	85.00
J 8603	Tor. Wr. (0-600 in. Lb.) .	*	*	2½	13.90
J 8604	Tor. Wr. (0-100 ft. Lb.) .	*	*	2½	14.75

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 8606	Bearing Installer	35	*	1	$ 7.30
J 8608	Pin. Brg. Cup Inst. ...	35	*	1½	5.75
J 8609	Pin. Brg. Installer	35	*	3¾	6.55
J 8610-01	Axle Seal Installer	38	*	¾	5.55
J 8611-01	Pin. Brg. Cup Inst. ...	35	*	1	5.75
J 8612	Pin. Brg. Remover	35	*	7¾	25.25
J 8613	Oil Seal Installer	35	*	½	4.15
J 8614	Holder & Remover	31	*	7	16.00
J 8615	Brg. Puller Adapter ...	35	*	½	3.25
J 8618	Alignment Studs	35	*	¼	1.30
J 8619-01	Pinion Set. Gauge	35	*	11½	92.20
J 8619-10	Pinion Depth Gauge ...	*	*	1¼	8.50
J 8619-11	Gauge Plate	*	*	1¾	12.80
J 8619-12	Pilot Washer	*	*	¼	2.70
J 8619-13	Stud Assembly	*	*	½	2.95
J 8621	Ax. Brg. Rem. Pl.....	38	*	1	6.75
J 8622	Ax. Hous. Adapter.....	38	*	6¾	25.00
J 8625-01	Injector Tester	*	84	22	163.50
J 8626	Adapter Set	*	*	¼	7.50
J 8627	Auto. Light Sw. Test. ..	60	*	¼	8.75
J 8629	Reamer Set (O.S.).....	*	*	6	21.60
J 8629-1	Reamer (Int. — 11/32″—.005″ O.S.) ..	*	*	1½	6.45
J 8629-2	Reamer (Int.)— ⅜″—.005″ O.S. ...	*	*	1½	6.65
J 8629-3	Reamer (Exh.)— 7/16″—.005″ O.S. ...	*	*	1½	6.95
J 8629-4	Reamer (Exh.)— 7/16″—.010″ O.S. ...	*	*	1½	6.95
J 8632	Prop. Shaft Gauge	31	*	4¾	19.50
J 8633-01	Poppet Assy. Tool.....	*	34	¼	4.50
J 8634	Pilot Stud Set.....	*	66	½	8.85
J 8635	Adapter Kit	*	*	¼	.80
J 8636-03	Carter Carb. Gauge....	13	*	½	3.35
J 8637-03	Roch. Carb. Gauge....	13	*	¾	4.25
J 8638	Synchro. Adj. Gauge...	17	*	¼	2.25
J 8639	Manometer (18-0-18) ..	*	98	3¼	27.65
J 8641	Solenoid Wr. (1 1/16″) ...	28	*	¼	2.30
J 8642	Seal Protector	43	*	¼	3.65
J 8644	Gear Assy. Fixture	*	42	27½	56.25
J 8646-01	Pulley Remover	43	*	1½	16.90
J 8647	Seal Remover	43	*	¾	7.85
J 8648	Seal Installer	43	*	¼	.95
J 8649	Shaft Support	43	*	1	4.25
J 8650	Eng. Adapter Plate....	*	67, 100	134½	155.00
J 8651-01	Combination Tester ...	60	*	12¾	57.50
J 8652-01	Auto. Light Sw. Test...	60	*	8½	34.95
J 8653	Nut Wrench	53	*	¼	4.10
J 8655	Ball Brg. Remover.....	*	22	1¼	6.20
J 8656	Needle Brg. Remover..	*	22	5	36.40
J 8657	Seal Installer	*	22	¾	3.90
J 8659	#4 Easy-Out Extrac. ...	43	*	¾	1.30
J 8660	Bush. Rem. & Inst.	*	67	3	12.50
J 8661	Bush. Rem. & Inst.	*	67	2	12.50
J 8662	"Eye" Conver. Kit	60	*	2¾	11.25
J 8864	Hex Adapter (¾″)	*	22	¼	4.65
J 8665	"Eye" Test Head.....	60	*	½	12.50
J 8666-01	Nozzle Tester & Case..	*	85	26	146.15
J 8667	Carb. Gauge Set	13	*	¼	1.95
J 8668-01	Bearing Installer	35	*	½	5.75
J 8669	Pinion Brg. Remover...	35	*	2¾	19.50
J 8670	Brg. Puller & Adapt....	35	*	2½	25.40
J 8671	Brg. Cup Installer.....	35	*	1¼	5.70

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 8672	Brg. Cup Installer	35	*	1	$ 5.35
J 8674	"Eye" Modif. Kit	60	*	1½	22.25
J 8676	Antenna Wrench	56	*	¼	3.15
J 8681	Short Checker	60	*	½	8.25
J 8682	Oil Seal Expander	*	67	2	14.75
J 8683	Eng. Stand Adapt. Pl.	*	67, 100	90	87.50
J 8686-02	Inj. Comparator	*	85	317	1675.00
J 8689	Injector Adapter	*	85	¼	3.00
J 8690-04	Eng. Stand Adapt. Pl.	60	*	51	52.80
J 8692	Hole Saw	*	*	½	11.25
J 8694	Sleeve Installer	*	75	1	3.60
J 8698	Shift Lever Gauge	17	*	¼	5.65
J 8701	Clutch Plate Remover	*	91	¼	5.90
J 8702	Bearing Installer	*	91	10	17.75
J 8703	Roll Pin Remover	*	91	3	19.50
J 8704	Race Installer	*	91	6¼	19.50
J 8705	Staking Tool	*	91	¾	13.70
J 8706	Roll Pin Installer	*	91	½	4.85
J 8707	Roll Pin Installer	*	91	½	4.85
J 8708	Race Installer	*	91	8	16.00
J 8709	Roll Pin Installer	*	91	¾	3.95
J 8710	Hous. Cup Installer	*	91	8¾	19.50
J 8711	Hous. Cup Installer	*	91	14½	35.00
J 8712	Roll Pin Installer	*	91	½	8.95
J 8715	Pinion Hold. Tool	35	*	3	19.10
J 8718	Piston Pin Remover	*	*	½	7.35
J 8728	"Eye" Adapt. Kit	60	*	4½	23.50
J 8730	Stator Assy. Sleeve	*	42	2	7.75
J 8731	Freon Adapt. (¼")	50	*	¼	1.95
J 8733	Torque Wrench	*	*	5	41.00
J 8734	Seal Installer	*	22	1	7.55
J 8739	Hex Bit Set	*	*	½	3.45
J 8741	Shim Gauge	*	31	4	16.25
J 8742	Shim Gauge	*	34	4	15.00
J 8743	Piston Ring Expander	*	*	½	2.30
J 8744	Brg. Nut Wrench	*	34	5	24.95
J 8746	Gauge Kit	*	22	22	149.95
J 8747	Track Wear Gauge	*	31	½	5.50
J 8748	Spring Compressor	*	22	¼	1.60
J 8749	Door Hinge Socket	51	*	½	4.70
J 8750	C.F.R. Carbon Blaster	*	*	24¼	272.50
J 8753	Oil Seal Installer	3	*	1	9.50
J 8754	Piston Pin Remover	8	*	2	14.50
J 8760-01	Speedo Gear Adapter	25	*	2	6.55
J 8761	Oil Seal Installer	25	*	¾	5.25
J 8762	Oil Seal Remover	*	*	1	8.25
J 8763-01	Trans. Hold. Fixture	25	*	14½	39.10
J 8765	"C" Washer	25	*	¾	2.55
J 8766	Oil Seal Protector	25	*	½	3.25
J 8767	Seal Protector	25	*	1	7.15
J 8768-01	Cone Puller	25	*	½	7.90
J 8773	Solenoid Adj. Kit	28	*	¾	7.55
J 8777	Oil Seal Installer	8	*	¼	2.85
J 8779	Bushing Remover	17	*	2	5.50
J 8785	Piston Ring Compr.	*	*	½	2.85
J 8786-01	Piston Ring Compr.	*	*	½	4.75
J 8787	Piston Ring Compr.	*	*	½	3.05
J 8788	Piston Ring Compr.	*	*	½	3.15
J 8789	Piston Ring Compr.	*	*	½	3.10
J 8790	Piston Ring Compr.	*	*	½	4.45
J 8791	Piston Ring Compr.	*	*	½	4.00
J 8792	Vib. Damp. Installer	8	*	3¾	21.50
J 8793	Air-Ride Socket (5/16"—12 Pt.—3/8" Dr.)	50	*	¼	$ .95
J 8794	"Flo-Tac" G-P-M-Ga.	60	*	2½	97.25
J 8794-80	G-P-M Adapter Kit (3/8" Tube)	*	*	¼	2.95
J 8794-85	G-P-M Adapter Kit (¼" Tube)	*	*	¼	3.40
J 8794-90	G-P-M Adapter Kit	*	*	¼	3.60
J 8794-95	G-P-M Adapter Kit (¼" Tube)	*	*	¼	6.25
J 8797	Gauge Oil (2 oz.)	*	67, 98	¼	3.75
J 8801	Socket ¼"—¼" Dr., 8 Pt.)	56	*	¾	.85
J 8802	Inj. Cup-Out Tool	*	72	2½	17.40
J 8803	Depth Ga. (0-3")	*	98	1	28.75
J 8804	Nut Wrench	*	35	10	49.50
J 8805-01	Axle Shaft Remover	38	*	3¾	9.80
J 8806-01	Ball Joint Remover	45	*	¾	17.95
J 8807	Crank. Seal Installer	3, 8	*	½	4.90
J 8808	Control Arm Spacer	45	*	¼	2.25
J 8809	Cam. Brg. Remover	3	*	14½	28.50
J 8810	Bushing Remover	40	*	½	3.50
J 8811	Seal Installer	40	*	¼	3.90
J 8813	Valve Guide Installer	6	*	1¼	5.00
J 8814	Valve Guide Reamer	6	*	¼	4.50
J 8818-01	Seal Installer	43	*	¼	1.70
J 8822	Bolt Guide Set	9	*	¼	4.30
J 8823	Adjust. Tool Kit	*	35	11	60.00
J 8824	Float Level Gauge	*	54	¼	1.25
J 8828	Oil Seal Protector	25	*	¼	1.60
J 8832	Val. Guide Inst. (Exh.)	*	72	1	4.50
J 8833	Val. Guide Inst. (Int.)	*	72	1	4.50
J 8834	Val. Guide Inst. (Exh.)	*	72	¾	6.50
J 8835	Val. Seat Inst. (Int.)	*	73	¾	6.50
J 8839	Bosch Adapter Kit	*	85	¾	10.00
J 8841	Seal Installer	43	*	¼	2.50
J 8842	Seal Remover	43	*	½	8.50
J 8843	Seal Protector	25	*	¼	3.20
J 8844	Test Oil (5 Gal.)	*	85	55	9.75
J 8845	Bushing Sleeve	25	*	3	16.50
J 8849	Brg. Cap Installer	47	*	½	4.30
J 8850	Brg. Race Installer	47	*	¾	5.80
J 8851	Track Wear Gauge	*	31	¾	16.50
J 8853	Axle Brg. Replacer	38	*	4	6.55
J 8855	Brg. Cup Remover	35	*	2	12.60
J 8859	Piston Pin Installer	9	*	1	12.80
J 8864	Oil Seal Installer	17	*	¼	4.05
J 8865	End-Play Check. Tool	31	*	2½	6.25
J 8870	Valve Remover Set	*	*	9½	192.25
J 8871	Truarc Pliers (#22 Ext.)	58	*	¼	2.95
J 8872	Truarc Pliers (#24 Ext.)	58	*	¼	3.30
J 8873	Truarc Pliers (#25 Int.)	58	*	¼	4.20
J 8874	Socket (3/8" Dr.)	25	*	¼	1.35
J 8877	Axle Brg. Remover	38	*	7½	13.60
J 8878	Carb. Chain Gauge	13	*	¼	3.15
J 8879-01	Roch. Carb. Ga. Set	13	*	¼	5.25
J 8880	Clutch Brg. Remover	17	*	5	45.25
J 8884	Pump Bush. Installer	17	*	¼	2.75
J 8885	Pump Bush. Remover	17	*	¾	2.65
J 8886	Shaft Bush. Installer	17	*	¼	6.25
J 8887	Pin. Bush. Installer	*	*	¼	2.60
J 8888	Bushing Installer	35	*	½	2.60
J 8889	Oil Seal Installer	31	*	½	3.75
J 8890	Spanner Wrench	35	*	1¼	10.80

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 8891	Speedo Gear Remover	35	*	1¾	$ 9.25
J 8892	Pin. Brg. Installer	35	*	1¾	6.25
J 8893	Pin Brg. Remover	35	*	1½	10.50
J 8894	Pin Brg. Installer	35	*	2¼	6.55
J 8897	Brg. Cup Remover	35	*	¾	4.25
J 8898	Brg. Cup Installer	35	*	2	7.25
J 8899	Oil Seal Installer	36	*	3¾	9.50
J 8900	Bearing Remover	36	*	3¼	23.80
J 8901	Bearing Installer	36	*	2½	5.50
J 8902	Spanner Wrench	36	*	½	7.35
J 8903	Brg. Check. Fixture	36	*	½	4.85
J 8904	Speed. Gear Remover	31	*	2	8.85
J 8905-01	Prop. Shaft Gauge	31	6	2½	32.75
J 8907	Control Arm Remover	45	*	¾	6.10
J 8909	Injector Timing Pin	*	85	¼	4.65
J 8910	Piston Ring Comp. (3½")	9	*	2¾	2.90
J 8911	Test Ga. (0-10,000#)	*	*	1½	31.25
J 8912	Injector Vise	*	85	2½	9.95
J 8913	Oil Seal Installer	36	*	½	3.25
J 8914	Brg. Cup Installer	47	*	2	5.35
J 8915	Brake Adj. Tool	48	*	¼	5.15
J 8916	Bearing Remover	38	*	6	45.85
J 8917	Control Arm Remover	47	*	2½	14.30
J 8918	Bearing Remover	17	*	1¼	20.50
J 8919	Pinion Set. Gauge	36	*	7	9.35
J 8923	Hood Spring Remover	51	*	1½	7.50
J 8924	Hollow Shaft Puller	*	91	4¼	13.75
J 8925	Differential Puller	*	*	2¾	8.20
J 8927	Stud Installer	6	*	½	6.05
J 8928	Valve Train Gauge	6	*	¼	4.75
J 8929-01	Spring Compressor	6	*	½	16.10
J 8932-01	Fuel Line Wrench	*	73, 85	¼	4.90
J 8933	Bev. Gear Nut Set	*	42	7½	59.75
J 8934	Stud Remover	6	*	¾	10.40
J 8937	Ball Seat Remover	43	*	1	3.25
J 8938	Guide Pin Set	25	*	¼	2.00
J 8940	Injector Tester	*	85	8	173.50
J 8942	Align. Blocks	53	*	¼	2.50
J 8943	Spot Weld Cutter	51	20	¾	5.70
J 8944	Adapter Plate	*	91, 100	29	35.00
J 8947	Ring Compressor	43	*	¾	9.65
J 8949	Eng. Stand Adapt. Pl.	*	*	20¼	52.00
J 8950	Fuel Tank Wrench	10	*	¾	7.15
J 8952	Wiring Connector	*	98	1	2.95
J 8954	Moulding Clip Tool	51	*	¼	2.95
J 8955	Track Link Gauge	*	*	½	3.35
J 8957	Water Pump Adapt.	*	*	½	10.50
J 8959	Timing Gauge	*	*	¾	6.35
J 8960	Needle Brg. Installer	*	22	4	10.10
J 8961	Seal Installer	*	23	2	7.80
J 8962	Brg. Inst. & Remover	*	23	10	24.50
J 8963	Bearing Remover	*	23	5	46.95
J 8964	Seal Installer	*	23	1	4.50
J 8965	Counter Shaft Inst.	25	*	1	2.65
J 8966	Wiper Arm Remover	53	*	¼	2.95
J 8967	Blade Set (Set of 6)	52	20	¼	5.25
J 8968	Drive Gear Installer	*	75	1	9.90
J 8972	Bush. Burn. Set	*	75	4¼	24.95
J 8973-03	Prop. Shaft Align. Set.	31	*	7	56.20
J 8974	Eng. Support Hooks	3	*	3	12.50
J 8976	Wire (.30 MM)	*	85	¼	.50
J 8977	Power Train Fixture	17, 25	*	20¼	44.00
J 8978	Piston Pin Remover	*	*	¼	1.40
J 8979	Piston Pin Remover	*	*	¼	$ 1.45
J 8980	Speedo Gear Installer	25	*	½	4.10
J 8984	Gov. Weight Spacer	*	87	¼	1.00
J 8985	Brg. Rem. & Installer	*	87	¼	3.75
J 8987	Pitman Arm Wrench	*	*	1	9.75
J 8988	Trans. Nut Wrench	*	*	¼	3.25
J 8990-01	Ball Joint Puller	44	*	3	28.95
J 8992	Linkage Fixture	41	*	¼	2.00
J 8993	Spanner Wrench Set	*	92	19	97.50
J 8995	Nozzle Remover	*	67	1	5.85
J 8999-01	Suspen. Serv. Set	45	*	6½	47.30
J 9003	Puller Legs (3")	60	*	4½	3.25
J 9005-1	5-Ton Ram	*	23	6½	8.50
J 9005-2	2-Finger Yoke	*	23	2¾	3.25
J 9006	Puller Legs (6")	60	23	2½	4.15
J 9007	Puller Adapter	*	*	¾	1.00
J 9010	Hydraulic Ram Assy.	60	*	3½	25.80
J 9010-4	4" Extension	*	*	¾	1.00
J 9100	Monox. Blow (⅓ H.P.)	60	*	74	219.00
J 9101	Monox. Blow. (⅓ H.P.)	60	*	80	223.50
J 9102	Monox. Blow. (½ H.P.)	60	*	85	252.00
J 9103	Monox. Blow. (½ H.P.)	60	*	87	249.00
J 9104	Monox. Blow. (¾ H.P.)	60	*	89	286.50
J 9105	Monox. Blow. (¾ H.P.)	60	*	89	283.50
J 9106	Monox. Blow. (1 H.P.)	60	*	94	336.00
J 9107	Monox. Blow. (1 H.P.)	60	*	74	304.65
J 9108	Monox. Blow. (2 H.P.)	60	*	118	514.65
J 9109	Monox. Blow. (2 H.P.)	60	*	175	449.35
J 9110	Monox. Blow. (3 H.P.)	60	*	250	577.35
J 9111	Monox. Blow. (3 H.P.)	60	*	250	506.65
J 9112	Monox. Blow. (5 H.P.)	60	*	250	613.35
J 9113-01	Tor. Wr. Adapt. (½")	58	77	¼	.95
J 9115	Tor. Wr. Adapt. (7/16")	*	79	½	4.45
J 9116-01	Nozzle Gauge (.0675")	*	77	¼	6.05
J 9117	Gauge (.126")	*	77	¼	6.05
J 9118	Gauge (.169")	*	77	¼	6.05
J 9119	Gauge (.254")	*	77	¼	6.05
J 9121	Gauge (.285")	*	77	¼	6.05
J 9122	Gauge (.112")	*	77	¼	6.05
J 9123	Gauge (.320")	*	77	¼	6.05
J 9124	Gauge (.210")	*	78	¼	6.05
J 9125	Gauge (.086")	*	*	¼	6.05
J 9126	Expander Ring	*	78	¼	3.85
J 9127	Disassembly Tool	*	78	¼	3.75
J 9128	Disassembly Ring	*	78	1¾	10.95
J 9129	Wheel Assy. Tool	*	78	½	4.30
J 9131	Spacer Block	*	78	2	12.00
J 9132	Oil Flinger Remover	*	78	1	11.45
J 9133	Flinger Assy. Gauge	*	78	1	6.50
J 9134	Ring Compressor	*	78	½	3.85
J 9135	Support Block	*	78	2	3.55
J 9136-01	Snap Ring Pliers	*	*	¼	10.75
J 9138	Snap Ring Pliers	*	78	½	9.60
J 9148	Ret. Spring Installer	50	*	¼	4.05
J 9152	Seal Installer	43	*	½	1.95
J 9153	Feeler (.025")	25	*	¼	.55
J 9154	Bushing Remover	25	*	1	3.05
J 9155	Bushing Installer	25	*	1	3.75
J 9156	Bearing Remover	17	*	¾	12.40
J 9157	Clearance Gauge	25	*	6½	21.50
J 9160	Trans. Gauge	*	*	¼	1.55
J 9161-02	Roch. Carb. Gauge	13	*	¼	3.15
J 9162	Crowfoot Wrench (11/16"-⅜" Dr.)	*	85, 98	¼	2.10

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 9163	Seal Installer	*	*	2¼	$ 8.95
J 9164	Trans. Bushing Inst.	25	*	6	13.50
J 9167	Trans. End-Play Gauge	25	*	1½	13.50
J 9172	Pitman Arm Puller	40, 44	*	3	15.40
J 9177	Spacer Set	60	*	5¾	15.00
J 9183	Converter Hold. Tool	17	*	2½	7.50
J 9184	Volt Reg. Gauge Set	14	*	¼	10.30
J 9187	Tor. Wr. (0-300 Ft. Lb.)	*	98	14	91.70
J 9189	Eng. Stand Adapt. Pl.	60	*	40¼	59.05
J 9190-02	Roch. Carb. Set	13	*	¼	3.45
J 9191	Roch. Carb. Set	13	*	¼	3.25
J 9192-02	Roch. Carb. Set	13	*	¼	2.70
J 9193	Slide Hammer Assy.	*	23, 98	3	5.95
J 9194	Axle Seal Installer	38	*	2	3.35
J 9195	Spring Compressor	*	*	2¾	30.00
J 9196	Bearing Installer	*	87	1	8.50
J 9199	Pump Housing Guide	25	*	4	28.00
J 9200-01	Gas & Temp. Tester	58	*	¼	6.00
J 9204	Brg. Installer Set	*	*	12¾	**
J 9205	Brg. Brooch Set	*	*	8	**
J 9206	Seal Rem. (Turbine)	*	*	4	**
J 9207	Seal Ream. (Blower)	*	*	3¼	**
J 9208	Shaft Pilot	*	*	½	**
J 9209	End-Play Spacer	*	*	1	**
J 9211	Bushing Installer	25	*	½	3.25
J 9213	A/C Nut Wrench	55	*	¼	4.80
J 9214	Hinge Rem. & Inst.	52	*	1	6.75
J 9215	Antenna Nut Wrench	52	*	¼	3.80
J 9216	5-Ton Hydraulic Puller	58	*	5	21.05
J 9217	Pit. Bush. Installer	40	*	½	4.15
J 9218	Brg. Cup Installer	43	*	½	6.25
J 9222	Carb. Ga. Name Tags	*	*	¼	2.50
J 9225	Pit. Seal Installer	40	25	1	3.25
J 9226	Bushing Remover	40	25	1	4.75
J 9228	Air Gap Gauges	55	*	¼	1.70
J 9229	Bushing Installer	25	*	¾	3.55
J 9230	Gear Shift Align. Ga.	17	*	¼	2.50
J 9231	Cas. Cam Wr. (1⅜″)	45	*	¾	5.50
J 9232	Nozzle Gauge	*	78	1	6.05
J 9233	Crank Seal Remover	9	*	2	18.50
J 9234	Conv. Assy. Remover	*	42	3½	10.80
J 9236	Cam Brg. Remover	*	*	8¼	16.50
J 9237	Cyl. Lin. Remover	*	*	5¼	22.65
J 9238	Cyl. Lin. Remover	*	*	2½	35.70
J 9239	Valve Seat Installer	*	*	½	8.45
J 9241	Valve Seat Installer	*	*	½	8.65
J 9243	Oil Seal Installer	*	*	2	16.50
J 9244	Oil Seal Installer	*	*	4¼	15.60
J 9245	Handle Set	*	*	10½	14.75
J 9248	T.V. Lever Bend. Tool	*	*	½	4.85
J 9249	Valve Guide Installer	*	*	½	6.20
J 9251	Brg. Seal Installer	*	23	3	9.50
J 9252	Carburetor Gauge	*	*	¼	1.95
J 9256	Crank Seal Remover	9	*	2	18.50
J 9257	T.V. Lever Link. Gauge	26	*	¼	3.00
J 9265	Valve Guide Remover	6	*	3¼	21.75
J 9267	Valve Seat Remover	*	*	1⅝	31.40
J 9269	Throttle Lever Gauge	*	*	¼	4.25
J 9270	Throttle Lever Gauge	*	*	¼	2.35
J 9271	Nose Angle Gauge	*	*	8½	25.00
J 9272	Cyl. Lever Clamp	*	67	4½	3.75
J 9273	Pressure Test Kit	*	*	23	105.40
J 9274	Snap Ring Pliers	*	*	1¾	13.90

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 9276-01	Torque Service Set	*	*	9¼	$172.25
J 9276-1	Brg. Cup Installer	*	*	1½	9.65
J 9276-2	Brg. Cup Installer	*	*	1½	7.85
J 9277	Comp. Fl. Adapt. Set	31	*	¼	4.05
J 9280	Suspen. Grease Gun	50	*	1¾	13.85
J 9281	Steer. Grease Gun	44	*	¾	13.85
J 9282	Bearing Thrust Washer Remover	*	78	¼	3.60
J 9283	Swench Wrench	*	*	11	165.00
J 9284	Swench Wrench	*	*	23	245.00
J 9285	Swench Wrench	*	*	78	795.00
J 9286	Body Seal Remover	*	*	¾	5.55
J 9287	Valve Seal Installer	*	*	⅞	3.30
J 9288	Piston Seal Installer	*	*	⅜	2.95
J 9289	Adapter Assembly	17	*	1	8.10
J 9290	Valve Lifter Remover	*	49	1	15.75
J 9291	Torque Mult. Wrench	*	92, 98	13	125.00
J 9293	Carb. Chain Gauge	13	*	¼	2.00
J 9296	Grinder Adapt. Set	*	*	4½	36.35
J 9297	Bushing Driver Set	*	67	5	13.50
J 9298	Guide Pin Set	26	*	¼	2.00
J 9300	Spanner Wrench	*	92	2¾	50.00
J 9301	Spanner Wrench	*	92	3	50.00
J 9302	Adapter (7/16″x14″)	*	*	⅝	5.00
J 9303	Water Pump Imp. Inst.	*	75	1	4.25
J 9304	Cyl. Lin. Remover	*	*	2½	21.75
J 9307	Valve Seat Remover	*	*	1¼	26.25
J 9311	Strom. Carb. Gauge	13	*	¼	4.05
J 9313	Spring Cent. Tool	26	*	¾	6.65
J 9314	Turb. Hold. Fixture	*	78	7	22.95
J 9316	Alignment Blocks	53	20	½	6.40
J 9317	Valve Guide Inst. Set	*	*	10	187.90
J 9317-1	Body	*	*	1½	22.05
J 9317-2	Pilot (5/16″)	*	*	¼	15.95
J 9317-3	Pilot (11/32″)	*	*	¼	15.95
J 9317-4	Pilot (3/8″)	*	*	¼	15.95
J 9317-5	Pilot (7/16″)	*	*	¼	15.95
J 9317-6	Pilot (9/16″)	*	*	½	15.95
J 8317-7	Spacer	*	*	¼	7.90
J 9317-9	Spacer	*	*	¼	7.90
J 9317-11	Spacer	*	*	¼	7.90
J 9317-12	Spacer	*	*	¼	7.90
J 9317-14	Spacer	*	*	¼	7.90
J 9317-16	Spacer	*	*	¼	7.90
J 9317-17	Spacer	*	*	¼	7.90
J 9317-18	Spacer	*	*	¼	7.90
J 9317-19	Spacer	*	*	¼	7.90
J 9317-20	Spacer	*	*	¼	7.90
J 9317-21	Spacer	*	*	¼	7.90
J 9317-22	Spacer	*	*	¼	7.90
J 9317-23	Spacer	*	*	¼	7.90
J 9317-25	Spacer	*	*	¼	7.90
J 9317-26	Spacer	*	*	¼	7.90
J 9317-27	Spacer	*	*	¼	5.00
J 9317-29	Application Chart	*	*	¼	3.50
J 9317-36	Exh. Val. Guide Sl. Adapt.	*	*	¼	3.50
J 9317-37	Int. Val. Guide Sl. Adapt.	*	*	5	11.30
J 9318	Piston Pin Remover	*	*	4¼	21.90
J 9325	Ridge Reamer	*	*	¼	2.80
J 9326	Carb. Ga. Conver. Kit	*	*	⅝	**
J 9327	Impeller Remover	*	52	7½	27.25
J 9333	Spanner Wrench	*	52	¼	6.70
J 9334-01	Seal Guide				

*Not Illustrated **Special Order Only—Not Stocked—Quote on Request

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 9335	Seal & Staking Tool	*	52	2½	$ 37.30
J 9336	Spring Compressor	*	53	½	6.85
J 9340	Pulley & Damp. Rem.	*	*	5	20.45
J 9344-01	Valve Guide Reamer	*	49	2	34.20
J 9345-01	Valve Guide Reamer	*	49	2	34.75
J 9346-01	Valve Guide Reamer	*	49	1¾	30.80
J 9347	Oil Seal Protector	36	*	¼	5.25
J 9348	Oil Seal Installer	36	*	½	2.85
J 9349	Brg. Cup Remover	36	*	¾	7.10
J 9350	Brg. Cup Remover	36	*	¾	7.50
J 9351	Brg. Cup Remover	36	*	¾	6.10
J 9352	Brg. Cup Remover	36	*	1½	6.10
J 9353	Cylinder Gauge Set	*	67	18	342.70
J 9354	Bearing Remover	*	*	1¾	6.45
J 9355	Prop. Shaft Seal Gauge	*	*	¼	3.25
J 9356	Bearing Replacer	*	*	1	4.05
J 9357	Bearing Replacer	*	*	½	3.30
J 9358	Bearing Remover	*	*	1½	8.20
J 9359-01	Bearing Remover	*	*	¼	7.25
J 9360	Seal Replacer	*	*	¼	2.80
J 9361	Seal Installer	*	*	3	5.70
J 9362	End-Play Check. Ga.	*	*	2¾	17.30
J 9363	Wrench	*	53	¼	6.70
J 9364	Support Plate	*	53	5	14.30
J 9365	Slide Hammer	*	*	2	2.45
J 9367	Balance Weight Set	26	*	¼	6.35
J 9369	Piston Inserter	*	51	1¾	12.25
J 9370	Ring Compressor	*	51	1¼	8.95
J 9371	Piston Inserter	*	51	1¾	7.40
J 9375	Float Level Gauge	11	*	¼	1.85
J 9376	Comp. Flange Inst.	31	*	¾	8.95
J 9378	Support Ring	*	53	¼	3.85
J 9379-01	Spring Compressor	*	53	½	2.80
J 9380	Gear Installer	*	*	2½	13.65
J 9381	Gear Installer	*	*	2	13.00
J 9382	Gear Installer	*	*	2½	10.50
J 9383	Aligning Arbor	*	43	2¼	7.25
J 9384-02	Carb. Chain Gauge	13	*	¼	5.30
J 9385-01	Bush. Guide Set	*	*	2½	7.50
J 9388	Spark Plug Adapt. (14 MM.)	3	49	½	1.00
J 9389	Engine Stand	*	67, 100	800	825.00
J 9392	Seal Rem. & Inst.	55	*	1½	6.25
J 9393	Seal Rem. & Inst.	55	*	½	3.75
J 9395	Pulley Adapter	55	*	½	3.90
J 9396	Holding Fixture	55	*	4¼	26.50
J 9397	Compr. Fixture	55	*	5	31.20
J 9398	Pulley Brg. Remover	55	*	½	4.85
J 9399	Socket Wrench (⅝″)	55, 58	*	¼	1.95
J 9401	Hub & Plate Remover	55	*	½	7.75
J 9402	Parts Tray	55	*	¾	4.00
J 9403	Cl. Hub Hold. Tool	55	*	¾	4.35
J 9404	Ring Compressor	*	*	1¾	13.70
J 9406-01	Carb. Chain Gauge	13	*	¼	4.25
J 9407	Roll Pin Remover	*	53	¾	1.85
J 9408	Fan Drive Tool Kit	*	*	17⅜	107.60
J 9410	Prop. Shaft Brg. Inst.	*	*	¾	3.75
J 9411-01	Knock-off Nut	*	*	½	1.95
J 9412	Roll Pin Remover	*	*	⅜	1.35
J 9415	Lock Nut Wrench	*	*	15¾	**
J 9416	Pin. Bearing Inst.	*	*	8½	29.75
J 9417	Brg. Depth Gauge	*	*	4	20.85
J 9418	Spray Tip Reamer	*	*	1½	31.50
J 9419	Seal Installer	*	*	1¼	$ 2.90
J 9420	Seal Remover	*	*	2	4.90
J 9421	Seal Protector	*	*	¼	3.80
J 9422	Bearing Support	*	*	½	1.75
J 9430	Oil Seal Installer	38	*	¼	2.85
J 9431	Oil Seal Installer	38	*	¼	2.85
J 9432	Need. Brg. Installer	55	*	1¼	4.10
J 9433	Seal Installer	55	*	¼	1.00
J 9435	Bush. Inst. Gauge	*	*	¼	4.75
J 9436	Retain. Ring Installer	38	*	2	9.15
J 9439	Axle Brg. Rem. Adapt.	38	*	½	8.65
J 9442	Weatherstrip Tool	53	*	¼	2.95
J 9443	Pulley Puller Screw	55	*	½	4.70
J 9447	Ratchet Wrench	58	*	1¾	15.55
J 9451	Oil Seal Installer	36	*	¼	2.90
J 9458	Comp. Fl. Inst. Adapt.	31	*	1	10.15
J 9459	Air Cond. Adapter	55	*	¼	2.25
J 9459-1	Service Valve Pkg.	*	*	¼	.60
J 9462	Spray Tip Gauge	*	*	¼	9.10
J 9464	Carbon Rem. Tip	*	*	¼	2.75
J 9465	Quill Sh. Seal Pro.	*	*	½	13.50
J 9466	Spanner Wrench	*	*	⅝	5.50
J 9477-01	Adapter	48	*	1	4.75
J 9478	Brake Band Pliers	48	*	¼	6.50
J 9479	Oil Seal Installer	*	*	2¾	23.50
J 9480	Drive Plate Installer	55	*	¼	7.00
J 9481	Pulley Brg. Installer	55	*	1¾	12.85
J 9483	Reaming Fixture	*	*	26½	325.00
J 9485	Brake Adj. Tool	48	*	¼	3.50
J 9488	Oil Seal Installer	*	*	1	22.90
J 9493	Adapt. Set (Ermeto)	*	*	½	16.95
J 9494	Cyl. Head Stud Set	*	*	¾	15.75
J 9495	Fixture	*	*	1	6.35
J 9496	Impeller Remover	*	*	½	2.45
J 9497	Remover	*	*	¼	2.10
J 9498	Installer	*	*	2¼	14.75
J 9499	Cleaning Brush	*	*	¼	2.50
J 9500	Impeller Installer	*	*	¼	4.15
J 9502-01	Bush. Rem. & Replacer	45	*	¾	11.55
J 9502-3	"C" Washer	45	*	¼	2.05
J 9504	Spanner Wrench	49	*	8¼	14.00
J 9505	Spanner Wrench	55	*	¼	4.00
J 9506	Trans. Hold. Fixture	20	*	3¼	11.00
J 9508	A/C Hose Remover	55	*	¾	4.50
J 9509-01	Throttle Gauge	*	*	¼	3.20
J 9510	Piston Pin Remover	9	*	3½	18.95
J 9513	Bush. Remover & Instal.	45	*	1¼	8.75
J 9514	Control Arm Spacer	45	*	¼	1.50
J 9516	Dust Shield Replacer	44	*	3	5.85
J 9517	Carter Spring Installer	50	*	¼	3.60
J 9519-01	Ball Joint Remover	45	*	4½	69.25
J 9519-7	L. Contr. Arm Stud Rem.	*	*	1¼	6.90
J 9519-8	Ball Stud Drive Screw	*	*	1	6.60
J 9519-10	Ball Stud Driver Body	*	*	7½	19.70
J 9519-16	Ball Joint Installer	45	*	½	4.75
J 9519-17	Ball Joint Rem. Adapt.	45	*	½	4.30
J 9521	Support Block	55	*	½	2.65
J 9522	Prop. Shaft Tool Set	31	*	10½	47.50
J 9525	Oil Seal Installer	*	*	3	14.50
J 9527	Pressure Test Set	55	*	¼	4.75
J 9528	Prop. Shaft Brg. Rem.	32	*	4¾	45.00
J 9530	Valve-Guide Installer	*	*	2	5.90
J 9533	Counterbore Set	*	*	15¾	225.00

*Not Illustrated **Special Order Only—Not Stocked—Quote on Request

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 9534-01	Pilot Brg. Remover....	14	*	¼	$ 4.45
J 9535	Pilot Brg. Installer....	14	*	1¾	9.45
J 9537-02	Side Brg. Installer....	38	*	1	7.55
J 9538	Pinion Assy. Tool	20	*	¼	1.50
J 9539	Slide Hammer Adapt. ..	20	*	¼	2.75
J 9540	Brake Seal Installer...	49	*	½	2.95
J 9541	Axle Seal Installer.....	38	*	¼	2.90
J 9543	Vacuum Mod. Wrench..	20	*	¼	2.80
J 9544	Dial Injector	58	*	¼	18.75
J 9546	Cl. Drum Bush. Rem. ..	20	*	1½	5.05
J 9549	Converter Hold. Strap..	20	*	¾	2.00
J 9550-02	Carb. Chain Gauge....	13	*	¼	6.40
J 9552	Coil Spring Compr.....	47, 50	*	1	11.05
J 9553	"O" Ring Remover.....	55	*	¼	.95
J 9554	Torsion Bar Remover..	52	*	2	5.25
J 9555	Oil Seal Installer.....	*	*	½	6.80
J 9557	Bush. Rem. & Inst.....	20	*	1	4.30
J 9559	Hood Spring Remover..	52	*	2	6.00
J 9560	Pinion Assembly Tool..	20	*	¼	1.50
J 9563	Countershaft Assy. Tool	18	*	¾	3.50
J 9564	Feeler Tension Gauge..	56	*	½	19.50
J 9565	Pitman Arm Puller	41	*	2½	17.50
J 9568	Con. Arm Bolt Hold....	46	*	½	2.50
J 9571	Height Gauge	49	*	¼	.75
J 9573	Countershaft Tool	18	*	1¼	3.50
J 9574	Linkage Gauge Block..	18	*	¼	1.75
J 9575	Bush. Rem. & Replacer.	18	*	1	4.00
J 9576	Assy. & Disassy. Fixt...	49	*	14	27.00
J 9576-1	Compr. Fixture	49	*	6	13.00
J 9577-01	Carb. Chain Gauge....	13	*	¼	3.25
J 9578-01	Speedo Gear Rem. ...	18	*	2	8.55
J 9580	Carb. Chain Gauge....	13	*	¼	2.75
J 9581	Bush. & Seal Installer.	*	*	2	13.95
J 9583	Hub Locating Gauge...	10	*	¼	3.25
J 9584	Bush. Rem. & Replacer.	46	*	1¼	10.25
J 9585-01	Carb. Chain Gauge....	13	*	¼	3.15
J 9586-01	Carb. Chain Gauge....	13	*	¼	2.75
J 9590	Exh. Valve Wrench	6	*	1¼	8.25
J 9591	Blower Hold. Fixture...	*	*	6¼	32.45
J 9595	Inj. Timing Gauge.....	*	*	¼	4.65
J 9596	Exh. Valve Cov. Rem...	6	*	¼	1.15
J 9597	Torsion. Bar Remover..	52	*	1¼	6.50
J 9598	Carb. Gauge Set.....	13	*	¼	4.45
J 9600-2	Diode Installer	14	*	½	3.35
J 9604	Seat Track Load. Tool..	52	*	¼	2.25
J 9608	Impeller Posit. Gauge..	10	*	¼	4.00
J 9614	Oil Filter Rem. Tool...	10	*	1	4.15
J 9615	Oil Seal Installer	28	*	½	2.95
J 9617	Oil Seal Installer	28	*	½	2.95
J 9618	Bush. Rem. & Inst.....	28	*	¾	4.35
J 9620	Seal Installer	28	*	¾	14.50
J 9621	Piston & Seal Inst.....	28	*	¾	9.90
J 9622	Pressure Test Fit.....	28	*	¼	1.50
J 9625	Pressure Test Set	56	*	¼	5.65
J 9627	Brush Retainer	14	*	¼	1.60
J 9628	Support Block	14	*	1	5.55
J 9629	Bearing Installer	14	*	¾	4.80
J 9630	Needle Brg. Remover..	14	*	¾	3.85
J 9639	Torque Wrench Ext. ...	28, 58	*	¼	3.50
J 9640	Bush. Rem. & Inst.	28	*	¾	3.55
J 9643	Carb. Gauge Set.....	13	*	¼	5.35
J 9643-1	Float Support	11	*	¼	2.35
J 9644	Pin Remover	46	*	¼	7.75

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 9646	Belt. Adj. Tool.....	56	*	¾	$ 4.35
J 9648	Locating Gauge	10	*	¼	4.20
J 9656	Ball Stud Remover....	46	*	¼	3.55
J 9657	Wir. Harness Remover.	14	*	⅛	2.95
J 9661	Feeler Tension Gauge..	56	*	¼	17.00
J 9665	Guide Stud Set	*	*	¾	6.95
J 9666	Spring Tester	*	*	9½	33.35
J 9669	Lube Gun & Adapt.	46	*	4	13.95
J 9670	Lube Gun & Adapt.	46	*	4	13.95
J 9671	Oil Seal. Installer.....	18, 26	*	¾	6.45
J 9708	Feeler Gauge Set.....	*	*	¼	4.85
J 9709	G-P-M Gauge (Volks.)..	60	*	6	33.25
J 9717-1	Diode Remover	14	*	¼	4.25
J 9717-2	Diode Support	14	*	¼	1.90
J 9718	Brg. Inst. & Spacer ...	10	*	1	6.25
J 9719-01	Seal Protector	49	*	¼	2.45
J 9727	Oil Seal Installer.....	*	*	2	33.50
J 9728	Chamfering Tool	*	*	¼	10.50
J 9729	Val. Guide Inst. (45°)..	*	*	¾	5.50
J 9730	Valve Guide Installer...	*	*	¾	9.25
J 9732	Seal Installer	41	*	1¼	3.30
J 9737-01	Flywheel Check Ga. ...	*	*	2½	92.30
J 9738	Seal Installer	41	*	1	3.25
J 9739	Brg. & Lk. Ring Inst. ..	38	*	3¾	7.95
J 9740	Oil Seal Installer.....	38	*	1	3.50
J 9742	Brg. Cup Installer.....	38	*	1½	8.25
J 9743	Bearing Support	36	*	7½	13.30
J 9744	Brg. Support Remover .	36	*	3	23.15
J 9745	Brg. Cup Installer.....	36	*	2	9.10
J 9746	Pin Brg. Remover	36	*	5½	19.75
J 9748	Dial Indicator Post....	*	*	¼	3.90
J 9756	Valve Guide Installer ..	*	*	¾	6.25
J 9757	Field Modif. Kit.....	*	*	1	38.35
J 9764	Chamfer. Tool (45°)...	*	*	¼	10.50
J 9765	Outer Race Remover...	36	*	¾	5.50
J 9767	Spanner Wrench	*	*	5¾	27.50
J 9769	Crank. Rear Seal Exp. .	*	*	1½	22.95
J 9771	Pin. Brg. Remover.....	36	*	1¾	14.10
J 9772	Pin. Brg. Installer.....	36	*	2	8.35
J 9773	Yoke Brg. Installer	39	*	½	5.70
J 9774	Seal Installer	39	*	3¾	2.90
J 9776	Weatherstrip Remover .	53	*	¼	2.75
J 9777	A/C Align. Fixture	*	*	3¾	46.45
J 9782-1	Jumper Lead	14	*	¼	.50
J 9782-3	4-Wire Connector	14	*	¼	2.45
J 9783	Oil Seal Installer.....	*	*	1½	19.75
J 9787	Injector Tester	*	*	49	269.50
J 9789	Univ. Carb. Ga. Set....	*	*	3	22.50
J 9790	Oil Seal Installer.....	*	*	¼	5.25
J 9791	Oil Seal Installer.....	*	*	¼	4.75
J 10162	Palm-Grip Ratchet	*	*	½	2.95
J 10167-1	Clut. S-Dvr. (5/32").....	26, 58	*	¼	1.70
J 10167-2	Clut. S-Dvr. (4½"-3/16").	*	*	⅛	1.70
J 10174-01	Main Jet Socket	11	54	¼	4.75
J 10175	Economizer Socket	11	54	¼	1.30
J 10176	Idle Adj. Wrench	*	54	¼	.80
J 10177	Float Gauge	*	54	¼	1.10
J 10178	Float Gauge	*	54	¼	1.10
J 10179	Float Gauge	*	54	¼	1.10
J 10180	Float Gauge (13/64").....	11	*	¼	2.60
J 10181	Float Gauge (¾").....	*	54	¼	2.60
J 10182	Economizer Socket	*	54	¼	3.80
J 10183	Valve Socket	*	54	¼	3.80

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 10184	Valve Socket	*	54	¼	$ 1.20
J 10185	Valve Socket	11	54	¼	3.80
J 10186	Plug Socket	*	54	¼	2.25
J 10187	Governor Gauge	*	54	¼	1.00
J 10189	Guide Pins	*	55	¼	2.45
J 10191	Hex Driver (⅜″)	*	*	¼	1.65
J 10192	Float Level Gauge	11	55	¼	3.25
J 10193	Float Level Gauge	11	55	¾	4.25
J 10194	Float Level Gauge	11	55	¼	4.50
J 10195	Staking Tool Set	*	55	½	12.75
J 10197-01	Float Gauge Set	*	55	2	17.80
J 10198	Hook Ring	*	55	¼	.05
J 10199	Metal Box	*	55	2	1.90
J 10200-03	Carb. Tool Kit	11	55	4	60.65
J 10202	Float Level Gauge	*	*	¼	1.50
J 10205-03	Carb. Tool Kit	11	*	¾	25.85
J 10206	Governor Control Assy. & Adjust. Tool Set	*	*	¼	5.80
J 10208	Carb. Gauge Set	13	*	⅛	4.40
J 10220	Distrib. Adj. Tool	*	56	½	8.00
J 10221	Distrib. Burn. Tool	*	56	1	7.50
J 10222	Distrib. Burn. Tool	*	56	2	7.40
J 10223	Distrib. Bush. Inst.	*	56	1	3.10
J 10224-01	Distrib. Bush. Driver	*	56	2	8.90
J 10228	Distrib. Clamp Sleeve	*	*	½	4.75
J 10231	Float Level Gauge	11	*	¼	2.95
J 10234	Spark Valve Remover	11	*	¼	3.75
J 10235	Vac. Piston Puller	11	*	¼	7.00
J 10236-01	Vac. Pist. Installer	11	*	¼	1.70
J 10237-02	Vac. Pist. Stak. Tool	11	*	¼	4.10
J 10238	Float Level Gauge	11	*	¼	.75
J 10240	Staking Tool	11	*	¼	8.25
J 10241	27/64″ Float Level Gauge	11	*	¼	.50
J 10242-01	Vacuum Piston Remover	*	*	¼	5.85
J 10244	Carb. Gauge Set	13	*	⅛	4.05
J 10250-01	Distrib. Tool Set	14	56	4	34.90
J 12000	Electronic Leak Detector	*	*	8¼	199.75
J 12078	Dial Thermometer	*	*	½	11.75
J 12080	Tube Flaring Tool	*	*	2¼	10.25
J 12147	Crimping Tool	*	*	½	4.95
J 12172	#22 Pliers	*	*	½	2.25
J 12213	Leak Detector	*	*	3⅝	9.36
J 12289	Hose Clamp Pliers	*	*	½	2.75
J 21000	Oil Seal Protector	43	*	¼	3.50
J 21001	Oil Seal Installer	43	*	¾	1.75
J 21004	Assy. & Disassy. Fixt.	11	*	3	4.50
J 21005	Oil Seal Installer	36	*	¾	3.00
J 21006	Ring Compr. (4 3/16″)	9	*	1¼	3.50
J 21007	Center Brg. Installer	32	*	¾	6.35
J 21008	Diode Test Light	14	*	¼	2.75
J 21009	Lock Nut Wrench	32	*	½	5.40
J 21010	Oil Seal Remover	47	*	½	5.35
J 21011	Oil Seal Installer	47	*	1¾	7.30
J 21012-01	Inj. Adapter Assy.	*	*	3	52.50
J 21013	Bushing Installer	20	*	½	3.55
J 21014	Bushing Installer	21	*	1¾	4.75
J 21015	Bushing Installer	21	*	¼	6.75
J 21016	Bushing Installer	21	*	½	4.65
J 21017	Bush. Inst. & Rem.	21	*	1¾	7.15
J 21018	Bushing Installer	21	*	¾	4.80
J 21019	Bushing Installer	21	*	¼	3.40
J 21020	Bearing Installer	39	*	2	6.75
J 21022	Bearing Installer	39	*	2¼	6.95
J 21023	Pin Brg. Remover	39	*	1¾	$ 8.95
J 21024	Oil Seal Installer	39	*	½	5.55
J 21025-01	Oil Seal Installer	26	*	3¼	7.10
J 21026	Bushing Installer	26	*	½	3.15
J 21027	Bush. Rem. & Inst.	39	*	1	12.50
J 21028	Speedo Gear Installer	26	*	½	3.90
J 21032	Bushing Installer	21	*	2¼	8.25
J 21033	Seal Installer	26	*	¾	5.75
J 21034	Quick-Coupler Clamp	26	*	¼	2.25
J 21037	Outer Race Installer	36	*	1¼	5.50
J 21040	Float Level Gauge	11	*	¼	1.00
J 21041	Float Level Gauge	11	*	¼	.85
J 21042	Muffler Wrap Installer	*	*	¼	1.00
J 21044	Comp. Flan. Holder	32	*	1	5.50
J 21047	Torque Wrench	3	*	¾	4.50
J 21051	Oil Seal Installer	*	*	1	7.30
J 21052	Harmon. Bal. Remover	9	*	2¼	26.50
J 21053	Delcotron Jum. Line	15	*	¼	1.00
J 21054	Cam Bush. Remover	3	*	7	9.85
J 21054-1	Handle	3	*	2½	6.00
J 21056	Carb. Chain Gauge	13	*	¼	4.75
J 21057	Brg. Seal Installer	36	*	1¾	4.25
J 21058	Bush. Rem. & Inst.	46	*	5	47.95
J 21059	Brg. Cup Installer	*	*	1½	9.00
J 21060	Brg. Cup Installer	*	*	¾	5.35
J 21061	Bush. Rem. & Inst.	*	*	4½	15.75
J 21062	Bushing Reamer	*	*	6	24.75
J 21066	Brg. Cup Installer	*	*	2½	9.80
J 21067	Brg. Cup Installer	*	*	1¾	8.75
J 21068	Gov. Brg. Installer	*	*	¾	5.95
J 21072	Oil Seal Protector	36	*	¼	1.75
J 21073	Valve Rem. & Inst.	6	*	½	4.75
J 21079	Flare Tool Set	*	*	12	82.50
J 21080	Bushing Remover	21	*	½	7.05
J 21081	Axle Flange Installer	*	*	3	12.05
J 21085	Spray Tip Blow. Gauge	*	*	6	145.90
J 21089	Inj. Body Reamer	*	*	½	7.50
J 21091	Elec. Terminal Rem.	52	*	¼	3.25
J 21092	Fabric Knife	58	*	½	2.95
J 21093	Wash. Selector Ga.	26	*	1¼	17.50
J 21094	Bushing Installer	26	*	¼	3.45
J 21095	Bushing Installer	26	*	¼	3.45
J 21096	Bushing Installer	26	*	¾	4.20
J 21098	Bushing Installer	26	*	¼	3.95
J 21099	Cam Bush. Rem. & Inst. Set	*	*	25	112.75
J 21099-15	Cam Bush. Rem. & Inst.	*	*	17¾	72.50
J 21099-16	Cam Bush. Rem. & Inst.	*	*	9⅜	34.25
J 21099-17	Adapter	*	*	⅞	6.00
J 21099-19	Adapter Set	*	*	28	13.60
J 21100	Push Rod Adj. Wr. Set	*	*	¼	12.50
J 21102	Seal Installer	*	*	5½	34.50
J 21104	Weatherstrip Remover	53	*	½	2.75
J 21106	Brg. Cup Installer	*	*	3½	11.75
J 21107	Brg. Cup Installer	*	*	2	9.85
J 21108	Brg. Cup Installer	*	*	2¾	11.50
J 21109	Ignit. Sw. Wrench	53	*	¼	5.45
J 21110	Clock Rem. & Inst.	56	*	¼	3.05
J 21111	Band Adj. Tool	28	*	½	3.50
J 21112	Rr. Crank. Oil Seal Inst.	*	*	3	37.50
J 21113	Oil Seal Installer	36	*	1½	5.10
J 21126	Ring Locking Tool	28	*	¼	1.65
J 21128	Pinion Oil Seal Inst.	36	*	½	3.25

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 21129	Ax. Shaft O.S. Installer.	39	*	2½	$ 3.50
J 21135-01	Coupling Remover	32	*	5½	22.75
J 21136	Coupling Installer	32	*	½	6.75
J 21137	Carb. Tag Set	*	*	¼	1.00
J 21138	Carb. Chain Gauge	13	*	¼	4.50
J 21143	Pitman Arm Puller	*	*	3	33.40
J 21144	Sleeve Railcar Trans...	*	*	¾	**
J 21145	Oil Seal Installer.....	9	*	3	10.70
J 21146	Lifting Eyebolt	*	*	3	**
J 21147	Oil Seal Installer.....	3	*	1¾	7.70
J 21150-01	Oil Seal Installer.....	3	*	½	8.50
J 21154	Snap Ring Installer....	15	*	¾	6.55
J 21155	Bearing Remover	15	*	1½	11.90
J 21156	Assembly Tool	15	*	¾	8.55
J 21157	Snap Ring Remover ...	15	*	¼	3.05
J 21158	Piston Ring Comp.....	9	*	1¾	4.25
J 21160	Inner Cup Installer	*	*	4½	12.75
J 21164	Pin Shim Gauge	36	*	4½	8.10
J 21165	Hub Seal Installer.....	*	*	1¾	7.25
J 21166	Acces. Dr. Oil Seal Align.	*	*	3	14.75
J 21167	Engine Stand	61	*	228	335.00
J 21169	Assy. Support Tool....	*	*	2¾	14.50
J 21170-01	Indicator Assembly	*	*	1	33.75
J 21171	Torque Wr. Adapter ...	41	*	¼	1.65
J 21172	Brake Wrench	49	*	¾	9.40
J 21174	Drain Plug Socket.....	3	*	¼	.75
J 21177	Brake Shoe Gauge	49	*	½	8.90
J 21178	Windshield Knife	*	*	¼	3.25
J 21179	Retain. Ring Installer ..	41	*	½	6.75
J 21180	Remover	41	*	1	2.75
J 21181-01	Tilt Spring Installer ...	41	*	½	3.50
J 21183	Height Gauge	49	*	¼	1.00
J 21186	Oil Seal Installer	*	*	3¼	**
J 21187	Oil Seal Installer	*	*	6½	**
J 21189	Reamer (.010″ O.S.)...	*	*	6	24.75
J 21190	Reamer (.020″ O.S.)...	*	*	6¼	24.75
J 21191	Reamer (.010″ O.S.)...	*	*	3½	18.25
J 21192	Reamer (.020″ O.S.)...	*	*	3½	18.25
J 21193	Fan Hub Loc. Gauge....	*	*	¼	3.75
J 21195	Strg. Wheel Puller.....	41	*	1	24.15
J 21196	Shift Linkage Gauge...	18	*	¼	1.55
J 21197	Installer	37	*	2¼	7.35
J 21198	Converter Holding Tool	26	*	1	7.05
J 21199	Conv. Remover	26	*	1	8.25
J 21200	Lapping Plate Set.....	*	*	2	19.75
J 21202	Retain. Installer	11	*	¾	2.85
J 21204	Brake Bleed. Adapter ..	49	*	½	4.75
J 21205-01	Carb. Chain Gauge	13	*	½	6.10
J 21207-01	Carb. Chain Gauge	13	*	¼	4.00
J 21209	Crank Frt. Oil Seal Inst.	*	*	1½	16.65
J 21210	Carb. Ga. Adapt. Kit ...	*	*	¼	1.75
J 21213	Temp. Tester	15	*	4¾	57.95
J 21214	Mould. Clip Tool.....	52	*	½	2.75
J 21215-01	Carb. Gauge Set.....	13	*	¼	3.00
J 21216-01	Carb. Gauge Set.....	13	*	¼	4.75
J 21217	Carb. Gauge Set.....	*	*	¼	3.25
J 21221	Retaining Ring Inst. ...	*	*	¾	12.75
J 21222	Parallel Bar	*	*	5	11.50
J 21223-01	Compr. Wheel Ret. Nut Wrench	*	*	½	8.00
J 21224	Dial Indicator Adapt....	*	*	¾	13.35
J 21225	Holding Fixture	*	*	4	18.75
J 21226	Measuring Fixture	*	*	3¼	45.00

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 21228	Adapter Brackets	*	*	4	$ 21.00
J 21231	Unlocking Tool	49	*	¼	2.95
J 21232	Str. Wheel Puller	41	*	¾	7.25
J 21233	Wrench	53	*	¼	8.80
J 21235	Ft. Coil Spring Compr..	*	*	11	38.50
J 21237	Low Servo Valve Inst...	26	*	¼	3.20
J 21238	Rock. Arm Bush. Serv. Tool Set.....	*	*	7	41.20
J 21239	Pump Pulley Remover..	43	*	1½	16.70
J 21240	End Play Check Ga. ...	46	*	¾	9.50
J 21245-01	Bushing Reamer Tool Set	*	*	2¾	40.10
J 21246	Carb. Chain Ga. Conver. Kit	*	*	¼	2.15
J 21249	Needle Brg. Installer..	26	*	2¾	10.10
J 21252	Carb. Gauge Set	13	*	½	17.50
J 21254	Guide Pin Set	30	*	¼	4.30
J 21255	Torque Wrench Adapt. .	*	2	2	14.50
J 21257	Conv. Align. Tool.....	30	*	4½	14.05
J 21258	Windshield & Light Sw. Nut Wrench	53	*	¼	5.05
J 21259	Trans. Holding Stand ..	30, 61	*	1¼	8.65
J 21260	Variable Resis. (50 Ohm, 25 Watt)..	*	*	¾	12.50
J 21262	Brake Bleeder Adapter.	49	*	1¼	7.40
J 21263	Needle Bearing Remover	26	*	1	2.90
J 21264	Ign. Distrib. Align. Ga. .	15	*	¾	8.10
J 21268	Alt. Belt Adjust. Wr....	15	*	1½	8.65
J 21276	Planet Pin. Pin Assy. Tool	*	*	¼	2.85
J 21277	Crank. Rear O.S. Inst...	*	*	3½	21.50
J 21278	Crank. Rear O.S. Expand.	*	*	¼	7.50
J 21279	Adapter Plate	*	*	12	21.50
J 21280	Valve Guide Remover..	6	*	¼	2.50
J 21281	Valve Guide Installer ..	6	*	½	2.70
J 21282	Valve Guide Reamer...	6	*	½	4.30
J 21283	Valve Guide Reamer...	6	*	½	4.30
J 21285-01	Rear Axle Dr. Pin. O.S. Ins.	37	*	½	3.75
J 21299	Speedometer Tester ...	53	*	16¼	158.00
J 21300	Oil Pan Contour Check. Ga.	*	*	½	1.95
J 21301	Conver. Pump Bush. Inst.	26	*	¾	3.60
J 21302	Conver. Pump Bush. Rem.	26	*	¼	9.80
J 21303	A/C Compr. O.S. Pro...	56	*	¼	2.75
J 21304	Hyd. Gov. Link Set Ga..	*	*	¼	15.35
J 21308	Cyl. Head Fin. Clean. Tl.	3	*	¼	2.65
J 21309	Rear Main Brg. O.S. Inst.	3	*	¾	4.50
J 21313	Water Pump Serv. Tl. Kit.	*	*	2¼	23.75
J 21314	Cyl. Head Guide Stud..	*	*	1	4.75
J 21315	Rear Main Brg. O.S. Inst.	3	*	¾	4.50
J 21316-01	Engine Stand Adapter..	61	*	20¼	36.00
J 21318	Valve Guide Reamer ...	6	*	¼	4.45
J 21322-01	Ring Gear & Case Rem.	37	*	3	7.75
J 21323	Tach. Drive Adapter.	15, 56	*	¼	4.60
J 21328	Bearing Puller	*	*	¼	4.75
J 21347	Turn Sig. & Shift Tube Rem.	41	*	½	2.25
J 21350	Spark Plug Term. Pliers	15, 58	*	½	3.15
J 21351	Hyd. Governor Gauge ..	*	*	¼	9.75
J 21352	Tilt Wheel Cover Inst. .	41, 56	*	½	2.50
J 21356	Master Ring Gauge....	*	*	10¼	125.00
J 21359	Pump Oil Seal Inst.....	26	*	½	3.40
J 21360	Check Valve Seat Inst..	26	*	¼	2.50
J 21361	Check Valve Seat Rem.	26	*	¼	7.50

*Not Illustrated **Special Order Only—Not Stocked—Quote on Request

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 21362	Clutch Inner Seal Pro.	26	*	¼	$ 3.75
J 21363	Clutch Inner Seal Pro.	26	*	1¼	4.25
J 21364	Support Adapter	27	*	¼	2.25
J 21365	Gear Assy. Inst. Adapt.	*	*	¼	2.25
J 21366	Converter Hold. Strap	27	*	¼	3.75
J 21367	Rear Sprag Installer	27	*	1¼	10.15
J 21368	Pump Body & Cov. Align.	27	*	¼	3.85
J 21369	Convert. Leak Test Fix.	27	*	1¾	24.55
J 21370-4	Selective Pin	27	*	¼	5.70
J 21370-5	Gauge Pin	27	*	¼	5.70
J 21370-6	Band Body Arm Assy.	27	*	1⅜	15.95
J 21371	End-Play Checking Fix.	27	*	1½	24.60
J 21374	Nozzle Insert Inst.	*	*	¾	9.50
J 21375	Cran. Front O.S. Inst.	*	*	3¼	14.50
J 21376	Cyl. Sleeve Puller	*	*	8½	22.50
J 21377	Crank. Rr. Seal Ring Ins.	*	*	4¼	19.70
J 21378	Piston Pin Bushing Tool	*	*	4	12.50
J 21379	Piston Pin Brg. Broach	*	*	7	35.00
J 21380	Pist. Pin Bush. Bkg. Pl.	*	*	2½	7.50
J 21381	Tim. Gear Cover Align.	*	*	3½	28.00
J 21382	Tim. Gear Cover Locat.	*	*	1¾	17.50
J 21383	Cylinder Sleeve Driver	*	*	1½	9.95
J 21384	Crank. Rear Seal Inst.	*	*	7½	34.00
J 21385	Cam Bush. Rem. & Inst.	*	*	½	23.15
J 21386	Cam Rod Cap Screw Wr.	*	*	½	2.50
J 21387	Engine Cranking Tool	*	*	10½	27.50
J 21389	Gov. Cam Setting Gauge	*	*	¼	5.65
J 21392	Tim. Advance Adj. Wr.	*	*	¼	5.50
J 21393	Cam Stop Meas. Stop	*	*	¼	11.40
J 21394	Gov. Spring Gap Gauge	*	*	1½	34.60
J 21395	Hyd. Head Compr. Tl.	*	*	¾	6.10
J 21396	Governor Weight Spacer	*	*	⅜	3.30
J 21397	Gov. Drive Gear Socket	*	*	⅛	4.10
J 21398	Deliv. Valve Hold. Tool	*	*	¼	14.80
J 21399	Pump Holding Bracket	*	*	1½	11.90
J 21400	Rod Exten. & Ret. Cam Kit	*	*	¼	34.90
J 21403-02	Holley Carb. Tool Kit	13	*	½	12.80
J 21409	Clutch Outer Seal Pro.	27	*	½	5.75
J 21410	Backup Light Hole Punch	56	*	5	32.45
J 21412	Rr. Deck Lid Tor. Rd. Tl.	52	*	1½	5.65
J 21416	Cam Protection Cap	*	*	⅛	4.15
J 21420	Reverse Clutch Spring Comp.	27	*	⅞	17.45
J 21421-01	Speedo Gear Installer	27	*	4¾	10.05
J 21421-3	Speedo Gear Inst. Adapt.	*	*	2½	4.40
J 21424	Trans. Bush. Serv. Tl. Set	27	*	4½	29.75
J 21426	Rear Oil Seal Installer	27	*	½	3.50
J 21427-01	Speedo Gear Remover	27	*	1	8.20
J 21428	Cam Bush. Rem. & Inst.	*	*	25	109.90
J 21429	Vibrat. Damp. Hub Rem.	*	*	¾	6.75
J 21457	Air Cond. Align. Fixture	*	*	6	82.50
J 21458	Air Cond. Align. Fixture	*	*	6½	82.50
J 21459	.005″ Music Wire	*	*	¼	1.40
J 21460	.0055″ Spray Tip Wire	*	*	¼	1.40
J 21461	.006″ Spray Tip Wire	*	*	¼	1.40
J 21462	.007″ Spray Tip Wire	*	*	¼	1.40
J 21464	Ex. Hous. O.S. Inst.	27	*	½	3.55
J 21465-01	Bushing Service Set	27	*	6	49.35
J 21468	Pinion O.S. Installer	37	*	2¾	5.85
J 21469	Trans. Bush. Rem. & Inst.	27	*	1¾	7.10
J 21470	Speedo Gear Inst.	27	*	3⅞	9.55
J 21471	Inspect-A-Lite Bush. Check.	*	*	5⅞	57.45
J 21472	Brake Bleeder Wrench	49	*	¼	$ 3.50
J 21473-1	Cam Bush. Rem. & Repl. Adap.	3	*	¾	4.10
J 21474	Contr. Arm. Bush. Serv. Set	46	*	8½	35.75
J 21474-1	Rear Contrl. Arm Spacer	46	*	¾	2.40
J 21474-2	Rr. Con. Arm Bush. Rem. & Inst.	46	*	¾	3.75
J 21474-3	Screw Assembly	46	*	½	5.70
J 21474-4	Nut	46	*	¼	3.80
J 21474-5	Receiver	46	*	1½	8.05
J 21474-6	Car. Bush. Rem. & Inst.	46	*	½	3.00
J 21474-8	Control Arm Bush. Rem.	46	*	½	2.65
J 21474-12	Control Arm Spacer	46	*	¼	1.20
J 21474-13	Control Arm Bush. Inst.	46	*	¾	4.75
J 21474-15	Control Arm Bush. Adapt.	*	*	¾	3.45
J 21474-16	Control Arm Bush. Adapt.	46	*	1¼	5.40
J 21474-17	Control Arm Bush. Adapt.	*	*	1	4.90
J 21477	Oil Cooler Pipe Wrench	27	*	½	3.75
J 21478	Slack Tube Manom. Set	*	*	2¼	33.45
J 21479	Brake Bleeder Adapter	49	*	1¼	9.50
J 21480	Connecting Rod Hook	*	*	¾	9.85
J 21481	Conn. Hole Plug Inst.	*	*	1¾	10.75
J 21482	Control Arm Spacer	46	*	1	4.75
J 21484	Ball Stud Seal Mold. Kit	*	*	⅜	7.75
J 21486	Turn. Signal Cover Rem.	41	*	½	8.20
J 21487	Cyl. Hd. Torque Wrench Adapt.	*	*	1	12.10
J 21491	Wh. Brg. & Oil Seal Inst.	39	*	1¾	6.90
J 21493	Pinion Bearing Remover	37	*	4	21.90
J 21495	Servo Cov. Rem. & Repl.	27	*	1	8.50
J 21496	.525″ Guide Stud	*	*	¼	5.85
J 21497	.497″ Guide Stud	*	*	¼	5.85
J 21501	Socket Adapter	15	*	¼	3.95
J 21505	Water Pump Hub Loc. Ga.	10	*	¼	3.25
J 21508	"O" Ring Installer	56	*	¼	3.75
J 21509-01	Gauge Manif. Test Unit	*	*	3	18.75
J 21512	Comfort Control Tester	56	*	1½	21.50
J 21515	Load Indicator	*	*	1½	31.25
J 21518-01	Fuel Tk. Unit Rem. & Inst.	11, 52	*	½	7.95
J 21520	Valve Guide Installer	*	*	1	5.80
J 21521	Brake Bleeder Adapter	49	*	1	7.50
J 21524	Power Piston Rem. & Inst.	49	*	¾	3.75
J 21529	Guide-Matic Analyzer	56, 61	*	1½	19.00
J 21530	Comfort Control Wh. Adj.	56	*	¼	2.75
J 21533	Trans. Hold. Fix. (Syn.)	18, 61	*	12½	24.90
J 21544	Valve Spring Comp.	*	*	¾	7.85
J 21545	Fuel Line Nut Wrench 9/16″	*	*	¼	4.15
J 21546	Oil Seal Rem.	*	*	¼	2.95
J 21547	Mod. Valve Spr. Compr.	27	*	¼	1.80
J 21548	"U" Joint Trun. Seal Inst.	32	*	1	3.90
J 21549	Reveal Mould. Clip Rem.	*	*	¼	2.75
J 21549-01	Reveal. Mould. Clip Rem. Set	*	*	½	6.25
J 21549-02	Window Glass Tool Set	53	*	¼	4.50
J 21549-1	Handle	53	*	¼	1.00
J 21549-2	Blade	53	*	¼	1.75
J 21549-3	Reveal Molding Clip Rem.	53	*	¼	1.75
J 21549-4	Knife Blade	53	*	¼	1.75
J 21550	Frt. Door Hinge Wrench	52	*	½	6.25

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 21551	Pit. Shaft Need. Brg. Rem.	41	*	½	$ 4.95
J 21552	Rack Piston Arbor	41	*	½	5.50
J 21553	Pitman Shaft Seal Inst.	41	*	¼	2.55
J 21554	Adj. Plug Seal Installer	41	*	¼	2.55
J 21556	"U" Joint Trun. Seal Inst.	32	*	¼	3.30
J 21558	Check Valve Installer	27	*	¾	2.75
J 21560	Core Plug Spanner Wrench	*	*	1¼	12.50
J 21565	Water Pump Seal Inst.	*	*	3¼	17.60
J 21567	Pressure Gauge	44	*	3	33.75
J 21568	Thrust Yoke	18	*	1	8.25
J 21569	Piston Ring Exp. (4 7/16")	*	*	½	10.50
J 21570	Piston Ring Exp. (4⅝")	*	*	½	10.50
J 21571	Piston Ring Exp. (4¾")	*	*	½	10.50
J 21572	Piston Ring Exp. (4⅞")	*	*	½	14.00
J 21573	Piston Ring Exp. (5⅛")	*	*	½	13.30
J 21574	Piston Ring Exp. (5½")	*	*	½	13.30
J 21577	Trans. Support Bush. Rem. & Instl.	*	*	1¾	7.60
J 21578	Conn. Rod. Nozzle Rem. & Inst. Set	*	*	21	46.65
J 21579	Axle Shaft Remover	39	*	2¼	5.95
J 21581	Pinion Holding Wrench	37	*	½	11.80
J 21582	Rocker Arm Bush. Inst.	*	*	¾	2.85
J 21583	Water Pump Shaft Nut Wrench	*	*	¾	9.40
J 21584	Crankshaft Gear Puller	*	*	6¾	33.90
J 21585	Valve Guide Remover	*	*	¾	6.40
J 21586	Valve Guide Installer	*	*	1	6.30
J 21587	Cyl. Sleeve Rem. Shoe	*	*	2½	10.70
J 21588	Injector Gasket Retriever	*	*	½	8.15
J 21589	Water Pump Seal Inst.	*	*	2½	6.50
J 21590	Piston Pin Driver	*	*	5½	7.90
J 21591	Sealing Ring Rem. Adapt.	*	*	¾	11.35
J 21592	Camshaft & Injector Pump Gear Rem.	*	*	3	30.40
J 21593	Vibration Dampner Hub Inst.	*	*	6	17:45
J 21594	Valve Guide Reamer	*	*	½	8.20
J 21595	Flywheel Housing Assy. Tool	*	*	2	19.30
J 21596	Flywheel Bearing Driver	*	*	1	13.20
J 21597	Water Pump Seal Inst.	*	*	2½	14.00
J 21598	Oil Pump Bush. Driver	*	*	½	2.65
J 21599	Piston Pin Bush. Rem. & Repl.	*	*	¼	5.65
J 21600	Voltage Regulator Adapt.	15	*	¼	4.40
J 21601	Pow. Brake Retain. Inst.	49	*	¼	3.00
J 21603	Shift Link. Posit. Ga.	18	*	¼	8.50
J 21607	Carb. Chain Gauge Set	13	*	¼	5.50
J 21608	Carb. Chain Gauge	13	*	¼	5.65
J 21610	Block Liner Pressing Sleeves	*	*	1	7.50
J 21611	Stamp Set	52, 58	*	½	2.95
J 21613	Contr. Arm Bush. Serv. Set	46	*	1⅜	12.95
J 21614	Carb. Chain Ga. Set	13	*	¼	4.00
J 21615-01	Carb. Chain Gauge	13	*	¼	2.75
J 21616	Adapter Tip	*	*	¼	20.65
J 21617	Clutch Align. Arbor	18	*	2	$ 7.35
J 21618	Shift Link Posit. Ga.	18	*	¾	6.25
J 21619	Compan. Flan. Rem. Adapt.	37	*	½	3.65
J 21622	Carb. Chain Gauge	13	*	¼	4.25
J 21623	Carb. Chain Gauge	13	*	¼	3.50
J 21624	Carb. Chain Gauge	13	*	¼	4.25
J 21625-01	Carb. Chain Gauge	13	*	½	4.00
J 21627	Chg. Line & Ga. Adapt. Set	*	*	¾	2.85
J 21628	7/16"x20" Ball Stud Rem.	46	*	¼	3.65
J 21629	Counter Gear Loader	18	*	1½	3.50
J 21643	Spanner Wrench	*	*	1½	14.50
J 21654	Converter Holding Tool	27	*	¾	1.00
J 21655	Air Cond. Align. Ga.	*	*	8¼	72.50
J 21659	Injector Body Ream.	*	*	½	8.75
J 21661	Special Screw Set	27	*	2¼	2.60
J 21662	Pan Rem. Block Kit	3	*	2	4.60
J 21663	Alignment Gauge	18	*	¾	6.80
J 21664	Compressor Adapt.	27	*	¼	2.95
J 21669	Pin. Nut Skt. Wr.	*	*	2	18.00
J 21672	Blower Tool Set	*	*	5½	80.55
J-21672-7	Gear & Plate R. & Inst.	*	*	3	35.30
J 21674	Wedges	*	*	¼	3.60
J 21675	Main Brg. Cap Pull.	*	*	¼	6.75
J 21681	Cr. Gear Puller Adapt.	*	*	¾	9.95
J 21683	Brg. Rem. Adapter	*	*	¼	2.35
J 21684	Slotted Plate	*	*	1¼	9.15
J 21685	Carb. Chain Gauge	*	*	¼	1.75
J 21686	Steer. Wheel. Rem.	*	*	1	15.25
J 21687	Ball Stud Remover	*	*	½	7.70
J 21688	Door Hinge Pin Rem.	*	*	1½	6.40
J 21689	Front Spring Comp.	*	*	21½	31.15
J 21690	Ball Joint Rem. & Inst.	*	*	½	2.85
J 21691	Pinion Set. Gauge	*	*	2½	24.55
J 21692	Pin Brg. Cup Inst.	*	*	½	5.95
J 21693	Pin Brg. Cup Inst.	*	*	¾	5.85
J 21694	Brg. Roce Rem Instl.	*	*	4¼	18.25
J 21695	Bearing Installer	*	*	¼	5.75
J 21696	Brg. & Deflect Inst.	*	*	1	6.15
J 21697	Comp. Flange Wrench	*	*	¼	6.65
J 21698	Oil Seal Inst.	*	*	1¼	9.50
J 21699	Bearing Adj. Wr.	*	*	2¼	16.75
J 21699-01	Brg. Adj. Wr. Set	*	*	2½	20.85
J 21699-4	Nut Wrench Adapt.	*	*	¼	4.10
J 21700	Aligning Arbor	*	*	¼	2.15
J 21701	Cyl. Piston Instl.	*	*	¼	1.95
J 21702	Valve Guide Reamer	*	*	¼	5.40
J 21703	Valve Guide Reamer	*	*	¼	5.40
J 21704	Reamer 25 MM	*	*	¼	5.40
J 21706	Bearing Instl.	*	*	1¼	6.30
J 21707	Oil Seal Instl.	*	*	1½	15.75
J 21708	Brg. & Gear Instl.	*	*	½	4.45
J 21709	Lock Cap. Rem. Instl.	*	*	½	3.00
J 21712	Pinion Mt. Sleeve	*	*	½	4.35
J 21713	Br. Bleeder Adapt	*	*	¼	3.85
J 21714	Aligning Arbor	*	*	½	6.75
J 21715	Pin Plug Remover	*	*	¼	9.90
J 21718	Bearing Remover	*	*	¼	9.75
J 21721	Brg. & Defl. Rem. Inst.	*	*	3½	12.75
J 21722	Trans. Guide Pin	*	*	¼	3.35
J 21724	Lt. Switch Wrench	*	*	¼	2.75
J 21731	Fuel Press Ga. Set	*	*	2	10.65

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
J 21732	Vibration Puller Adapter	*	*	½	$ 3.55
J 21733	Cyl. Liner Assy. Tool ..	*	*	2½	13.70
J 21734	Inj. Test Nozzle Ad. ..	*	*	3½	39.50
J 21735-01	Cyl. Comp. Adapt.	*	*	1	38.45
J 21736	Driver Bit ⅜ Sq.	*	*	¼	4.75
J 21737	Driver Bit ½ Sq.	*	*	¼	4.75
J 21738	Allen Wrench 12 MM ..	*	*	½	1.65
J 21740	Oil Seal Installer	*	*	¾	7.90
J 21741	Cradle Adapter	*	*	48¾	47.85
J 21742	Timing Cov. Align.	3	*	¾	6.15
J 21743	Piston Ring Comp. ...	*	*	½	5.75
J 21744-01	Rack Travel Ga.	*	*	¾	15.00
J 21746	Cl. Pedal Sp. Rem. & Inst.	*	*	½	3.95
J 21752	Positraction Spr. Comp.	37	*	1	17.50
J 21753	Valve Guide Inst.	6	*	1¾	7.85
J 21754	Valve Guide Inst.	6	*	1½	7.55
J 21755	Eng. Stand Adapt. Plate	*	*	66	74.75
J 21757	Oil Signal Sw. Wrench .	10, 15	*	¼	1.75
J 21761	Nozzle Service Set ...	*	*	2	17.90
J 21762	Carbon Remover	*	*	¾	9.10
J 21767	Rev. Flow. Mod. Kit	*	*	1	18.75
J 21768	Fly. Hous. Seal Inst. ..	3	*	1½	6.10
J 21770	Inj. Nozzle Tester	*	*	18	140.00
J 21772	Bridge Adj. Tool	*	*	1¼	7.50
J 21773	Stamp. Ext. Holder ...	52, 58	*	½	2.00
J 21774-02	Trans. Brg. Rem. & Repl.	18	*	2¼	17.70
J 21775	Ctrshf. Align. Tool	18	*	1	3.00
J 21777	Pinion Setting Ga. ...	37	*	8	52.75
J 21779	Lever Position Pin ...	*	*	⅛	2.50
J 21780	Lever Adjust. Tool	*	*	⅝	10.65
J 21781	Pinion Hold. & Stak. ..	37	*	1⅛	12.80
J 21784	Diff. Brg. Inst.	37	*	¾	6.60
J 21786	Pinion Brg. Cur. Rem. .	37	*	¾	7.75
J 21787	Pinion Brg. Cur. Rem. .	37	*	¾	4.90
J 21788	Oil Seal Installer	39	*	2	3.50
J 21791	Vibr. Damp Puller	9	*	3¼	25.65
J 21793	Cyl. Lin. Clamp One ...	*	*	1⅝	5.80
J 21795-01	Gear Unit Holding Tool.	27	*	¾	6.65
J 21795-4	Thumb Screw	*	*	½	.90
J 21796	Oil Seal Inst.	39	*	½	3.75
J 21797	Speed Dr. Gr. Rem. Bt.	27	*	1⅛	1.75
J 21799	Alignment Bar	*	*	34	145.00
J 21800	Gauge Modif. Kit	*	*	¾	24.50
J 21825	Solderless Term. Tl. ..	15, 58	*	¾	5.60
J 21828	Reveal Moulding Inst. .	*	*	¼	2.20
J 21830	Suspen. Bsh. Set	*	*	3⅞	17.55
J 21831	Rr. Ax. Spindle Rem. ..	*	*	¼	3.10
J 21834	Align. Clamp Set	*	*	4¼	21.00
J 21836	Selector Gauge	*	*	½	20.70
J 21837	Axle Seal Inst.	*	*	2½	3.65
J 21838	Brg. Cup Inst.	*	*	¾	4.95
J 21842	Outer Seal Inst.	*	*	¼	3.65
J 21843	Fl. & Brg. Inst.	*	*	2¾	16.45
J 21844	Torque Arm Bushing Installer	*	*	⅝	2.20
J 21849	Core Plug Inst.	*	*	¾	6.80
J 21850	Bl. Core Plug. Inst. ..	*	*	½	5.75
J 21852	T & T Up Cov. Rem. ..	41	*	½	6.70
J 21853	Upper Cover Inst.	41	*	⅝	4.65
J 21854	Pivot Pin Rem.	41	*	¼	3.60
J 21855	T & T Sprg. Comp.	41	*	⅝	12.70
J 21856	Shift Lever Gauge	18	*	¼	$ 5.75
J 21858	Axle Brg. Remover	39	*	3¼	15.80
J 21859	Comp. Flange Rem. ...	*	*	3	28.30
J 21863	Pump Tool Set	*	*	14	62.85
J 21864	Pump Tool Set	*	*	36	147.10
J 21865	Eye Bolt ½-13	*	*	½	.60
J 21866	Eye Bolt ¾-11	*	*	¾	.85
J 21867	Pr. Gauge & Hose Assy.	21	*	1¼	8.50
J 21871	Oil Seal Installer	39	*	½	3.75
J 21872	Wr. Pin. Rem. & Repl. .	9	*	3⅛	15.95
J 21876	Susp. Cont. Bsh. Set ..	*	*	¼	4.90
J 21878	Lower Cont. Arm Spr. ..	*	*	⅜	1.50
J 21881	Cyl. Head Bolt Wr.	3	*	¾	3.85
J 21882	Inlet Tube Inst.	10	*	¼	1.45
J 21883	Strg. Pump Pull Plr. ..	44	*	1⅛	16.40
J 21884	Hydr. Tappet Rem. ...	*	*	2½	13.50
J 21885	Accum Piston Inst. ...	27	*	¾	13.25
J 21892	Cntr. Gear Load. Tl. ..	18	*	1½	3.50
J 21894	Oblong Bushing Installer	46	*	1⅝	25.10
J 21899	Oil Seal Installer	*	*	¾	8.00
J 21904	Speedo Gear Rem. Bolt	27	*	1	3.25
J 21905	Camp. Plug Driver	*	*	½	3.25
J 21925	Prop. Shaft Coup. Rem.	32	*	7¼	27.25
J 21927	Spring Instl.	*	*	2	4.75
J 21928	Torque Rod Adj. Tl. ..	*	*	3½	6.95
J 21930	Tie Rod End Puller	44	*	¾	13.25
J 21931-01	Valve Spring Comp. ...	6	*	1	11.75
J 21932	Sw. Bez. Fer. Nut Wr...	53	*	¼	3.85
J 21938	Piston Retain. Tool ...	*	*	¼	4.30
J 21939	Piston Seal Instal.	*	*	¾	4.50
J 21940	Piston Seal Instal. ...	*	*	½	4.10
J 21943	Monox. Exhaust Adapter	61	*	1	6.95
J 21944	Carb. Gauge Set. Afb. ..	*	*	⅛	4.95
J 21945	Carb. Gauge Set. 4 GC..	*	*	⅛	4.05
J 21946	Carb. Gauge Set 2 GC..	*	*	⅛	4.60
J 21947	Carb. Gauge Conver. Kit	*	*	⅛	2.00
J 21967	Bearing Remover	*	*	½	8.35
J 21970	T & T Holding Fixture ..	41	*	¾	4.75
J 21971	W. Pump Impell. Inst. .	*	*	⅝	4.60
J 21972	Ext. Hous. Bushing Rem. & Inst.	27	*	1½	5.35
J 21974	Temp. Gauge Set	56	*	1	12.00
J 21978	Bushing Rem. & Inst. ..	*	*	⅞	5.80
J 21979	Bushing Rem. & Inst. ..	*	*	⅝	5.25
J 21980	P. Shaft Coup. Instl. ..	32	*	1⅛	6.25
J 21981	Spring Inst. & Rem. ..	49	*	⅜	2.75
J 21982	E. St. Adapter Plate ..	*	*	60½	47.50
J 21983	Rear Oil Seal Inst.	*	*	6⅝	36.75
J 21984	Oil Seal Installer	28	*	3½	3.25
J 21985	Spee. Dr. Gr. Rem. Rod	27	*	1¼	6.85
J 21991	Carrier Bushing Rem. ..	*	*	¼	3.25
J 21993	Trk. Roll Lub. Nozz. ..	*	*	¼	2.50
J 21994	Brake Bleeder Adapt. ..	*	*	1	4.50
J 21995	Gov. Fork Inst. Tool ..	*	*	⅛	4.35
J 21996	Spec. Plug Remover ..	*	*	¾	4.70
J 21999	Fill Valve Assy. Set. ..	47	*	⅛	2.75
J 22042	L.H. Bolt Slv. Set	37	*	⅜	2.25
J 22055	Wind. Ret. Nut. Instl. ..	*	*	¼	4.60
J 22056	Cl. Sft. Align. Arbor ..	18	*	1⅜	5.75
J 22090	Lapping Block Set	*	*	28	95.75
J 22091	Seal Installer	*	*	1	8.65

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
SE 611-1	Carbon Brush (1″)	*	*	¼	$ 1.85
SE 686	Cyl. Gauge	*	*	2¼	28.50
SE 789	Burnishing Bar	*	*	1¼	16.50
SE 850	Wheel Puller	*	*	10	49.20
SE 855-7	Staking Punch	*	*	1¼	7.50
SE 875	Burnishing Bar	*	*	2	16.60
SE 879	Burnishing Bar	*	*	1¼	13.10
SE 920	Spring Assy. Sleeve ...	*	*	2	4.95
SE 931	Bush. Expand. Tool ...	*	*	1	12.05
SE 940	St. Wheel Puller	*	*	11	26.90
SE 996	Copper Tube Cutter ...	*	*	1	4.65
SE 1007-01	Feel & Scale Set	*	*	½	16.60
SE 1033	Burn. Support Block ..	*	*	14	34.00
SE 1036	Bushing Driver Set ...	*	*	13½	55.00
SE 1050	Pitman Arm Puller	*	*	2½	20.75
SE 1051	Pitman Arm Puller ...	*	*	4	22.55
SE 1052	Pitman Arm Puller ...	*	*	7½	33.40
SE 1065-A	Pinion Setting Gauge ..	*	*	20	121.45
SE 1065-64	Disc Set	*	*	62½	217.50
SE 1065-9A	Adapter Discs	*	*	¾	5.75
SE 1065-9B	Adapter Discs	*	*	1	5.75
SE 1065-9C	Adapter Discs	*	*	1¼	5.75
SE 1065-9D	Adapter Discs	*	*	1¼	5.25
SE 1065-9E	Adapter Discs	*	*	1¼	6.25
SE 1065-9G	Adapter Discs	*	*	1½	6.75
SE 1065-9H	Adapter Discs	*	*	2	7.25
SE 1065-9I	Adapter Discs	*	*	1¾	6.75
SE 1065-9J	Adapter Discs	*	*	1	6.25
SE 1065 9K	Adapter Discs	*	*	1½	6.25
SE 1065-9L	Adapter Discs	*	*	2¾	7.25
SE 1065-9M	Adapter Discs	*	*	2½	7.25
SE 1065-9N	Adapter Discs	*	*	2	5.75
SE 1065 9O	Adapter Discs	*	*	1¾	6.75
SE 1065-9P	Adapter Discs	*	*	1½	6.75
SE 1065-9R	Adapter Discs	*	*	2¾	7.25
SE 1065-9S	Adapter Discs	*	*	3½	10.15
SE 1065-9T	Adapter Discs	*	*	4	10.65
SE 1065-9W	Adapter Discs	*	*	¾	6.25
SE 1065-9Y	Adapter Discs	*	*	¾	5.75
SE 1065-9Z	Adapter Discs	*	*	¾	6.25
SE 1065-AA	Adapter Discs	*	*	1¼	3.60
SE 1065-9BB	Adapter Discs	*	*	1¼	6.75
SE 1065-9CC	Adapter Discs	*	*	1½	7.25
SE 1065-9DD	Adapter Discs	*	*	1¾	7.25
SE 1065-9EE	Adapter Discs	*	*	1¾	7.25
SE 1065-9HH	Adapter Discs	*	*	1¾	7.25
SE 1065-9II	Adapter Discs	*	*	1¾	7.25
SE 1065-9JJ	Adapter Discs	*	*	2½	7.75
SE 1065-9KK	Adapter Discs	*	*	2½	7.75
SE 1065-9LL	Adapter Discs	*	*	2¾	7.75
SE 1065-9MM	Adapter Discs	*	*	1¼	6.75
SE 1065-9NN	Adapter Discs	*	*	1½	7.25
SE 1065-9OO	Adapter Discs	*	*	1½	7.25
SE 1065-9PP	Adapter Discs	*	*	1	6.75
SE 1065-9RR	Adapter Discs	*	*	1¼	6.75
SE 1065-9SS	Adapter Discs	*	*	¾	6.25
SE 1065-9WW	Adapter Discs	*	*	1¾	7.25
SE 1065-9XX	Adapter Discs	*	*	1¾	7.25
SE 1065-9YY	Adapter Discs	*	*	2½	7.25
SE 1065-9ZZ	Adapter Discs	*	*	2½	7.75
SE 1103	Staking Tool	*	*	2½	12.00
SE 1121	Off. Wrench Extension .	*	*	¾	4.25
SE 1122	Off. Wrench Extension .	*	*	¾	6.30

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
SE 1147	Reamer Set	*	*	8	$135.00
SE 1149	Ring Expander Set	*	*	6	68.25
SE 1149-1	Ring Expander (3⁵⁄₁₆″) .	*	*	½	6.75
SE 1149-2	Pis. Ring Rem. (3⅜″) .	*	*	½	6.75
SE 1149-3	Pis. Ring Rem. (3½″) .	*	*	½	6.75
SE 1149-4	Piston Ring Tool (3⅞″)	*	*	½	6.75
SE 1149-5	Piston Ring Tl. (4⅛″) .	*	*	½	6.75
SE 1149-6	Piston Ring Tl. (4⅜″) .	*	*	½	10.50
SE 1149-7	Piston Ring Tl. (3⁷⁄₁₆″) .	*	*	½	6.75
SE 1149-8	Piston Ring Tl. (3⁹⁄₁₆″) .	*	*	½	6.75
SE 1149 9	Piston Ring. Exp. (4¹³⁄₁₆″)	*	*	½	14.00
SE 1149-10	Piston Ring. Tl. (3⅝″) .	*	*	½	6.75
SE 1149-11	Piston Ring. Tl. (3¾″) .	*	*	½	6.75
SE 1149-12	Ring Replacer (3¹³⁄₁₆″) .	*	*	½	6.75
SE 1149-13	Ring Replacer (4½″) ..	*	*	½	10.50
SE 1149-14	Ring Expander (3¹¹⁄₁₆″) .	*	*	½	6.75
SE 1178	Tube Bender	*	*	½	1.40
SE 1263	Piston Pin Driver	*	*	1	4.35
SE 1368	Puller Set	*	*	10	61.55
SE 1386	Flaring Tool	*	*	14½	104.90
SE 1499	Snap Ring Tool Set ...	*	*	1¼	14.80
SE 1539	Pitman Arm Puller	*	*	4¾	22.55
SE 1565	Clutch Spr. Tester	*	*	22	97.50
SE 1567	Cleaning Brush Set ...	*	*	½	10.25
SE 1575	Riveting Fixture	*	*	121	260.00
SE 1581-1B	Handle	*	*	2½	3.80
SE 1585	Staking Tool	*	*	1¾	14.80
SE 1694	Truarc Pliers (#2)	*	*	¼	2.30
SE 1705	Valve Guide Reamer ..	*	*	¼	4.85
SE 1715	Crank. Gear Puller ...	*	*	13¼	46.00
SE 1717	Timing Gear Cover Sl. .	*	*	2¼	7.50
SE 1718	Oil Seal Replacer	*	*	1⅜	6.25
SE 1719-01	Bearing Cap Remover .	*	*	2½	12.65
SE 1720	Oil Seal Compressor ..	*	*	8½	24.50
SE 1721	Pump Seal Installer ..	*	*	1¼	2.75
SE 1722	Valve Guide Remover ..	*	*	½	5.00
SE 1723	Valve Guide Replacer ..	*	*	1¼	3.50
SE 1724-A	Bushing Replacer	*	*	35	108.90
SE 1725	Core Plug Inst. Tool ..	*	*	1¼	5.75
SE 1728	Tube Nut Wrench	*	*	1	4.90
SE 1735	Valve Plug Gauges ...	*	*	1½	35.00
SE 1745	Wheel Adj. Wrench ...	*	*	½	1.45
SE 1746	Bearing Remover	*	*	3½	30.00
SE 1772	Holley Carb. Tl. Kit ...	*	*	1¾	36.70
SE 1784	Facing Arbor	*	*	3	20.60
SE 1785	Snap Ring Pliers	*	*	½	5.70
SE 1792	Spanner Wrench	*	*	2	8.70
SE 1796	Axle Housing Spreader	*	*	20	34.75
SE 1821-01	Steering Wheel Puller .	*	*	¾	18.25
SE 1825	Zenith Carb. Tl. Set ...	*	*	3	18.95
SE 1826	Valve Guide Ga. Set ..	*	*	⅛	8.65
SE 1827	Band Adj. Gauge	*	*	¼	16.55
SE-1828	Trans. Press. Gauge ..	*	*	2	9.75
SE 1829	Rear Eng. Support	*	*	9½	13.30
SE 1830	Trans. Lift Cradle	*	*	14	21.50
SE 1831	Converter Aligner	*	*	4½	47.50
SE 1832	Trans. Pilot Studs	*	*	¼	1.25
SE 1833	Adapt. Plate Align. ...	*	*	1¾	16.25
SE-1834	Bell Housing Fixture ..	*	*	4¼	18.90
SE 1835	End-Play Gauge	*	*	8¾	28.35
SE 1836	Gov. Set-Screw Wr. ...	*	*	¼	2.95
SE 1837	Lube Valve Rod	*	*	¼	2.25
SE-1838	Piston Inst. Pins	*	*	¼	9.00

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
SE 1839	Clutch Sleeve	*	*	1½	$ 3.70
SE 1841	Bearing Installer	*	*	2	9.95
SE-1842	Auto. Trans. Stand	*	*	2½	7.45
SE 1843	Bearing Puller	*	*	5	15.65
SE-1846	Valve Lifter	*	*	6	12.65
SE 1847	Reamer Set	*	*	3½	32.95
SE 1848	Dial Indicator Gauge	*	*	3	37.95
SE 1877	Hyd. Valve Lift. Rem.	*	*	¾	12.75
SE-1878	Power St. Tool Set	*	*	2	17.10
SE-1879	Slide Hammer Set	*	*	12½	27.50
SE 1880-01	Camshaft Remover	*	*	3¾	10.80
SE 1881	Valve Guide Remover	*	*	½	4.90
SE-1882	Valve Guide Installer	*	*	1½	13.10
SE-1883	Valve Guide Reamer	*	*	1¼	9.35
SE 1884	Snap Ring Pliers (Int.)	*	*	¼	2.65
SE 1885	Bushing Remover	*	*	2¾	7.75
SE 1886	Bushing Burnisher	*	*	2¼	14.55
SE 1887	Exh. Valve Remover	*	*	2¼	26.75
SE-1888	Piston Pin Remover	*	*	3¼	5.10
SE 1889	Cyl. Head Hold. Fix.	*	*	28½	27.75
SE 1890	Hydraul. Lif. Unload	*	*	¼	8.10
SE 1891	Hyd. Lifter Brush	*	*	¼	.45
SE 1892	Hyd. Lifter Tray	*	*	12	23.40
SE 1893	Hyd. Lifter Tester	*	*	28	65.95
SE-1894	Hyd. Lift. Storage Box	*	*	3	9.90
SE 1896	Cyl. Head Sling	*	*	3¾	9.35
SE 1897-02	Bushing Rem. & Inst.	*	*	17¾	73.90
SE 1898	Pulley Spacer	*	*	¼	.95
SE 1899	Eng. Lift. Eye Bolts	*	*	¾	5.00
SE 1900-01	Cam. & Cr. Gear Inst.	*	*	10¼	95.00
SE 1901	Oil Seal Compressor	*	*	7¼	14.45
SE 1902	Holley Distrib. Tools	*	*	3	23.40
SE 1903	Tube Wrench	*	*	1	5.30
SE 1904	Hyd. Clutch Spr. Tool	*	*	1½	5.45
SE 1905	Rem. & Installer	*	*	19¼	85.50
SE 1909	Band Adjust. Wrench	*	*	4½	39.10
SE 1910	Band Adjust. Tool	*	*	2	32.85
SE 1911	Spring Compressor	*	*	2¼	9.60
SE 1912	Spring Compressor	*	*	2½	16.25
SE 1913	Clutch Holder	*	*	3¾	4.75
SE 1914	Oil Seal Replacer	*	*	3½	12.50
SE 1915	Dial Ind. Support	*	*	½	2.10
SE 1917	Funnel	*	*	2¼	9.95
SE 1919	Torque Wrench Set	*	*	2½	21.45
SE 1933	4-X Multi. Wrench	*	*	15½	180.95
SE 1935	Lock Nut Wrench	*	*	13½	102.15
SE 1938	01 Hdlt. Dev.	*	*	7	49.95
SE 1938-1	Light Intensity Meter	*	*	8⅝	29.95
SE 1940	Tube Nut Wrench	*	*	5¾	8.60
SE 1941	Oil Seal Remover	*	*	½	13.70
SE 1942	Oil Seal Installer	*	*	5¾	27.00
SE 1943	Valve Guide Installer	*	*	1	10.35
SE 1944	Off. Wrench (¾″ Box)	*	*	1	3.95
SE 1945	Core Plug Installer	*	*	½	4.95
SE 1946	Piston Pin Remover	*	*	5½	16.50
SE 1947	Hyd. Lifter Remover	*	*	1¼	19.75
SE 1948	Engine Lifting Plate	*	*	8	17.80
SE 1949	Oil Seal Aligner	*	*	5¾	11.90
SE 1950	Impeller & Hub Inst.	*	*	1	8.30
SE 1951	Exh. Valve Remover	*	*	1¼	33.75
SE 1951-9	Expander Screen Assy.	*	*	⅛	6.90
SE 1951-10	Expander Screen Assy.	*	*	⅛	6.90
SE 1952	Spring Depressor	*	*	½	6.45
SE 1953	Tor. Conv. Aligner	*	*	¾	$ 8.85
SE 1954	Thermostat Adapter	*	*	2¼	8.75
SE 1955	Holley Distrib. Tool	*	*	3⅞	39.20
SE 1966	Lock Nut Wrench	*	*	4¼	22.80
SE 1967	Poppet Ball Assembly	*	*	¼	5.60
SE 1969	Distributor Tool Kit	*	*	⅝	20.70
SE-1971-01	Pinion Setting Gauge	*	*	7¼	47.50
SE 1985	Pow. St. Press. Test	*	*	3½	27.50
SE 1994	Engine Lift. Fixture	*	*	10½	37.20
SE 1995	Piston Pin Remover	*	*	¾	4.80
SE 1996	Brg. Nut Wrench	*	*	3¾	19.30
SE 1998	Cyl. Balance Tester	*	*	4	19.75
SE 2003	Air Pressure Adapter	*	*	¼	3.75
SE 2011	Cam. Bush. Remover	*	*	11¼	59.00
SE 2022	Torsion Tool Set	*	*	5	30.80
SE 2024	Bushing Installer	*	*	3½	10.45
SE 2045	Equalizer Beam End Nut Wrench	*	*	3	14.25
SE 2049	Feeler Ga. (.015″-.017″)	*	*	¼	4.85
SE 2051	Inj. Timing Gauge	*	*	¼	1.65
SE 2054	Axle Spreader	*	*	14½	26.90
SE 2060	Alternator Tool Set	*	*	3¼	21.80
SE-2060-1	Diode Installer	*	*	½	3.35
SE 2060-2	Diode Remover	*	*	¼	4.25
SE 2060-3	Support	*	*	¼	1.90
SE 2060-4	Diode Test Light	*	*	¼	2.75
SE 2060-5	Gen. Output Test Adapt.	*	*	¼	1.00
SE 2060-7	Wir. Harn. Conn. Jump.	*	*	¼	.50
SE 2069-9	Volt. Reg. Wiring Harn.	*	*	¼	4.40
SE 2066	Clus. Gear Brg. Rem. & Inst.	*	*	1½	14.70
SE 2068	Clutch Release Lever Adj. Spacer Spale Set	*	*	7½	36.75
SE 2072	Governor Con. Valve Assy. & Adj. Tl.	*	*	¼	5.80
SE 2073	Valve Core Rem. & Repl.	*	*	¼	4.25
SE 2074	Height Control Valve Comp.	*	*	½	6.25
SE 2075	Hub. Brg. Nut Wrench	*	*	1	14.95
SE 2081	Fastestor	*	*	4	19.95
SE 2082	Assy. & Disassy. Fixture	*	*	3	4.50
SE 2083	Turbocharger Impeller Inst.	*	*	¼	3.55
SE 2084	Exhaust Valve Guide Reamer (.002 O.S.)	*	*	1⅜	9.35
SE 2085	Water Pump Pulley Hub Inst.	*	*	⅝	4.35
SE 2086	Water Pump Impeller Shim Set	*	*	¼	1.50
SE 2091	Universal Seal Puller	*	*	3	5.25
SE 2092	Seal Installer	*	*	4	34.50
SE 2093	Main Brg. Cap Rem.	*	*	¼	4.75
SE 2094	Valve Seat Peening Tool	*	*	2	15.65
SE 2095	Piston Pin Rem. & Inst.	*	*	3	21.80
SE 2096	Oil Seal Installer	*	*	3	16.75
SE 2097	Tappet Rem. & Inst.	*	*	3½	21.25
SE 2098	Pump Hub Brg. & Rem. Inst.	*	*	1½	9.25
SE 2099	Inj. Pump Drive Loc. Fix.	*	*	2½	29.15
SE 2100	Diff. Side Brg. Repl.	*	*	2	29.75
SE 2101	Valve Recession Checking Gauge	*	*	¾	18.60

*Not Illustrated

Tool No.	Description	Form No. 64-61 Page No.	Form No. 61-1 Page No.	Weight in lbs.	Dealer Net Price
SE 2102	Injector Nozzle Assy. Holding Stand	*	*	5	$ 13.50
SE 2103	Engine Lifting Plate & Cable Assy.	*	*	3½	24.90
SE 2104	Cyl. Head Hldg. Fixture	*	*	10¾	7.25
SE 2105	Engine Support Plate	*	*	2½	10.30
SE 2110	Delivery Valve Rem.	*	*	¼	5.55
SE 2111	Suction Valve Rem. & Instl.	*	*	⅛	1.60
S 200	Gauge	*	*	¼	1.50
S 1055	Retainer	*	*	¼	1.55
S 1070	Joint Clamp	*	*	1	5.50
S 1135	Pitman Arm Remover	*	*	1½	18.40
S 1138	Adjuster	*	*	½	4.75
SW 91	Installer	*	*	¾	4.85
SW 97	Remover	*	*	3¼	$ 11.95
SW 225	Installer	*	*	2½	9.30
SE 2130	Lifting Eye	*	*	½	4.70
SE 2131	Clutch Disc Locking Wire Rem. & Inst.	*	*	1	2.80
SE 2132	Clutch Spring Comp.	*	*	2	9.60
SE 2133	Clutch Clearance Checking Fixture	*	*	10	62.60
SE 2134	Front Oil Pump Inst.	*	*	3½	11.25
SE 2135	Conv. Cover & Pump Assy. Rem.	*	*	2½	9.20
SE 2136	Guide Bolt Set	*	*	¼	7.70
SE 2137	Clutch Housing Bushing Instl.	*	*	1	6.90
SE 2138	Bushing Service Set	*	*	5	44.15

*Not Illustrated

SERVICE TOOL DIVISION

KENT-MOORE ORGANIZATION, INC.

Engineers and Manufacturers of Automotive Service Tools and Equipment

Executive Offices: 28635 Mound Road—Warren, Michigan 48092
Factories and General Offices: Jackson, Michigan 49203

FORM NO. 65-5

LITHO IN U.S.A.